

**Reference Manual
for
EL470 IP Satellite Modem**

version 3.1

SHAPING THE FUTURE OF SATELLITE COMMUNICATIONS



© 2011 Newtec Cy N.V.

The material contained in this document is confidential and intended for use only by parties authorised by Newtec Cy N.V.

All Rights Reserved. No part of this document may be photocopied, reproduced, stored in a retrieval system or transmitted in any form or by any means whether electronic, mechanical or otherwise without the prior written permission of Newtec Cy N.V.

Newtec Cy N.V.
Laarstraat 5
9100 Sint-Niklaas, Belgium

General: +32 (0)3 780 65 00
www.newtec.eu
Fax +32 (0)3 780 65 49
General: general@newtec.eu

ABOUT THIS MANUAL

This manual provides a detailed overview of the commands used in this device. Here you can find a description of the function of the command, the possible values and structures of the commands and the information you need to be able to enter commands using RCMP or SNMP.

Cautions and symbols

The following symbols appear in this manual:



A hint message indicates information for the proper operation of your equipment, including helpful hints, short cuts or important reminders.



A reference message is used to direct to an internal reference within the document, a related document or a web-link.

Version history and applicability

Document version	Date	Subject	Comment
Version 1.2	May 14 th 2008	EL470	Initial release
Version 1.3	July 22 nd 2008	EL470	Feedback Implementation
Version 1.4	November 6 th 2008	EL470	GbE R6
Version 1.5	December 8 th 2008	EL470	Remove ASI alarms
Version 2.0	February 26 th 2010	EL470	Release 7
Version 3.0	September 30 th 2010	EL470	Release 8 AES, GSE, DC BUC Power
Version 3.1	September, 2011	EL470	L-band Transmit: always enabled Tx supression on demod unlock

Related documentation

- EL470 User Manual: this manual gives a general description of the device, its technology and its features. It also explains a number of use cases with step-by-step configuration instructions.
- RMCP and SNMP manual.



Request a RMCP and SNMP manual via the Newtec Service Desk tool:

> Browse to <http://customersupport.newtec.eu>
> Fill in your Username and Password
> Create a ticket

As response of your request you will receive the manual from our support team.

In case you don't have a Username and Password yet for the Newtec Service Desk tool request a login to customersupport@newtec.eu

Applicability

Product range

Elevation

Software ID

M&C ntc6279

Software versions

Release 8.1

Feedback

Newtec Cy N.V. encourages your comments concerning this document. We are committed to providing documentation that meets your needs.

Please send any comments by contacting us at documentation@newtec.eu.

Please include document and any comment, error found or suggestion for improvement you have regarding this document.

TABLE OF CONTENTS

About this Manual.....	ii
Table of Contents.....	v
1 Introduction.....	1
Contents of the Document.....	1
Searching parameters in this Manual.....	1
Parameter Table.....	2
Introduction.....	2
'Normal' Command.....	2
Structured Command.....	4
Special Command.....	7
Array Command.....	7
2 Operation.....	8
Overview.....	8
3 User Menu.....	11
4 Unit Menu.....	12
/Unit.....	12
/Unit/Setup.....	12
/Unit/Control.....	20
/Unit/Monitor.....	31
/Unit/Architecture.....	34
Retrieving Architectural Information.....	34
Unit/Architecture/general.....	34
Unit/Architecture/Common/M&C module.....	35
Unit/Architecture/Modem/Interfaces.....	35
Unit/Architecture/Modem/Modulation.....	35
Unit/Architecture/Modem/Demodulation.....	36
Architecture Commands.....	36
Unit/Diagnostics.....	43
5 Modem.....	44
/Modem/Control.....	44
/Modem/Control/Common.....	44
/Modem/Control/Interfaces.....	45
/Modem/Control/Modulation.....	71

/Modem/Control/Demodulation.....	99
/Modem/Monitor.....	116
/Modem/Monitor/Interfaces.....	116
/Modem/Monitor/Modulation.....	146
/Modem/Monitor/Demodulation.....	157
Config.....	166
Structured Elements with Individual Access.....	168
Variables only Used via other Commands.....	194
Test.....	235
6 Alarms.....	246
Alarm Types.....	246
Alarm Commands.....	246
Alarm Front Panel Operation.....	249
Alarm List.....	251
Appendix A: Action Keys.....	254
Appendix B: Troubleshooting.....	257
Appendix C: Abbreviations.....	258
Appendix D: List of Commands.....	262

1 INTRODUCTION

Contents of the Document

This manual is the reference guide of the EL470. It provides a detailed description of the parameters:

- Chapter 2 gives an overview of the menu structure.
- Chapter 3 describes the User menu parameters.
- Chapter 4 describes the Unit setup, control, monitor and architecture parameters.
- Chapter 5 describes the IP Satellite Modem specific parameters.
- Chapter 6 describes the Alarms.
- Appendix A describes how to configure Action Keys.
- Appendix B describes a brief guide on Troubleshooting.
- Appendix C gives a list of Abbreviations.
- Appendix D gives a list of all Commands in this manual.

Searching parameters in this Manual

The parameters you find in the Menu Structure section on page 8 of this manual are organised in the same order as the menu tree of your IP Satellite Modem. Depending on hardware installed and on software capabilities, you may not have access to some of the menu items described in this manual.

The menu structure of any Newtec Cy N.V. device is built dynamically depending on its configuration.

The list of parameters is rather extensive. You can choose between three types of navigation:

1. A classic contents list, list of figures and abbreviations list as described in the table of contents.
2. A tree structure of variables in the IP Satellite Modem. The tree structure of the variables visualised on the next pages provides, in a very compact way, the menu structure of the IP Satellite Modem.
3. A search in the list of commands: Appendix D on page 262 contains the alphabetical list of mnemonics which directs to the page where the mnemonic-variable is used.

Parameter Table

Introduction

There are specific tables for three types of commands:

- Command
- Structured Command
- Special Command

These types of commands are described in detail in the following paragraphs.



Request a RMCP and SNMP manual via the Newtec Service Desk tool:

- > Browse to <http://customersupport.newtec.eu>
- > Fill in your Username and Password
- > Create a ticket

As response of your request you will receive the manual from our support team.

In case you don't have a Username and Password yet for the Newtec Service Desk tool request a login to techsupport@newtec.eu

'Normal' Command

Description

The 'normal' command is a command that sets or gets the value of a variable in the device.

You can use a 'normal' command:

1. As stand alone.
2. As stand alone and used in a structured or special command. In this case a link towards the command is added in the structured or special command.
3. As part of a structured or special command only. In this case the location in the command description is NA (Not Applicable). In the command description there is a link to both the structured and special command in which this 'normal' command is used.




Figure 1: Usage of a Normal Command

The table of description of a 'normal' command is presented below.

Command <Technical Command Name – for future use>	<The name of the command, also visualised in the GUI (Graphical User Interface / Web Interface)>		
Location	<location of the command>		
	<This row cautions that this parameter is only available for a certain hardware configuration or for a certain setting.>		
Description	<Description of the Command>		
RMC Command	<RMC command> For details we refer to the RMC manual.	Access	Normal user: <read/write rights> Expert user: <read/write rights>
SNMP	Table		
	Comma nd		
	OID		
Values	Factory Default	Enumeration or Unit	Value
	<factory default: enumeration>	<mnemonic for first enumeration> <mnemonic for second enumeration> ... or <the unit of in which the value is given> There are two types of units: - command unit: the unit in which the command is given - GUI unit: the unit in	<value enumeration 1> <value enumeration 2> ... values are given in command units Value can be a: - discrete e.g. 1 - range e.g. [0..255] - string e.g. 10.0.0.1

Command	<The name of the command, also visualised in the GUI (Graphical User Interface / Web Interface)>		
		which the GUI is working	



The displayed range of parameter values may differ depending on the configuration of the device. The values given in this manual are applicable for the device in full option configuration.

Example

- Table of description of the 'Device serial number' command.

Command		Device serial number			
SyDev Sn					
Location	/Unit/Architecture				
Description	This number should be the same as the serial number on the backpanel label (for rack mounted units).				
RMCP Command	SLs		Access	Normal user : R Expert user : R	
SNMP	Table	ntcDevsMod01SystemEntry			
	Command	ntcDevsMod01SyDevSn			
	OID	1.3.6.1.4.1.5835.3.1.1.1.31.0.1			
Values	Factory Default		String Description		
	03051439		length : 8 (fixed) format : Hexadecimal chars		

Structured Command

Description

A structured command can have more than one argument that are separated by commas ','. These are especially useful to get or set parameters that are closely related.

You can read and/or set this structure in the EL470 through one single command. In some cases, structured variables are designed for efficiency, for example to communicate less data. In other cases, structured variables are designed so you can set or read closely related variables immediately.

In this way, you can avoid invalid intermediate states, which could occur if you were to set the components one by one.

The structured commands have an identical list of set and reply arguments.




Figure 2: Usage of a Structured Command
A description table of a structured command is presented below.

Structured Command <Technical Command Name – for future use>		<The name of the command, also visualised in the GUI>					
Location	<location of the command>						
	<This row cautions that this parameter is only available for a certain hardware configuration or for a certain setting.>						
Description	<Description of the Command>						
RMCP Command	<RMCP command> For details we refer to the RMCP manual.		Access	Normal user: <read/write rights> Expert user: read/write rights>			
SNMP	Table						
	Command						
	OID						
Variables			Page				
<arguments used in the commands – these arguments are hyperlinked, so by selecting this argument you jump to it in this document>			<page ref>				

Example

The table of description for the 'PRBS counter' Structured Command.

Structured Command		PRBS counter					
BecBec							
Location	Demodulator/Monitor						
Description	Reads the current status (PRBS synchronisation), elapsed time since start of the PRBS counter being locked and the number of PRBS errors counted since last lock. Reset the time and number counters by pushing the "CLR" key.						
RMC Command	Bec		Access	Normal user : no access Expert user : R			
SNMP	Table	ntcDevsMod01BecEntry					
	Command	ntcDevsMod01BecBec					
	OID	1.3.6.1.4.1.5835.3.1.10.1.3.1.1					
Variables		Page					
BecStatus		<page reference to the page where BecStatus is described>					
BecErrCnt		<page reference to the page where BecErrCnt is described>					
BecSecs		<page reference to the page where BecSecs is described>					

The Page column refers to the pages describing the variables in detail.

e.g. description table of the variable BecStatus:

Command		BER counter status					
BecStatus							
Location	NA						
Used as variable of	Command(s)	Page					
	BecBec	<page ref. to the page where the command BecBec is described>					
Description	BecBer	<page ref. to the page where the command BecBer is described>					
	Current state of the BER counter.						
	<ul style="list-style-type: none"> • unsync: BER counter is continuously trying to synchronise to the data stream • ones: BER counter detects presence of AIS (all-ones) in data stream • PRBS: BER counter detects the PRBS pattern <p>Note that in the AIS and PRBS states, the BER counter is synchronised and fully operational. The error count and ratio readings indicate the received errors as compared to the AIS or PRBS signal.</p>						
RMC Command	Bcs		Access	Normal user : no access Expert user : R			
SNMP	Table	ntcDevsMod01BecEntry					
	Command	ntcDevsMod01BecStatus					
	OID	1.3.6.1.4.1.5835.3.1.10.1.11.1.1					
Values	Factory Default		Enumeration	Value			
	unsync		unsync	0			
	ones		ones	1			
	prbs		prbs	2			
	disabled		disabled	3			

Special Command

Special commands can have different receive and reply arguments. These commands exist in 'set' and 'get' versions. Keep in mind that the command/reply argument lists can differ between the get and the set version.

Page references in the table refer to the pages where the commands/variables are detailed.

All complex commands fall into this category.

Special Command <Technical Command Name – for future use>		<The name of the command, also visualised in the GUI>			
Location	<location of the command>				
	<This row cautions that this parameter is only available for a certain hardware configuration or for a certain setting.>				
Description	<Description of the Command>				
RMCP Command	<RMCP command> For details we refer to the RMCP manual.		Access Normal user: <read/write rights> Expert user: <read/write rights>		
SNMP	Table				
	Command				
	OID				
Get Command Arguments		Set Command Arguments			
Command(s) / Variable(s)		Page	Command(s) / Variable(s)		
<command arguments used in requesting information – these arguments are hyperlinked. By selecting this argument you are directed to the specific description in this document>		<page ref.>	<command arguments used in requesting information – these arguments are hyperlinked. By selecting this argument you are directed to the specific description in this document>		
Get Reply Values		Set Reply Values			
Command(s) / Variable(s)		Page	Command(s) / Variable(s)		
<command arguments used in requesting information – these arguments are hyperlinked. By selecting this argument you are directed to the specific description in this document>		<page ref.>	<command arguments used in requesting information – these arguments are hyperlinked. By selecting this argument you are directed to the specific description in this document>		

Array Command

An array command is used when a variable is used over a number of identical instances. In the RMCP command overview array commands have the "array range" indicated, as explained in the General RMCP Manual.

2 OPERATION

Overview

In this overview you see the menu structure of variables in the EL470. This is also the menu of the Graphical User Interface (GUI). The main categories in the EL470 device are shown in Table 1 .

EL470		Page
	User	11
	Unit	12
	IP Satellite Modem	44
	Alarm	246
	Config	166

Table 1 - High level structure of device parameters

The following tables show the structure details of the EL470 menu.

For a list of all the commands and their page reference, refer to the list of Commands at the end of this document.

	EL470 IP Satellite Modem	Page
Unit		12
	Setup	12
	Serial port settings	14
	Ethernet settings	15
	Display settings	17
	SNMP settings	18
	Web Interface	19
	Control	20
	AES	29
	Monitor	31
	Architecture	34
	Diagnostics	43

	EL470 IP Satellite Modem		Page
Modem			44
	Control		44
		Common	44
		Interfaces	45
			Ethernet 45
		Modulation	71
			Main 71
			DVB-S2 Streams 79
			BasebandFraming 80
			ACM control 82
			PHY 88
			AES 93
		Demodulation	99
			Backup carrier 107
			ACM client 109
			AES 109
	Monitor		116
		Interfaces	116
			Ethernet 116
		Modulation	146
			Packets 151
			Frames 153
			ACM control 155
		Demodulation	157
			ModCodStats 162
			ACM client 163
	Actionkeys		254
	Test		235
		Interfaces	235
		Modulation	236

	EL470 IP Satellite Modem			Page
		Demodulation		244
Config				166
	Structured elements with Individual Access			168
	Variables only Used via other Commands			194

Table 2 : Structure of the 'IP Satellite Modem' sub-menu operating in normal mode

3 USER MENU

You can configure the user menu for your own use. In this way, you can create a quick access to those control and monitoring parameters that you need to change or monitor regularly. In addition, you can also change the order in which the menu items are presented to meet your specific demands. This is very useful in, for example, the DSNG applications. Here you can pre-configure the general parameters and store them in the default boot-configuration. Here you can pre-configure the general parameters and store them in the default boot-configuration. The relevant parameters needing a quick change (during link setup) are made available as a group in the user menu.

```
EL470>> User  
:go to/unit/setup to define
```

Description: enter this menu to access the commands you have grouped.

Go to .../**Unit/Setup/User** menu to add or remove commands from the user defined menu.

4 UNIT MENU

In this section of the menu you can control and monitor the operational parameters of the device. The parameters to use the device as test generator or bit error monitor are also explained. When you are logged in as administrator or in expert mode, additional (non-frequently used) parameters become available. When you are logged in as operator or in normal mode, only relevant operational parameters are shown.

/Unit

/Unit/Setup

Special Command SyDevMode		Device mode	Device mode
Location	/Unit/Setup		
Description	Configuration of the device operation mode. The following device operating modes are defined: <ul style="list-style-type: none"> Normal mode: This is the standard operating mode which enables the default set of parameters that are most frequently used. Expert mode: This mode gives an expert operator access to an additional set of more advanced parameters. A password is required to switch to expert mode. This password is the model number of the device. 		
RMCP Command	SMm	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyDevMode	
	OID	1.3.6.1.4.1.5835.3.1.1.1.18.0.1	
Get Command Arguments		Set Command Arguments	
Command(s) / Variable(s)	Page	Command(s) / Variable(s)	Page
none	none	SyDevModeState SyDevModePass	188 228
Get Reply Values		Set Reply Values	
Command(s) / Variable(s)	Page	Command(s) / Variable(s)	Page
SyDevModeState	188	SyDevModeReply SyDevModeState	229 188

Command SyDevRmcVer		RMCP version	RMCP version
Location	/Unit/Setup		
Description	Readout of the current RMCP version. It allows controlling devices to distinguish between RMCP versions and adapt their functionality accordingly. <ul style="list-style-type: none"> RMCP version 2.0 is the enhanced protocol that can be used when designing new management systems. Contact Newtec to obtain a copy of the separate RMCP user manual. 		
RMCP Command	CRV	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyDevRmcVer	
	OID	1.3.6.1.4.1.5835.3.1.1.26.0.1	
Values	Factory Default	Enumeration	Value
	rmcp2	V2.0	2

Command SyDevRtc		System time	System time
Location	/Unit/Setup		
Description	Configuration command to read or modify the real time clock. The format is hh:mm:ss dd/mm/yyyy.		
RMCP Command	RTc	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyDevRtc	
	OID	1.3.6.1.4.1.5835.3.1.1.1.59.0.1	
Values	Factory Default	String Description	
	16:24:53 14/05/2003	length : 0 .. 19 format : \d{2}:\d{2}:\d{2} \d{2}\d{2}\d{4}	

Command SyDevUptime		System uptime	System uptime
Location	/Unit/Setup		
Description	Readout of the time passed since last device boot. The data is displayed in days, hours, minutes and seconds. Remark: This data is the uptime of the operating system, not the uptime of the application.		
RMCP Command	Upt	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyDevUptime	
	OID	1.3.6.1.4.1.5835.3.1.1.1.84.1.1	

Command SyDevUptime		System uptime	System uptime
Values	Factory Default	String Description	
		length : 0 .. 128 format : any chars	

/Unit/Setup/Serial port settings

Command SyDevSerIfType		Serial M&C interface type	Serial interf. type
Location	/Unit/Setup/Serial port settings		
Description	Configuration of the monitoring and control serial port interface type: RS485 (default) or RS232. RS232 is used for monitoring and control of a single device. RS485 is typically used for multiple devices on a single bus.		
RMCP Command	SIT	Access	Normal user : no access Expert user : RW
SNMP	Table ntcDevsMod01SystemEntry Command ntcDevsMod01SyDevSerIfType OID 1.3.6.1.4.1.5835.3.1.1.1.29.0.1		
Values	Factory Default	Enumeration	Value
	rs485	RS485 RS232	0 1

Command SyDevRs485Addr		Device address for serial interface	Device RMCP address
Location	/Unit/Setup/Serial port settings		
Description	Configuration of the device address for the serial interface. The device address, used in the messages for remote serial management and control, is a single byte with a value in the range 49 (31 hex - ASCII "1") up to 110 (6E hex - ASCII "n"). It identifies the device that has to handle the message from the remote control unit. When the multi-user RS485 bus is used, each device on the bus must have a different address, unique in the system. Address 111 (6F hex - ASCII "o") is the "broadcast" address. This can be used when only one device is connected to a COM-port of a PC to address the device without knowing its exact address.		
RMCP Command	Adr	Access	Normal user : RW Expert user : RW
SNMP	Table ntcDevsMod01SystemEntry Command ntcDevsMod01SyDevRs485Addr OID 1.3.6.1.4.1.5835.3.1.1.1.27.0.1		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	NA	NA	50

/Unit/Setup/Ethernet settings

Command SyDevIPAddr		Device IP address	Device IP address
Location	/Unit/Setup/Ethernet settings		
Description	Configuration of the device IP address.		
RMCP Command	DIP	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyDevIPAddr	
	OID	1.3.6.1.4.1.5835.3.1.1.14.0.1	
Values	Factory Default	String Description	
	10.0.0.1	length : 0 .. 15 format : \d{1,3}\.\d{1,3}\.\d{1,3}\.\d{1,3}	

Command SyDevIPMask		Device IP mask	Device IP mask
Location	/Unit/Setup/Ethernet settings		
Description	Configuration of the device IP netmask.		
RMCP Command	DIM	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyDevIPMask	
	OID	1.3.6.1.4.1.5835.3.1.1.16.0.1	
Values	Factory Default	String Description	
	255.255.255.0	length : 0 .. 15 format : \d{1,3}\.\d{1,3}\.\d{1,3}\.\d{1,3}	

Command SyDevIPGateWay		Default gateway IP address	Default gateway
Location	/Unit/Setup/Ethernet settings		
Description	Configuration of the IP address of the default gateway.		
RMCP Command	DGW	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyDevIPGateWay	
	OID	1.3.6.1.4.1.5835.3.1.1.15.0.1	
Values	Factory Default	String Description	
	0.0.0.0	length : 0 .. 15 format : \d{1,3}\.\d{1,3}\.\d{1,3}\.\d{1,3}	

Command SyEthTransType		Ethernet M&C transport protocol		Transport protocol		
Location	/Unit/Setup/Ethernet settings					
Description	Configuration of the Ethernet interface transport layer. TCP (default) uses acknowledgements to confirm reception of messages while UDP does not. UDP has the advantage of being faster since it does not require the wait for acknowledgement. Furthermore RMCP over Ethernet already has protection on the RMCP layer by means of the CRC. So there is no need for the extra protection provided by the TCP-transport layer.					
RMCP Command	Ett		Access	Normal user : no access Expert user : RW		
SNMP	Table	ntcDevsMod01SystemEntry				
	Command	ntcDevsMod01SyEthTransType				
	OID	1.3.6.1.4.1.5835.3.1.1.1.37.0.1				
Values	Factory Default		Enumeration	Value		
	tcp		TCP UDP	0 1		

Command SyDevMacAddr		Device MAC address	Device MAC address
Location	/Unit/Setup/Ethernet settings		
Description	Readout of the device MAC address.		
RMCP Command	DMA		Access Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyDevMacAddr	
	OID	1.3.6.1.4.1.5835.3.1.1.1.17.0.1	
Values	Factory Default	String Description	
	00:06:39:00:10:5D	length : 17 (fixed) format : ^([\\da-fA-F]{2}:){5}[\\da-fA-F]{2}\$	

/Unit/Setup/Display settings

Command SyDevDispContrast		Display contrast		Display contrast		
Location	/Unit/Setup/Display settings					
Description	Configuration command to adjust the display contrast. Use the +/- keys on the front panel to adjust the display contrast..					
RMCP Command	dpc	Access		Normal user : RW Expert user : RW		
	SNMP	Table	ntcDevsMod01SystemEntry			
		Command	ntcDevsMod01SyDevDispContrast			
Values	OID	1.3.6.1.4.1.5835.3.1.1.10.0.1				
		GUI Unit	Cmd Unit	Factory Default (CU)		
		units	units	50		
				0 .. 100		

Command SyScreenSaveDly		Screensaver delay		Screensaver delay		
Location	/Unit/Setup/Display settings					
Description	Configuration of the screensaver delay. The screensaver delay is the number of minutes of inactivity that is needed before the screensaver is displayed. The screensaver is disabled if this time is set to 0.					
RMCP Command	sSt	Access		Normal user : RW Expert user : RW		
	SNMP	Table	ntcDevsMod01SystemEntry			
		Command	ntcDevsMod01SyScreenSaveDly			
Values	OID	1.3.6.1.4.1.5835.3.1.1.155.0.1				
		GUI Unit	Cmd Unit	Factory Default (CU)		
		min	min	10		
				0 .. 1440		

Command SyScreenSaveMsg		Screensaver message		Screensaver message		
Location	/Unit/Setup/Display settings					
Description	Configuration of the screensaver message. The screensaver message is the text to be displayed when the screensaver is active. Typically a device or channel identification is used (e.g. MOD_1, BBC1, HB_9, CH1,...). The maximum length of this text is 20 characters. When the screensaver is activated the display will show this text together with the last configuration that has been loaded.					
RMCP Command	SSm	Access		Normal user : RW Expert user : RW		
	SNMP	Table	ntcDevsMod01SystemEntry			
		Command	ntcDevsMod01SyScreenSaveMsg			
Values	OID	1.3.6.1.4.1.5835.3.1.1.156.0.1				

Command SyScreenSaveMsg		Screensaver message	Screensaver message
Values	Factory Default	String Description	
	Screensaver	length : 0 .. 20 format : any chars	

/Unit/Setup/SNMP settings

Command SyROCommunity		SNMP read only community	Read community
Location	/Unit/Setup/SNMP settings		
Description	Configuration command for the SNMP community name with read-only access.		
RMCP Command	SRo	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyROCommunity	
	OID	1.3.6.1.4.1.5835.3.1.1.1.70.1.1	
Values	Factory Default	String Description	
	public	length : 0 .. 40 format : any chars	

Command SyRWCommunity		SNMP read-write community	Read-write community
Location	/Unit/Setup/SNMP settings		
Description	Configuration command for the SNMP community name with read-write access.		
RMCP Command	SRw	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyRWCommunity	
	OID	1.3.6.1.4.1.5835.3.1.1.1.71.1.1	
Values	Factory Default	String Description	
	public	length : 0 .. 40 format : any chars	

Command SyTrapIPAddr		SNMP trap IP address	Trap IP address
Location	/Unit/Setup/SNMP settings		
Description	Configuration of the IP address of the host that is allowed to receive SNMP traps.		
RMCP Command	TIP array : [1 .. 2]	Access	Normal user : RW Expert user : RW

Command SyTrapIPAddr		SNMP trap IP address	Trap IP address
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyTrapIPAddr	
	OID	1.3.6.1.4.1.5835.3.1.1.69.0.1.[1 .. 2]	
Values	Factory Default		String Description
	000.000.000.000		length : 0 .. 15 format : \d{1,3}\.\d{1,3}\.\d{1,3}\.\d{1,3}

Command SyTrapCommunity		Trap community	Trap community
Location		/Unit/Setup/SNMP settings	
Description			Configuration of the community name to be able to receive SNMP traps.
RMCP Command	TCO array : [1 .. 2]		Access Normal user : RW Expert user : RW
	Table	ntcDevsMod01SystemExtEntry	
	Command	ntcDevsMod01SyTrapCommunity	
SNMP	OID	1.3.6.1.4.1.5835.3.1.1000.1.5.1.1.[1 .. 2]	
	Factory Default		String Description
	public		length : 0 .. 40 format : any chars

/Unit/Setup/Web Interface



The WI user is not displayed in the tree view of the Graphical user interface (GUI). This function is located in the Function controls window of the GUI under the tab User List.
We refer to the explanation of the GUI in the user manual of this device.

Special Command WIUsers		WI user	WI user	
		FTP is used to put new files on the device. FTP file-transfer to the device is only possible via the credentials (user and logon) from the 4th webinterface user as defined in the device.		
Location			/Unit/Setup/wi	
Description			Configuration command used to define the login and password for web interface (WI) users. By default the login and password is root and root. A total of four web interface users can be defined. The following fields have to be filled in: <ul style="list-style-type: none"> • Web interface user login name: This is the login definition for the user. • Web interface user login access: This is the type of access attributed to that user. • Web interface old password: This is the current password of the user. • Web interface login password: This is the new password the user 	

Special Command WIUsers		WI user	WI user
	has to use. Remark: The following access rights are possible: <ul style="list-style-type: none"> • Minimum or read-only access. • Operator or limited access. • Administrator or full access. 		
RMCp Command	Wlu array : [1 .. 4]	Access	Normal user : no access Expert user : W
SNMP	Table	ntcDevsMod01SystemExtEntry	
	Command	ntcDevsMod01WIUsers	
	OID	1.3.6.1.4.1.5835.3.1.1000.1.6.1.1.[1 .. 4]	
Get Command Arguments		Set Command Arguments	
Command(s) / Variable(s)		Page	Command(s) / Variable(s) Page
NA		NA	WILogInUser WILogInUserAccess WILogInOldPass WILogInPass
Get Reply Values		Set Reply Values	
Command(s) / Variable(s)		Page	Command(s) / Variable(s) Page
NA		NA	WILogInReply

/Unit/Control

Command SyDevSleepMode		Device sleep mode	Device sleep mode
	This command is only available using the front panel.		
Location	/Unit/Control		
Description	Configuration of the device sleep mode. The sleep mode control allows the user to power-down the device without actually removing the power or using a power switch. <ul style="list-style-type: none"> • Operational: The device is fully operational and responds to input from keyboard and RCMP commands. • Sleep mode: The device is put in a low power-consumption (power down) state and ignores all monitoring and control from RCMP. It can be awakened by pressing a front panel key after which it will perform a boot-cycle. 		
RMCp Command	DSM	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyDevSleepMode	
	OID	1.3.6.1.4.1.5835.3.1.1.30.0.1	
Values	Factory Default	Enumeration	Value
	operational	Operational Sleep	0 1



The device reset is not displayed in the tree view of the Graphical user interface (GUI). This function is located in the Function controls window of the GUI under the tab Reset Device. We refer to the explanation of the GUI in the user manual of this device.

Command SyDevRst		Device reset	Device reset
Location	/Unit/Control		
Description	<p>Command to initiate a device reset.</p> <ul style="list-style-type: none"> A soft reset will send the reset command to all boards. A config reset will clear all operational control settings and place them back on default value. A hard reset will power-cycle the device. After a reset, the device initially starts up the boot loader code, waits for 2 seconds and then activates the application code. Consequently, the unit performs a number of initialisation routines, loads its default configuration from permanent memory and performs a self test. The selection upgrade is used whenever an upgrade through bucket-files is performed; refer to the appendices for details on the upgrade procedure. A factory reset clears all device settings (including Ethernet settings) and place them back on default value. You can only reach this reset option from the device front panel. The selection reset upgrade logs is used to delete a bucket upgrade log. When an upgrade fails, the failure will be written in the upgrade_log.html report which will be used by the unit to generate a general device alarm. When this happens the unit should be upgraded again to reset this flag, although it could be desired to reset this flag without doing any upgrade. Therefore this selection will only clear the upgrade_log.html file. 		
RMCP Command	SRr	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyDevRst	
	OID	1.3.6.1.4.1.5835.3.1.1.1.28.0.1	
Values	Factory Default	Enumeration	Value
	none	None Soft Configs Hard Upgrade Factory Upgrade logs	0 1 2 4 6 7 8

Command SyDevGenerate		Generate selected output file	Generate output file
Location	/Unit/Control		
Description	 <p>With this command certain output files can be generated by selecting the required output type. The generated output file can be retrieved from the \FTP\out directory. In case of errors, the error output log can be found in the \FTP\log directory. The generated files have by default the unit name as file name. The file name can be changed, but it is not allowed to change the extension!</p> <p>The following selections are available:</p> <ul style="list-style-type: none"> • Unit configuration file with extension cfg: This file stores all global settings and all the user configurations. The file can be used for archiving configuration, but it can also be uploaded to another device by using the command SyDevActivate. The source unit (creation of the configuration file) and the destination unit (activation of the configuration file) do not explicitly need the same software version. The settings not known by the destination unit will be deleted and new settings not known by the source unit will derive the factory default. Some differences in the configuration (capability differences) between source and destination unit can result in deleting the complete user configuration. • Linear pre-distortion file with extension lp: All data relevant for linear pre-distortion will be stored in one output file. • Non-linear pre-distortion file with extension nlp: All data relevant for non-linear pre-distortion will be stored in one output file. 		
RMC Command	GOf	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyDevGenerate	
	OID	1.3.6.1.4.1.5835.3.1.1.1.83.1.1	
Values	Factory Default	Enumeration	Value
	none	None Unit Configuration Linear Predistortion Non Linear Predistortion	0 1 2 3

Command SyDevActivate		Activate system file	Activate system file
Location	/Unit/Control		
Description	 <p>Configuration command to process the selected output file. With this command, all files found in the input directory (\FTP\In) will be processed if the enumeration All is selected. The file name can be anything; only the extension of the file will be used to identify the type of action. In case of errors, the error output log can be found in the \FTP\log directory.</p> <p>The following types of input files are available:</p> <ul style="list-style-type: none"> • Unit configuration file with extension cfg. • Linear pre-distortion file with extension lp. • Non-linear pre-distortion file with extension nlp. • RMC command file (such as used for RMC loader). Remark: RMC is the default behaviour if former extensions are not found. 		
RMC Command	Alf	Access	Normal user : no access Expert user : RW

Command SyDevActivate		Activate system file	Activate system file
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyDevActivate	
	OID	1.3.6.1.4.1.5835.3.1.1.1.82.1.1	
Values	Factory Default	Enumeration	Value
	none	None All	0 1

Command SyIntAlarmMaskMode		Interface alarm masking mode	Interface alarm mask
Location	/Unit/Control		
Description	Configuration of the interface alarm masking mode. When the unit is controlled via a universal switching system, the interface alarm relais contact is used to determine the switch over. The interface alarm is a group of alarms, thus each of these alarms can trigger the universal switching system switch over. Due to the hardware set-up, it could be desired to change the behaviour of the interface alarm relais contact by masking some of the alarms. With this command some alarms in the interface alarm group could be masked.		
RMCP Command	IAm		Access
	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyIntAlarmMaskMode	
SNMP	OID	1.3.6.1.4.1.5835.3.1.1.1.94.1.1	
	Values	Factory Default	Enumeration
		off	Off Mod Input Demod Lock Demod Lock + Mod Input
			0 1 2 3

Command SyInputAIEscallation		Input alarm escalation	Input alarm escallat
Location	/Unit/Control		
Description	This field is used to select if the input alarm needs to be escalated to an interface alarm or not. An interface alarm can thus be used as a trigger for redundancy switchover.		
RMCP Command	iae		Access
	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyInputAIEscallation	
SNMP	OID	1.3.6.1.4.1.5835.3.1.1.1.108.1.1	

Command SyInputAI Escallation		Input alarm escallation	Input alarm escallat
Values	Factory Default	Enumeration	Value
	off	Off Interface alarm	0 1

Command SyRefClock		Reference clock selection	Reference clock sel.
Location	/Unit/Control		
	Only applicable for modems equipped with a 10 MHz Reference Board.		
Description	Configuration of the reference clock selection. The 10 MHz reference clock can be either internally generated (default) or taken from an external source for enhanced stability and/or synchronisation.		
RMCP Command	RCS		Access Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyRefClock	
	OID	1.3.6.1.4.1.5835.3.1.1.1.46.0.1	
Values	Factory Default	Enumeration	Value
	internal	Internal External	0 1

Command SyRef10MTuning		10 MHz operator frequency adjust	10 MHz oper. adjust
Location	/Unit/Control		
	Only applicable for modems equipped with a 10 MHz Reference Board.		
Description	Configuration command to adjust the 10 MHz frequency. The internal 10MHz operator adjustment value controls the frequency of the internal 10 MHz reference oscillator and can be used, by the operator, to re-calibrate the internal 10 MHz. If this calibration value needs to be used, SyRef10MCtrl must be set to by operator . Otherwise when set to by factory , the default tuning value of the in-factory calibration will be used. The tuning range is normalized to a range from -50 to +50. Remark: The actual range (ppm or Hz) depends on the type of oscillator used.		
RMCP Command	RFt	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyRef10MTuning	
	OID	1.3.6.1.4.1.5835.3.1.1.1.45.0.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU) Expert Range (CU)

Command SyRef10MTuning		10 MHz operator frequency adjust		10 MHz oper. adjust	
	units	units	0	-50 .. 50	

Command SyRef10MCalib		10 MHz ref. factory default		10 MHz factory defau					
Location	/Unit/Control								
	Only applicable for modems equipped with a 10 MHz Reference Board.								
Description	<p>Readout of the internal 10MHz reference frequency calibration factory default. This is the factory-calibrated tuning value for the internal 10 MHz reference oscillator. This value is determined during factory calibration and is hard-coded into the reference board. It can not be changed by the operator.</p> <p>This value will be used when SyRef10MCtrl is set to by factory. Otherwise when set to by operator, the value entered in SyRef10MTuning will be used to adjust the 10 MHz internal reference frequency.</p>								
RMC Command	RFC	Access		Normal user : no access Expert user : R					
SNMP	Table	ntcDevsMod01SystemEntry							
	Command	ntcDevsMod01SyRef10MCalib							
	OID	1.3.6.1.4.1.5835.3.1.1.1.42.0.1							
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)					
	units	units	0	-50 .. 50					

Command SyRef10MCtrl		10 MHz reference calibration control		10 MHz cal. control					
Location	/Unit/Control								
	Only applicable for modems equipped with a 10 MHz Reference Board.								
Description	Configuration of the internal 10MHz reference calibration control. The internal 10MHz reference frequency can be controlled by either the factory-calibrated value or the operator-controlled tuning value.								
RMC Command	RFC		Access	Normal user : no access Expert user : RW					
SNMP	Table	ntcDevsMod01SystemEntry							
	Command	ntcDevsMod01SyRef10MCtrl							
	OID	1.3.6.1.4.1.5835.3.1.1.1.43.0.1							
Values	Factory Default		Enumeration	Value					
	factory		By factory By operator	0 1					

Command CvLNBPow		LNB power supply	LNB power supply
Location	/Unit/Control		
Description	<p>Configuration of the power supply of an external LNB. If the power supply is turned on, +13 or +18 volt DC and/or 22 kHz tone can be provided on the input connector. Use the command ODCtrl to control the actual voltage and tone.</p> <p>Remark: If the power is enabled, devices that do not tolerate a DC-voltage at their input can be damaged (e.g. non-Newtec outdoor units, spectrum analysers). The use of a blocking capacitor is mandatory in this case.</p>		
RMCP Command	XVp array : [1 .. 2]	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ConverterExtEntry	
	Command	ntcDevsMod01CvLNBPow	
	OID	1.3.6.1.4.1.5835.3.1.7000.1.5.1.1.[1 .. 2]	
Values	Factory Default	Enumeration	Value
	disabled	Disabled Enabled	0 1

Command MoOLevelOffset		Level offset	Level offset	
Location	/Unit/Control			
Description	<p>Configuration of the modulator level offset. The level offset can be used to enter a gain or attenuation in the transmit path (cables, splitters, combiners, high power amplifier). This will give the operator the opportunity to set a level on the modulator that will correspond to a level at a certain point in the transmit chain. The factory default level is the attenuation of the cable between the output of the modulator board or installed converter and the connector on the chassis.</p> <p>Typical applications would be to take into account losses of cross-site cabling and/or the gain of the high power amplifier and antenna. The level offset can also be used to realign (calibrate) the modulator output level.</p> <p>Remark: This parameter makes it easier for the operator to readout the correct transmitted RF-power. However, this parameter has no effect on the transmitted output power!</p>			
RMCP Command	OLo	Access	Normal user : RW Expert user : RW	
SNMP	Table	ntcDevsMod01ModulatorEntry		
	Command	ntcDevsMod01MoOLevelOffset		
	OID	1.3.6.1.4.1.5835.3.1.3.1.42.1.1		
Values	GUI Unit	Cmd Unit	Factory Default (CU) Expert Range (CU)	
	dB	dB	0 -999.9 .. 999.9	

Command ExtLOFreq		Ext LO Freq. out	Ext LO Freq. out
Location	/Unit/Control		
Description	Configuration of the local oscillator frequency for a non-Newtec external up- or down-converter. This allows the operator to enter the RF frequency directly without having to re-calculate the frequency to L-band or IF. Use the external spectral inversion menu to indicate if local oscillator frequency is above or below the RF frequency.		
RMCP Command	LOF	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01ExtLOFreq	
	OID	1.3.6.1.4.1.5835.3.1.3.1.26.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	MHz	Hz	12450
Expert Range (CU)		0 .. 990000000000	

Command DmExtLOFreq		LO IFL in	LO IFL in
Location	/Unit/Control		
Description	Configuration of the local oscillator frequency of a converter in case a non-Newtec external up- or down-converter is used. This allows the operator to enter the radio frequency directly without having to recalculate the frequency to L-band or IF-band. Use the external spectral inversion menu to indicate if the local oscillator frequency is above or below the radio frequency.		
RMCP Command	LOf array : [1 .. 2]	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmExtLOFreq	
	OID	1.3.6.1.4.1.5835.3.1.13.1.43.1.1.[1 .. 2]	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	MHz	Hz	12450
Expert Range (CU)		0 .. 990000000000	

Command DmExtLOPolVal		Spectrum inv. IFL in	Spect. inv. IFL i
Location	/Unit/Control		
Description	Configuration of the external converter spectrum polarity: <ul style="list-style-type: none"> When the spectrum is direct, the formula is: $f(RF) = f(LO) + f(L\text{-band})$. When the spectrum is inverted, the formula is: $f(RF) = f(LO) - f(L\text{-band})$. Remark: Use inverted spectrum whenever the local oscillator frequency is above the radio frequency. 		
RMCP Command	LOp array : [1 .. 2]	Access	Normal user : no access Expert user : RW

Command DmExtLOPolVal		Spectrum inv. IFL in	Spect. inv. IFL i
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmExtLOPolVal	
	OID	1.3.6.1.4.1.5835.3.1.13.1.44.1.1.[1 .. 2]	
Values	Factory Default	Enumeration	Value
	directSpectrum	Direct spectrum Inverted spectrum	1 2

Command ExtLOPolVal		Ext. spectrum inv.	Ext. spectrum inv.
Location	/Unit/Control		
Description	Configuration of the external converter spectrum polarity: <ul style="list-style-type: none"> When the spectrum is direct, the formula is: $f(RF) = f(LO) + f(L-band)$. When the spectrum is inverted, the formula is: $f(RF) = f(LO) - f(L-band)$. Remark: Use inverted spectrum whenever the local oscillator frequency is above the radio frequency. 		
RMCP Command	LOS		Access Normal user : no access Expert user : RW
	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01ExtLOPolVal	
Values	Factory Default	Enumeration	Value
	directSpectrum	Direct spectrum Inverted spectrum	1 2

/Unit/Control/ODU

Command ODPow		Outdoor power supply	Outdoor power supply
Location	/Unit/Control/ODU		
Description	Configuration command to enable or disable the outdoor power supply as delivered by the outdoor unity and LNB controller unit.		
RMCP Command	ODp		Access Normal user : no access Expert user : RW
	Table	ntcDevsMod01ODUEntry	
	Command	ntcDevsMod01ODPPow	
Values	Factory Default	Enumeration	Value
	disabled	Disabled Enabled	0 1

Command ODCurLimits		Outdoor current limit	Outdoor cur. limit %
Location	/Unit/Control		
Description	Configuration of the current limitation for the outdoor unit. If the current to the outdoor unit exceeds the limitation an alarm is generated.		
RMC Command	Ocl array : [1 .. 2]	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ODUExtEntry	
	Command	ntcDevsMod01ODCurLimits	
	OID	1.3.6.1.4.1.5835.3.1.14000.1.5.1.1.[1 .. 2]	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	mA	mA	0
		Expert Range (CU)	0 .. 4000

Command MoODU100		ODU 100 MHz reference	ODU 100 MHz referenc
Location	/Unit/Control		
Description	Configuration command to control the 100 MHz outdoor unit reference signal when an outdoor unit conditioning module is used. This 100 MHz reference signal is needed whenever a Newtec outdoor unit is used and is used as a reference for the local oscillator of the up-converter.		
RMC Command	XOm	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01ODUEntry	
	Command	ntcDevsMod01MoODU100	
	OID	1.3.6.1.4.1.5835.3.1.14.1.12.1.1	
Values	Factory Default	Enumeration	Value
	disabled	Disabled Enabled	0 1

/Unit/Control/AES

Command AESGroupKey		Group Key	Group Key
Location	/Unit/Control/AES		
Description	This key is used for AES decryption of encrypted keys entered by the user. The length of the key can be 64bits or 128bits long depending on AES key length The value is entered as a hexadecimal value: <ul style="list-style-type: none">• 64 bits - 8 bytes (16 text bytes)• 128 bits - 16 bytes (32 text bytes)		
RMC Command	AGk	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01SystemEntry	

Command AESGroupKey		Group Key	Group Key
	Command	ntcDevsMod01AESGroupKey	
	OID	1.3.6.1.4.1.5835.3.1.1.1.122.1.1	
Values	Factory Default		String Description
	FFFFFFFFFFFFFFFF FFFFFFFFFFFFFFFF FFFF		length : 0 .. 32 format : Hexadecimal chars

Command AESKeyLength		Key Length	Key Length
Location	/Unit/Control/AES		
Description	This variable describes the length of the AES encryption keys. <ul style="list-style-type: none"> • 64 : 64bit key length - (0) • 128 : 128bit key length - (1) 		
RMCP Command	AKI		Access Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01AESKeyLength	
	OID	1.3.6.1.4.1.5835.3.1.1.1.123.1.1	
Values	Factory Default	Enumeration	Value
	64	64 128	0 1

Command AEEraseAllKey		Erase All Keys	Erase All Keys
Location	/Unit/Control/AES		
Description	This variable erases all encryption keys to there default value. The value is autmatically reset after operation is completed. <ul style="list-style-type: none"> • No : Do not Erase All AES Keys • erase : Erase All AES Keys 		
RMCP Command	AAE		Access Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01AEEraseAllKey	
	OID	1.3.6.1.4.1.5835.3.1.1.1.121.1.1	
Values	Factory Default	Enumeration	Value
	no	No Erase	0 1

/Unit/Monitor

Command SyIntTemp		Device internal temperature		Device temperature					
Location	/Unit/Monitor								
Description	Readout of the internal temperature of the device. The internal temperature must be within +10 and +70° C. Typically, this temperature should be around 40°C ($\pm 10^{\circ}\text{C}$).								
RMCP Command	Sst	Access			Normal user : R Expert user : R				
SNMP	Table	ntcDevsMod01SystemEntry							
	Command	ntcDevsMod01SyIntTemp							
	OID	1.3.6.1.4.1.5835.3.1.1.1.39.0.1							
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)					
	C	C	40	0 .. 100					

Command SyDevPowP3V3		Device +3V3 power supply		+3V3 power supply					
Location	/Unit/Monitor								
Description	Readout of the +3.3 volt power supply monitor. A power supply alarm is triggered when this voltage is outside the range of +2.5 volt and +4.1 volt.								
RMCP Command	P33	Access			Normal user : R Expert user : R				
SNMP	Table	ntcDevsMod01SystemEntry							
	Command	ntcDevsMod01SyDevPowP3V3							
	OID	1.3.6.1.4.1.5835.3.1.1.1.23.0.1							
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)					
	V	V	3.3	0 .. 10					

Command SyDevPowP5V		Device +5V power supply		+5V power supply					
Location	/Unit/Monitor								
Description	Readout of the +5 volt power supply monitor. A power supply alarm is triggered when this voltage is outside the range of +4.0 volt and +5.9 volt.								
RMCP Command	P50	Access			Normal user : R Expert user : R				
SNMP	Table	ntcDevsMod01SystemEntry							
	Command	ntcDevsMod01SyDevPowP5V							
	OID	1.3.6.1.4.1.5835.3.1.1.1.24.0.1							
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)					
	V	V	5	0 .. 10					

Command SyDevPowP12V		Device +12V power supply	+12V power supply
Location	/Unit/Monitor		
Description	Readout of the +12volt power supply monitor. A power supply alarm is triggered when this voltage is outside the range of +10.0 volt and +14.0 volt.		
RMCP Command	P12	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyDevPowP12V	
	OID	1.3.6.1.4.1.5835.3.1.1.22.0.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	V	V	12
		Expert Range (CU)	0 .. 50

Command SyDevPowM12V		Device -12V power supply	-12V power supply
Location	/Unit/Monitor		
Description	Readout of the -12 volt power supply monitor. A power supply alarm is triggered when this voltage is outside the range of -10.0 volt and -14.0 volt.		
RMCP Command	M12	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyDevPowM12V	
	OID	1.3.6.1.4.1.5835.3.1.1.21.0.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	V	V	-12
		Expert Range (CU)	-50 .. 0

Command SyRef10MLevel		10 MHz reference input level measurement	10 MHz input level
Location	/Unit/Monitor		
	Only applicable for modems equipped with a 10 MHz Reference Board.		
Description	Readout of the 10 MHz reference input level estimation as derived from the monitored AGC level. For optimal operation (conform to the specifications), the level should be within the range of 2.4 and 3.7 volt. A level lower than 1 volt (lower than - 5 dBm) will trigger the reference clock alarm. Following table shows the measured voltage and the corresponding level in dBm: a. 2.4 ± 0.5 volt => - 3 dBm. b. 3.0 ± 0.5 volt => - 0 dBm. c. 3.4 ± 0.5 volt => + 3 dBm. d. 3.7 ± 0.5 volt => + 7 dBm. e. 4.0 ± 0.5 volt => +10 dBm.		
RMCP Command	ril	Access	Normal user : no access

Command SyRef10MLevel		10 MHz reference input level measurement	10 MHz input level
			Expert user : R
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyRef10MLevel	
	OID	1.3.6.1.4.1.5835.3.1.1.144.0.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	mV	V	2950
		Expert Range (CU)	
		5000 .. 0	

Command SyRFCalcForm		Modulation RF frequency formula	Mod RF freq. formula
Location	/Unit/Monitor		
Description	Readout of the frequency conversion formula. This parameter shows the operator how to calculate the different frequencies in the system.		
RMCP Command	FFc	Access	Normal user : no access Expert user : R
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyRFCalcForm	
	OID	1.3.6.1.4.1.5835.3.1.1.157.1.1	
Values	Factory Default	String Description	
	RF Freq = LO freq [+-] L-band freq	length : 0 .. 40 format : any chars	

/Unit/Architecture

Retrieving Architectural Information

The architecture parameters are a special case in commands. In this section you can find all the commands to retrieve architecture information from the device. First, there is the architecture information on device level. They can be retrieved via the menu tree:EL470 >> Unit >> Architecture >> General. On device level, the SNMP commands can be used, or RCMP using the command and the address 111.

There is also the architecture information on board level within the device. **WARNING:** SNMP can not be used to retrieve architecture information on board level. The RCMP commands that are used to retrieve board level information are the same as the commands used on device level. On board level, the used addresses used is 100, and the subaddress depends on the board: These are the subaddresses for the several boards:

- M&C module: 48 (in RMCPLoader -1:1:0 is used)
- Interface: 100 (in RMCPLoader -1:1:d is used)
- Modulation: 116 (in RMCPLoader -1:1:t) is used

The applicability of the commands are shown in following table:

Unit/Architecture/general

Nr	Command Name	Page
1	Device Serial Number	37
2	Device Type	41
3	Product Number	42
4	Bucket version	37
5	OS version	38
6	RAM Disk version	38
7	PPC boot version	38
8	SNMP Daemon version	39

Unit/Architecture/Common/M&C module

Nr	Command Name	Page
1	Device Serial Number	37
2	Device type	41
3	HW ID	36
4	HW version	39
5	HW capability	39
6	SW ID	40
7	SW version	40
8	Device capability	41
9	Product ID	37

Unit/Architecture/Modem/Interfaces

Nr	Command Name	Page
1	Device Serial Number	37
2	Device type	41
3	HW ID	36
4	HW version	39
5	HW capability	39
5	SW ID	40
6	SW version	40
7	Device capability	41
8	Product Id	37

Unit/Architecture/Modem/Modulation

Nr	Command Name	Page
1	Device Serial Number	37
2	Device Type	41
3	HW ID	36
4	HW version	39
4	HW capability	39
5	SW ID	40
6	SW version	40

Nr	Command Name	Page
7	Device capability	41
8	Product Id	37

Unit/Architecture/Modem/Demodulation

Nr	Command Name	Page
1	Device Serial Number	37
2	Device Type	41
3	HW ID	36
4	HW version	39
4	HW capability	39
5	SW ID	40
6	SW version	40
7	Device capability	41
8	Product Id	37

Architecture Commands

Command SyDevHwId1		Device hardware identification		Hardware Id		
Location	/Unit/Architecture					
Description	Readout of the device hardware identification. The hardware identification displays the device type, the sub-type (alphanumeric suffix) together with a short description identifying the hardware.					
RMCP Command	Hld		Access	Normal user : R Expert user : R		
SNMP	Table	ntcDevsMod01SystemEntry				
	Command	ntcDevsMod01SyDevHwId				
	OID	1.3.6.1.4.1.5835.3.1.1.1.12.0.1				
Values	Factory Default		String Description			
	NA		length : 0 .. 40 format : any chars			

Command SyDevProdId1		Product identification number	Product Id
Location	/Unit/Architecture		
Description	Readout of the product identification number. The product identification displays the device type, the sub-type (alphanumeric suffix) together with a short description identifying the product.		
RMCP Command	PId	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyDevProdId	
	OID	1.3.6.1.4.1.5835.3.1.1.25.0.1	
Values	Factory Default	String Description	
	NA	length : 0 .. 40 format : any chars	

Command SyDevSn11		Device serial number	Device serial number
Location	/Unit/Architecture		
Description	Readout of the device serial number. Each device has a label at the side panel that contains the serial number. This number is the same as the serial number on the label.		
RMCP Command	SLs	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyDevSn	
	OID	1.3.6.1.4.1.5835.3.1.1.31.0.1	
Values	Factory Default	String Description	
	03051439	length : 8 (fixed) format : Hexadecimal chars	

Command SyBucketVersion1		Bucket version	Bucket version
Location	/Unit/Architecture		
Description	Readout of the bucket version. A bucket, used for upgrades, is a subset of firmwares. The bucket version is a unique value which represents the group of firmware versions which are present in the bucket. The bucket version gives a correct idea about the installed firmware versions of all the boards which can be upgraded by the bucket upgrade tool. Each time a new upgrade is done, the bucket version will be updated to identify the new upgrade.		
RMCP Command	Buv	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyBucketVersion	
	OID	1.3.6.1.4.1.5835.3.1.1.87.1.1	

Command SyBucketVersion1		Bucket version	Bucket version
Values	Factory Default	String Description	
	Vx.xx	length : 0 .. 20 format : any chars	

Command SyOSVer1		Operating system version	OS version
Location	/Unit/Architecture		
Description	Readout of the operating system version and release date.		
RMCP Command	Ove		Access
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyOSVer	
	OID	1.3.6.1.4.1.5835.3.1.1.1.63.0.1	
Values	Factory Default	String Description	
	NA	length : 0 .. 25 format : any chars	

Command SyRamDiskVer1		RAM disk version	RAM disk version
Location	/Unit/Architecture		
Description	Readout of the RAM disk version and release date.		
RMCP Command	RDv		Access
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyRamDiskVer	
	OID	1.3.6.1.4.1.5835.3.1.1.1.64.0.1	
Values	Factory Default	String Description	
	NA	length : 0 .. 25 format : any chars	

Command SyPPCVer1		PPC boot version	PPC boot version
Location	/Unit/Architecture		
Description	Readout of the PPC boot version and release date.		
RMCP Command	Pve		Access
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyPPCVer	
	OID	1.3.6.1.4.1.5835.3.1.1.1.67.0.1	
Values	Factory Default	String Description	
	NA	length : 0 .. 25	

Command	PPC boot version	PPC boot version
SyPPCVer1		format : any chars

Command	SNMP daemon version	SNMP daemon version
SySnmpVer1		
Location	/Unit/Architecture	
Description	Readout of the SNMP daemon version and release date.	
RMCP Command	SDv	Access Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01SystemEntry
	Command	ntcDevsMod01SySnmpVer
	OID	1.3.6.1.4.1.5835.3.1.1.1.68.0.1
Values	Factory Default	String Description
	NA	length : 0 .. 25 format : any chars

Command	Device hardware version	Hardware version
SyDevHwVer1		
Location	/Unit/Architecture	
Description	Readout of the device hardware version.	
RMCP Command	Hve	Access Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01SystemEntry
	Command	ntcDevsMod01SyDevHwVer
	OID	1.3.6.1.4.1.5835.3.1.1.1.13.0.1
Values	Factory Default	String Description
	<press OK>	length : 0 .. 5 format : any chars

Command	Device hardware capability	Hardware capability
SyDevHwCapab1		
Location	/Unit/Architecture	
Description	Readout of the hardware configuration of the device. It can only be changed by installing or removing hardware modules. Capability = 0 corresponds to full device definition. Capability = 255 corresponds to an illegal capability ("blocked" mode).	
RMCP Command	HWC	Access Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01SystemEntry
	Command	ntcDevsMod01SyDevHwCapab
	OID	1.3.6.1.4.1.5835.3.1.1.11.0.1
Values	GUI Unit	Cmd Unit
		Factory Default (CU)
		Expert Range (CU)

Command SyDevHwCapab1		Device hardware capability		Hardware capability	
	NA	NA	Device specific	0 .. 255	

Command SyDevSwCapab		Device software capability		Software capability			
Location	/Unit/Architecture						
Used as variable of	Command(s)				Page		
	SyDevCapab				41		
Description	Readout of the active device software capability number to indicate software variants of the device. In order to increase device functionality (= changing software capability), a device-specific software key can be obtained from Newtec.						
RMCP Command	SWC	Access			Normal user : R Expert user : R		
SNMP	Table	ntcDevsMod01SystemEntry					
	Command	ntcDevsMod01SyDevSwCapab					
	OID	1.3.6.1.4.1.5835.3.1.1.32.0.1					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)			
	NA	NA	<press OK>	0 .. 255			

Command SyDevSwId1		Device software identification		Software Id			
Location	/Unit/Architecture						
Description	Readout of the device software identification. This identification contains the device type and a short description.						
RMCP Command	SId			Access	Normal user : R Expert user : R		
SNMP	Table	ntcDevsMod01SystemEntry					
	Command	ntcDevsMod01SyDevSwId					
	OID	1.3.6.1.4.1.5835.3.1.1.33.0.1					
Values	Factory Default		String Description				
	<press OK>		length : 0 .. 22 format : any chars				

Command SyDevSwVer11		Device software version		Software version			
Location	/Unit/Architecture						
Description	Readout of the device software version and release date.						
RMCP Command	Sve			Access	Normal user : R Expert user : R		
SNMP	Table	ntcDevsMod01SystemEntry					
	Command	ntcDevsMod01SyDevSwVer					

Command SyDevSwVer11		Device software version	Software version
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.1.1.34.0.1	
Values	Factory Default	String Description	
	<press OK>	length : 0 .. 40 format : any chars	

Special Command SyDevCapab1		Device capability	Device capability
Location	/Unit/Architecture		
Description	Configuration command for the device software capability. A get request returns the software capabilities that are enabled on the device. A set command requires a software license key specific to the device.		
RMC Command	SDC array : [1 .. 6]	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyDevCapab	
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.1.1.8.0.1.[1 .. 6]	
Get Command Arguments		Set Command Arguments	
Command(s) / Variable(s)		Page	Command(s) / Variable(s) Page
none		none	SyDevCapPass 229
Get Reply Values		Set Reply Values	
Command(s) / Variable(s)		Page	Command(s) / Variable(s) Page
SyDevSwCapab		40	SyDevCapReply 229 SyDevSwCapab 40

Command SyDevType111		Device type	Device type
Location	/Unit/Architecture		
Description	Readout of the type of device. Currently two types are identified: <ul style="list-style-type: none">• NTC: Newtec device.• OEM: Original equipment manufacturer device.		
RMC Command	SDT	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyDevType	
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.1.1.80.1.1	
Values	Factory Default	Enumeration	Value
	ntc	Ntc Oem	0 1

Command SyDevProdNbr11		Product number	Product number
Location	/Unit/Architecture		
Description	Readout of the product number of the device.		
RMCP Command	PNr	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyDevProdNbr	
	OID	1.3.6.1.4.1.5835.3.1.1.1.88.1.1	
Values	Factory Default	String Description	
	<press OK>	length : 0 .. 20 format : any chars	

Command SyDevIPCoreSwId		IPCore software identification	IPCore Sw Id
Location	/Unit/Architecture		
Description	Readout of the identification of software running on an IP Core component in an FPGA (e.g. extra micro-processor core).		
RMCP Command	Ild	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyDevIPCoreSwId	
	OID	1.3.6.1.4.1.5835.3.1.1.1.76.1.1	
Values	Factory Default	String Description	
		length : 0 .. 40 format : any chars	

Command SyDevIPCoreSwVer111		IP Core software version	IP Core Sw Ver.
Location	/Unit/Architecture		
Description	Readout of the version of the software running on an IP Core component in a FPGA (e.g. extra micro-processor).		
RMCP Command	Ive	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyDevIPCoreSwVer	
	OID	1.3.6.1.4.1.5835.3.1.1.1.77.1.1	
Values	Factory Default	String Description	
	v00.00	length : 0 .. 12 format : any chars	

Unit/Diagnostics



Diagnostics is not displayed in the tree view of the Graphical user interface (GUI). This function is located in the Function controls window of the GUI under the tab Reset Device.
We refer to the explanation of the GUI in the user manual of this device.

Command SyTSRappor	Generate diagnostics report	Diagnostics report			
Location	/Unit/Diagnostics				
Description	<p>Command to generate a diagnostics report. This command is also triggered when a diagnostics report is requested through the web interface.</p> <p>There are two possible reports:</p> <ul style="list-style-type: none"> A basic diagnostics report: To be used by customers to request all configuration settings and alarms. A full diagnostics report: To be used by Newtec engineering as a debugging tool to investigate specific problems detected by the basic diagnostics report. 				
RMC Command	GTS	Access	Normal user : no access Expert user : W		
SNMP	Table	ntcDevsMod01SystemEntry			
	Command	ntcDevsMod01SyTSRappor			
	OID	1.3.6.1.4.1.5835.3.1.1.1.65.1.1			
Values	Factory Default	Enumeration	Value		
	basic	Basic Full	0 1		

Special Command AISeftTestBrd	Board selftest result	Board selftest resul	
Location	/Unit/Diagnostics		
Description	Readout of the the concatenated string of the board self test results.		
RMC Command	DSt array : [1 .. 16]	Access	Normal user : no access Expert user : RW
Get Command Arguments		Set Command Arguments	
Command(s) / Variable(s)	Page	Command(s) / Variable(s)	Page
none	none	none	none
Get Reply Values		Set Reply Values	
Command(s) / Variable(s)	Page	Command(s) / Variable(s)	Page
AISeftTestString	193	AISeftTestString	193

5 MODEM

/Modem/Control

/Modem/Control/Common

Command MdModStand		Modulation standard	Modulation standard
Location	/Modem/Control/Common		
Description	Configuration of the modulation standard that defines the major operating mode of the device. <ul style="list-style-type: none"> • DVB-S2: Compatible with EN302307. • DVB-S: Compatible with EN300421 for QPSK and EN301210 for 8PSK and 16QAM. 		
RMCP Command	DDc	Access	Normal user : RW Expert user : RW
	Table	ntcDevsMod01ModemEntry	
	Command	ntcDevsMod01MdModStand	
Values	Factory Default	Enumeration	Value
	modDVB	DVB-S DVB-S2	3 5

Command MdProcMode		Processing mode	Processing mode
Location	/Modem/Control/Common		
Description	Configuration of the processing mode: Configuration of the Ethernet interface (IP-data) for modulator, demodulator or modem. It offers an Ethernet interface for a modulator, demodulator or modem to transmit or receive IP packets (or Ethernet frames) over satellite. The different options are: <ul style="list-style-type: none"> • Eth(IP) <-> Air(TS), applicable for DVB-S and DVB-S2: dataflow from an ethernet input to the modulator board. Ethernet input is encapsulated in TS packets, then put in Baseband Frames and forwarded towards the modulator board and received from the demodulator board. • Eth(IP) <-> Air(XPE), applicable for DVB-S2.2. dataflow from an ethernet input to the modulator board. DVB-S2 Baseband Frames are generated towards the modulator board and received from the demodulator board. • Eth(IP) ↔ Air(GSE) applicable for DVB-S2. IP data is encapsulated in GSE and carried directly in DVB-S2 Base Band Frames. GSE encapsulation/decapsulation is performed in the modulator/demodulator. 		

Command MdProcMode		Processing mode		Processing mode
		<ul style="list-style-type: none"> Eth(ntS2BBF) -> Air(S2BBF), applicable for DVB-S2. Transparent DVB-S2 Baseband frames received from a Newtec encapsulator forwarded from an Ethernet input to the modulator board and from demodulator back to Ethernet output. 		
RMCP Command	DPM	Access		Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01ModemEntry		
	Command	ntcDevsMod01MdProcMode		
	OID	1.3.6.1.4.1.5835.3.1.18.1.7.1.1		
Values	Factory Default		Enumeration	
	tsmode		Eth(IP)<->Air(TS) Eth(IP)<->Air(XPE) Eth(TSoIP)<->Air(TS) Eth(S2BBF)<->Air(S2BBF) Eth(ntS2BBF)->Air(S2BBF)	
				0 1 4 8 10

/Modem/Control/Interfaces

/Modem/Control/Interfaces/Ethernet

Command IfEthMtu		Ethernet MTU		Ethernet MTU		
Location	/Modem/Control/Interfaces/Ethernet					
Description	Configuration of the Ethernet payload size. This number defines the maximum Ethernet payload size which is usually 1500 bytes. It does not include the Ethernet header, the Ethernet frame check sequence (=CRC32) or the VLAN extension of 4 bytes.					
RMCP Command	mtu	Access		Normal user : no access Expert user : RW		
SNMP	Table	ntcDevsMod01InterfaceEntry				
	Command	ntcDevsMod01IfEthMtu				
	OID	1.3.6.1.4.1.5835.3.1.4.1.244.1.1				
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	NA	NA	1500	1500 .. 1600		

/Modem/Control/Interfaces/Ethernet/Link/Interface

Only valid for Eth(IP), Eth(TSIP), Eth(S2BBF) or Eth(ntS2BBF) processing modes.

/Modem/Control/Interfaces/Ethernet/Link/Interface A

Command IfEthAutoNegEn		Auto-Negotiation			
Location	/Modem/Control/Interfaces/Ethernet/Link/Interface A				
Description	Configuration of auto-negotiation of the Ethernet physical interface. When auto-negotiation is disabled the correct speed must be configured via command IfEthForceSpeed . If auto-negotiation is enabled, the auto-negotiation sequence will be restarted. Remark: For 1000 BASE-T, auto-negotiation must always be enabled.				
RMCP Command	EAe array : [1 .. 2]	Access	Normal user : RW Expert user : RW		
	Table	ntcDevsMod01InterfaceEntry			
	Command	ntcDevsMod01IfEthAutoNegEn			
SNMP	OID	1.3.6.1.4.1.5835.3.1.4.1.81.1.1.[1 .. 2]			
	Factory Default	Enumeration	Value		
	enabled	Disabled Enabled	0 1		

Command IfEthAutoNegRestart		Restart Auto-Negotiation			
Location	/Modem/Control/Interfaces/Ethernet/Link/Interface A				
Description	Configuration command to restart the auto-negotiation sequence of the Ethernet physical interface.				
RMCP Command	EAe array : [1 .. 2]	Access	Normal user : RW Expert user : RW		
	Table	ntcDevsMod01InterfaceEntry			
	Command	ntcDevsMod01IfEthAutoNegRestart			
SNMP	OID	1.3.6.1.4.1.5835.3.1.4.1.82.1.1.[1 .. 2]			
	Factory Default	Enumeration	Value		
	idle	Restart Idle	0 1		

Command IfEthForceSpeed2		Speed advertisement	Speed advertisement
Location	/Modem/Control/Interfaces/Ethernet/Link/Interface A		
Description	Configuration command to force the speed of the Ethernet physical interface to a given bitrate by changing the advertised speeds in the auto-		

Command IfEthForceSpeed2		Speed advertisement	Speed advertisement
	negotiation process.		
RMCP Command	efs array : [1 .. 2]	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfEthForceSpeed2	
	OID	1.3.6.1.4.1.5835.3.1.4.1.232.1.1.[1 .. 2]	
Values	Factory Default	Enumeration	Value
	autonegotiated	autonegotiated 10 BASE-T Half Duplex 10 BASE-T Full Duplex 100 BASE-T Half Duplex 100 BASE-T Full Duplex 1000 BASE-T Full Duplex	0 1 2 3 4 5

/Modem/Control/Interfaces/Ethernet/Link/Interface B

Command IfEthAutoNegEn		Auto-Negotiation	Auto-Negotiation
Location	/Modem/Control/Interfaces/Ethernet/Link/Interface B		
Description	Configuration of auto-negotiation of the Ethernet physical interface. When auto-negotiation is disabled the correct speed must be configured via command IfEthForceSpeed . If auto-negotiation is enabled, the auto-negotiation sequence will be restarted. Remark: For 1000 BASE-T, auto-negotiation must always be enabled.		
RMCP Command	EAe array : [1 .. 2]	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfEthAutoNegEn	
	OID	1.3.6.1.4.1.5835.3.1.4.1.81.1.1.[1 .. 2]	
Values	Factory Default	Enumeration	Value
	enabled	Disabled Enabled	0 1

Command IfEthAutoNegRestart		Restart Auto-Negotiation	Restart Auto-Negotia
Location	/Modem/Control/Interfaces/Ethernet/Link/Interface B		
Description	Configuration command to restart the auto-negotiation sequence of the Ethernet physical interface.		
RMCP Command	EAr array : [1 .. 2]	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfEthAutoNegRestart	

Command IfEthAutoNegRestart		Restart Auto-Negotiation	Restart Auto-Negotiation
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.4.1.82.1.1.[1 .. 2]	
Values	<i>Factory Default</i>	<i>Enumeration</i>	<i>Value</i>
	idle	Restart Idle	0 1

Command IfEthForceSpeed2		Speed advertisement	Speed advertisement
Location	/Modem/Control/Interfaces/Ethernet/Link/Interface B		
Description	Configuration command to force the speed of the Ethernet physical interface to a given bitrate by changing the advertised speeds in the auto-negotiation process.		
RMCP Command	efs array : [1 .. 2]	Access	Normal user : no access Expert user : RW
SNMP	<i>Table</i>	ntcDevsMod01InterfaceEntry	
	<i>Command</i>	ntcDevsMod01IfEthForceSpeed2	
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.4.1.232.1.1.[1 .. 2]	
Values	<i>Factory Default</i>	<i>Enumeration</i>	<i>Value</i>
	autonegotiated	autonegotiated 10 BASE-T Half Duplex 10 BASE-T Full Duplex 100 BASE-T Half Duplex 100 BASE-T Full Duplex 1000 BASE-T Full Duplex	0 1 2 3 4 5

/Modem/Control/Interfaces/Ethernet/Itf redundancy

Command IfEthIfRedunEnable		Eth ift redundancy	Eth ift redundancy
Location	/Modem/Control/Interfaces/Ethernet/Itf redundancy		
Description	Configuration command to enable or disable Ethernet interface redundancy. When Ethernet interface redundancy is enabled, Ethernet interface A and B will behave as one virtual interface. Only one of the physical interfaces will be active at a time. The configuration will move from one interface to the other, as one takes over operation from the other.		
RMCP Command	eir	Access	Normal user : RW Expert user : RW
SNMP	<i>Table</i>	ntcDevsMod01InterfaceEntry	
	<i>Command</i>	ntcDevsMod01IfEthIfRedunEnable	
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.4.1.241.1.1	
Values	<i>Factory Default</i>	<i>Enumeration</i>	<i>Value</i>
	disabled	Disabled Enabled	0 1

Command IfEthIfRedunEnable	Eth if redundancy	Eth if redundancy
	Enabled: prioritize A Enabled: prioritize B	2 3

Command IfEthIfRedunFollowGw		Itf follows gateway	Itf follows gateway
Location	/Modem/Control/Interfaces/Ethernet/Itf redundancy		
Description	Configuration for the interface link selection to choose the active link where the gateway IP address(es) can be reached. When one of the configured IP gateways is not reachable on one of the interfaces, it will make the other interface active. Gateway detection is only performed on the active link. After switching to the redundant link, the system will not try to switch back to the original link unless if there is a problem on the new active link.		
RMCP Command	irf	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfEthIfRedunFollowGw	
	OID	1.3.6.1.4.1.5835.3.1.4.1.242.1.1	
Values	Factory Default	Enumeration	Value
	disabled	Disabled Enabled	0 1

/Modem/Control/Interfaces/Ethernet/Unit redundancy

Command IfEthUnitRedunState		Unit redundancy state	Unit redundancy stat
Location	/Modem/Control/Interfaces/Ethernet/Unit redundancy		
Description	This command allows to configure the unit as active or standby. The Ethernet interfaces of a standby unit will not carry operational traffic.		
RMCP Command	eus	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfEthUnitRedunState	
	OID	1.3.6.1.4.1.5835.3.1.4.1.246.1.1	
Values	Factory Default	Enumeration	Value
	active	Standby Active	0 1

Command IfEthUnitRedunVmac		Unit redun virtual MAC	Unit redun virtual M
Location	/Modem/Control/Interfaces/Ethernet/Unit redundancy		
Description	Configuration command to enable virtual MAC addresses on the Ethernet traffic ports. Units that backup each other should have the same IP addresses and virtual MAC addresses when one goes down. Before enabling virtual MAC addressing, you should configure the virtual reality identifier that determines the virtual MAC address to be used (according to the virtual router redundancy protocol standard). Ethernet interfaces that backup each other should be assigned the same VR-ID or virtual reality identifier.		
RMCP Command	euv		
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfEthUnitRedunVmac	
	OID	1.3.6.1.4.1.5835.3.1.4.1.247.1.1	
Values	Factory Default	Enumeration	Value
	disabled	Disabled Enabled	0 1

Command IfEthUnitRedunVrrp		VRRP enable	VRRP enable
Location	/Modem/Control/Interfaces/Ethernet/Unit redundancy		
Description	This value is used to enable or disable the use of the VRRP protocol to check the presence of a redundant unit. It is used to avoid that 2 devices would be enabled at the same time.		
RMCP Command	urv		
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfEthUnitRedunVrrp	
	OID	1.3.6.1.4.1.5835.3.1.4.1.255.1.1	
Values	Factory Default	Enumeration	Value
	enabled	Disabled Enabled	0 1

Command IfEthUnitRedunVridA		VR-ID Eth A	VR-ID Eth A
Location	/Modem/Control/Interfaces/Ethernet/Unit redundancy		
Description	Configuration of the VR-ID or virtual reality identifier for Ethernet interface A. Ethernet interfaces that backup each other should have the same VR-ID. The VR-ID is a value between 1 and 255. It uniquely identifies a set of redundant Ethernet interfaces on a LAN.		
RMCP Command	vra	Access	Normal user : RW Expert user : RW

Command IfEthUnitRedunVridA		VR-ID Eth A	VR-ID Eth A
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfEthUnitRedunVridA	
	OID	1.3.6.1.4.1.5835.3.1.4.1.248.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	NA	NA	1 .. 255

Command IfEthUnitRedunVridB		VR-ID Eth B	VR-ID Eth B
Location	/Modem/Control/Interfaces/Ethernet/Unit redundancy		
Description	Configuration of the VR-ID or virtual reality identifier for Ethernet interface B. Ethernet interfaces that backup each other should have the same VR-ID. The VR-ID is a value between 1 and 255. It uniquely identifies a set of redundant Ethernet interfaces on a LAN.		
RMCP Command	vrb	Access	
	Normal user : RW Expert user : RW		
	SNMP		ntcDevsMod01InterfaceEntry
Values	Table	ntcDevsMod01IfEthUnitRedunVridB	
	Command	1.3.6.1.4.1.5835.3.1.4.1.249.1.1	
	OID	NA	
GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	NA	2	1 .. 255

Command IfEthUnitRedunFollowGw		Unit follows gateway	Unit follows gateway
Location	/Modem/Control/Interfaces/Ethernet/Unit redundancy		
Description	Configuration for unit redundancy to choose the active unit where the gateway IP address(es) can be reached. When one of the configured IP gateways is not reachable on one of the units, it can make the other unit active. Gateway detection is only performed on the active link. After switching to the redundant unit, the system will not try to switch back to the original unit unless if there is a problem on the new active unit.		
RMCP Command	urf		Access
SNMP	Table	Normal user : RW Expert user : RW	
	Command	ntcDevsMod01InterfaceEntry	
	OID	ntcDevsMod01IfEthUnitRedunFollowGw	
Values	Factory Default		Enumeration
	disabled		Disabled Enabled
			Value
	0		1

/Modem/Control/Interfaces/Ethernet/IP encap-decap



Only valid for Eth (IP) processing modes.

Command IfEthInputConf		Enable Ethernet ift	Enable Ethernet ift
Location	/Modem/Control/Interfaces/Ethernet/IP encap-decap		
Description	Configuration of the interface to be used on the Ethernet board. When Ethernet interface redundancy is enabled, interface A points to the virtual interface on top of interface A and B. If you want to know which of both interfaces is currently active on a redundant setup, you can look at the monitoring page.		
RMCP Command	llc	Access	Normal user : RW Expert user : RW
SNMP	Table ntcDevsMod01InterfaceEntry Command ntcDevsMod01IfEthInputConf OID 1.3.6.1.4.1.5835.3.1.4.1.84.1.1		
Values	Factory Default noinput	Enumeration None Interface A Interface B	Value 0 1 2

Command IfVLANSupport		VLAN Support	VLAN Support
Location	/Modem/Control/Interfaces/Ethernet/IP encap-decap		
Description	Configuration of VLAN support. <ul style="list-style-type: none"> With VLAN support enabled (default), Ethernet filtering and processing is based on VLAN tags. With VLAN support disabled (= native VLAN support in 801.1Q), all traffic coming from the input interface is processed without looking at any VLAN information. e.g. the Ethernet RX filters which have different VLAN identifier and different destination MAC behave as if they had the same VLAN identifier and that this imaginary VLAN matched the Ethernet input interface. 		
RMCP Command	IVS	Access	Normal user : RW Expert user : RW
SNMP	Table ntcDevsMod01InterfaceEntry Command ntcDevsMod01IfVLANSupport OID 1.3.6.1.4.1.5835.3.1.4.1.114.1.1		
Values	Factory Default disabled	Enumeration Disabled Enabled	Value 0 1

Command IfEthRxFixedFilter Protocols		Encapsulation protocol		Encapsulation protocol
Location	/Modem/Control/Interfaces/Ethernet/IP encaps-decap			
Description	Configuration of the encapsulation protocol to use.			
RMCP Command	Efp		Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry		
	Command	ntcDevsMod01IfEthRxFixedFilterProtocols		
	OID	1.3.6.1.4.1.5835.3.1.4.1.85.1.1		
Values	Factory Default	Enumeration	Value	
	ule	None ULE Datapiping XPE MPE GSE	0 1 2 3 4 5	

Command IfBridgeType		Bridge type	Bridge type
Location	/Modem/Control/Interfaces/Ethernet/IP encaps-decap		
Description	Configuration of the bridge type. The following selections are possible: <ul style="list-style-type: none"> • Layer 2 Ethernet Bridge: Raw Ethernet packet forwarding. • Layer 3 IP Bridging: Raw IP packet forwarding with proxy ARP support for remote IP addresses in the same subnet. • Layer 3 IP Routing: Raw IP packet forwarding. The modulator acts as a router. 		
RMCP Command	lbt		Access Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfBridgeType	
	OID	1.3.6.1.4.1.5835.3.1.4.1.190.1.1	
Values	Factory Default	Enumeration	Value
	ethbridge	L2 Ethernet Bridge L3 IP Bridge L3 IP Router	0 1 2

Command IfEnableL2routing		L2 routing	L2 routing
Location	/Modem/Control/Interfaces/Ethernet/P encaps-decap		
Description	Configuration command to enable or disable layer 2 routing in a layer 3 forwarding device. When you enable layer 2 routing, you can route IP packets on the destination MAC address.		
RMCP Command	elr		Access Normal user : no access Expert user : RW

Command IfEnableL2routing		L2 routing	L2 routing
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfEnableL2routing	
	OID	1.3.6.1.4.1.5835.3.1.4.1.230.1.1	
Values	Factory Default		Enumeration
	enabled		Disabled Enabled
		0 1	

Command IfPromiscFlag		promiscuous mode	promiscuous mode
Location		/Modem/Control/Interfaces/Ethernet/IP encaps-decap	
Description		Readout of the promiscuous flag that indicates if the Ethernet interface is receiving packets for all MAC addresses (= promiscuous) or only for its own MAC address (= non-promiscuous).	
RMCP Command	prm		Access Normal user : no access Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfPromiscFlag	
	OID	1.3.6.1.4.1.5835.3.1.4.1.197.1.1	
Values	Factory Default		Enumeration
	nonPromiscuous		Non-promiscuous Promiscuous
		0 1	

Command IfForcePromiscuous		Force promiscuous	Force promiscuous
Location		/Modem/Control/Interfaces/Ethernet/IP encaps-decap	
Description		Configuration to force packet reception from the Ethernet interface in promiscuous mode which means accepting all MAC addresses from the Ethernet physical interface. Normally, the system will decide automatically whether the Ethernet physical interface should be in promiscuous mode or not. Forcing the physical interface into promiscuous mode is useful for troubleshooting, because it allows you to capture all packets that are received on the wire.	
RMCP Command	fpr		Access Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfForcePromiscuous	
	OID	1.3.6.1.4.1.5835.3.1.4.1.192.1.1	
Values	Factory Default		Enumeration
	automatic		Automatic Force promiscuous
		0 1	

Command IfPacketInsStreamId		Inband mngt encap stream id		Inband mngt encap st		
Location	/Modem/Control/Interfaces/Ethernet//P encapsulation-decap					
Description	Inband management encapsulation stream id.					
RMCP Command	Pis	Access		Normal user : no access Expert user : RW		
SNMP	Table	ntcDevsMod01InterfaceEntry				
	Command	ntcDevsMod01IfPacketInsStreamId				
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	NA	NA	1	1 .. 5		

Command IfPacketInsStreamId		Inband mngt encap stream id		Inband mngt encap st		
Location	/Modem/Control/Interfaces/Ethernet//P encapsulation-decap					
Description	Inband management encapsulation stream id.					
RMCP Command	Pis	Access		Normal user : no access Expert user : RW		
SNMP	Table	ntcDevsMod01InterfaceEntry				
	Command	ntcDevsMod01IfPacketInsStreamId				
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	NA	NA	1	01/05/10		

Command IfVLANForwarding		VLAN forwarding		VLAN forwarding		
Location	/Modem/Control/Interfaces/Ethernet/ipencap					
Description	Select how VLANs are mapped to the satellite payload:					
	<ul style="list-style-type: none"> • add-drop: VLAN is dropped, and replaced by PID/ISI/AirMAC addressing • keep: VLAN is kept, in addition to the PID/ISI/AirMAC addressing 					
RMCP Command	vfw	Access		Normal user : RW Expert user : RW		
SNMP	Table	ntcDevsMod01InterfaceEntry				
	Command	ntcDevsMod01IfVLANForwarding				
	OID	1.3.6.1.4.1.5835.3.1.4.1.280.1.1				
Values	Factory Default		Enumeration	Value		
	adddrop		Add-drop Keep	0 1		

Command IfVLANTypeId		VLAN type id	VLAN type id
Location	/Modem/Control/Interfaces/Ethernet/ipencap		
Description	This field defines the VLAN type identifier. It can be used to filter on the outer VLAN tag in a QinQ frame (standardized as 0x9100). This device filters on maximum 1 VLAN tag.		
RMCP Command	vtp	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfVLANTypeId	
	OID	1.3.6.1.4.1.5835.3.1.4.1.281.1.1	
Values	Factory Default	String Description	
	8100	length : 4 (fixed) format : Hexadecimal chars	

/Modem/Control/Interfaces/Ethernet/IP encap-decap/IP interface table

Structured Command IfBrifEntry		IP interface table	IP interface table
Location	/Modem/Control/Interfaces/Ethernet/encap-decap/IP interface table		
Description	Configuration of the IP interface entry that contains the configuration parameters of an IP subnet that is bridged or routed over the satellite link.		
RMCP Command	Bte array : [1 .. 32]	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfBrifEntry	
	OID	1.3.6.1.4.1.5835.3.1.4.1.183.1.1.[1 .. 32]	
Variables			Page
IfBrifEnable			190
IfBrifLocalVlan			191
IfBrifLocalIp			191
IfBrifLocalIpMask			192
IfBrifLocalGateway			192
IfBrifRemotelp			192
IfBrifRemotelpMask			193

/Modem/Control/Interfaces/Ethernet/IP encap-decap/Ethernet Rx routes

Structured Command IfChConfigEthRx		Ethernet receive routes	Ethernet Rx routes
Location	/Modem/Control/Interfaces/Ethernet/ipencap/Ethernet Rx routes		
Description	Configuration of the routes from the Ethernet interface towards the satellite interface. Packets are captured from the specified VLAN and filtered by the Ethernet MAC address and/or IP address. The matching packets are encapsulated by the specified protocol engine using the specified PID and air-MAC address (if needed by protocol settings). Remark1: Ethernet MAC address = 00:00:00:00:00:00 matches all addresses. Remark2: IP address = 0.0.0.0 matches all addresses.		
RMCP Command	ICR array : [1 .. 255]	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfChConfigEthRx	
	OID	1.3.6.1.4.1.5835.3.1.4.1.59.1.1.[1 .. 255]	
Variables			Page
IfChConfigEthRxEnable IfChConfigEthRxVlanId IfChConfigEthRxMac IfChConfigEthRxIp IfChConfigEthRxIpMask IfChConfigEthRxStreamId IfChConfigEthRxPID IfChConfigEthRxAirMac IfChConfigEthRxPackingDelay			175 176 176 176 177 177 178 178 178

/Modem/Control/Interfaces/Ethernet/IP encap-decap/Demod Rx routes

Structured Command IfChConfigEthTx		Demod Rx routes	Demod Rx routes
Location	/Modem/Control/Interfaces/Ethernet/ipencap/Demod Rx routes		
Description	Configuration of the routing from the demodulator interface towards the Ethernet network. MPEG transport stream packets with the specified PID are decoded by the protocol engine. If the protocol requires an Air-MAC address, the specified Air-MAC address is used and the resulting Ethernet packet is sent to the specified VLAN. If an Ethernet MAC address is specified (00:00:00:00:00:00 means "not set"), the destination MAC address of the Ethernet frame is set accordingly. If the Ethernet MAC address is not specified, the destination MAC address for the next HOP will be found by using ARP.		
RMCP Command	ICT array : [1 .. 32]	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfChConfigEthTx	
	OID	1.3.6.1.4.1.5835.3.1.4.1.67.1.1.[1 .. 32]	
Variables			Page

Structured Command IfChConfigEthTx	Demod Rx routes	Demod Rx routes
IfChConfigEthTxEnable		179
IfChConfigEthTxISI		180
IfChConfigEthTxPID		180
IfChConfigEthTxAirMac		180
IfChConfigEthTxVlanId		181
IfChConfigEthTxMac		181

/Modem/Control/Interfaces/Ethernet/IP encaps-decap/Protocols

Only valid for Eth (IP) processing modes.

Structured Command IfUleSettings	ULE Settings	ULE Settings			
Location	/Modem/Control/Interfaces/Ethernet/IP encaps-decap/Protocols				
Description	<p>Configuration of the ULE encapsulator or decapsulator.</p> <ul style="list-style-type: none"> Air-Mac mode: Enables or disables the insertion of an Air-MAC address. Enabling Air-MAC address insertion gives 6 bytes extra overhead for each Ethernet packet. Air-MAC addresses provide the user with an extra level of filtering at the demodulator side. The easiest way of filtering is on PID but if this is not enough or not possible, Air-MAC addresses are available. CRC: CRCs are used to protect the encapsulated data. When enabled, it calculates the CRC-32 over the encapsulated data and checks this checksum again at the demodulator side. When disabled, no CRC-32 value is inserted and may increase the encapsulation performance slightly. The last option might be useful if a slight performance boost is required by the user. 				
RMCP Command	IUS	Access	Normal user : RW Expert user : RW		
SNMP	Table	ntcDevsMod01InterfaceEntry			
	Command	ntcDevsMod01IfUleSettings			
	OID	1.3.6.1.4.1.5835.3.1.4.1.107.1.1			
Variables					
IfUleSettingsDestMac					
IfUleSettingsCRC					
		Page			
IfUleSettingsDestMac					
IfUleSettingsCRC					

Structured Command IfGBSSettings	XPE Settings	XPE Settings	
Location	/Modem/Control/Interfaces/Ethernet/IP encaps-decap/Protocols		
Description	Only valid for modes Air (XPE).		
RMCP Command	IGS	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	

Structured Command IfGBSSettings		XPE Settings	XPE Settings
	Command	ntcDevsMod01IfGBSSettings	
	OID	1.3.6.1.4.1.5835.3.1.4.1.91.1.1	
Variables			Page
IfGBSSettingsDestMac			182
IfGBSSettingsCRC			183

Structured Command IfGSESettings		GSE Settings	GSE Settings
Location	/Modem/Control/Interfaces/Ethernet/ipencap/Protocols		
Description	Configuration of GSE encapsulator/decapsulator. To change the values, press the change button. For each variable, a drop down box will appear. Select your choices, and press the APPLY button.		
RMCP Command	gss		Access
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfGSESettings	
	OID	1.3.6.1.4.1.5835.3.1.4.1.274.1.1	
Variables			Page
IfGSESettingsDestMac			183

/Modem/Control/Interfaces/Ethernet/IP encap-decap/QOS

Command IfEnableQosClassif		Eth RX QOS	Eth RX QOS
Location	/Modem/Control/Interfaces/Ethernet/IP encap-decap/QOS		
Description	Configuration command to enable or disable Ethernet quality of service classification or QOS classification.		
RMCP Command	eqc		Access
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfEnableQosClassif	
	OID	1.3.6.1.4.1.5835.3.1.4.1.231.1.1	
Values	Factory Default	Enumeration	Value
	enabled	Disabled Enabled	0 1

Command IfQosOnCpupload		QOS on cpupload		QOS on cpupload
Location	/Modem/Control/Interfaces/Ethernet/IP encaps-decap/QOS			
Description	Configuration command to specify if the quality of service mechanism need to be applied when the CPU is highly loaded. Enabling this will lower the maximum throughput.			
RMCP Command	qoc		Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry		
	Command	ntcDevsMod01IfQosOnCpupload		
	OID	1.3.6.1.4.1.5835.3.1.4.1.250.1.1		
Values	Factory Default	Enumeration	Value	
	disabled	Disabled Enabled	0 1	

Structured Command IfQosQueueEntry		Eth RX QOS queue table	Eth RX QOS queue tab
Location	/Modem/Control/Interfaces/Ethernet/IP encaps-decap/QOS		
Description	Configuration of a quality of service queue entry that contains the dimensioning parameters for a quality of service queue.		
RMCP Command	qqe array : [1 .. 4]		Access Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceExtEntry	
	Command	ntcDevsMod01IfQosQueueEntry	
	OID	1.3.6.1.4.1.5835.3.1.4000.1.17.1.1.[1 .. 4]	
Variables			Page
IfQosQueuePriority IfQosQueueGuarPerFlow IfQosQueueMaxPerQos			195 195 196

Structured Command IfEthQosRuleEntry		Eth RX QOS rule table	Eth RX QOS rule tabl
Location	/Modem/Control/Interfaces/Ethernet/IP encaps-decap/QOS		
Description	Configuration of a quality of service rule entry to define which packets are directed to which quality of service queue.		
RMCP Command	qre array : [1 .. 8]		Access Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceExtEntry	
	Command	ntcDevsMod01IfEthQosRuleEntry	
	OID	1.3.6.1.4.1.5835.3.1.4000.1.16.1.1.[1 .. 8]	
Variables			Page
IfEthQosRuleEnable			196

Structured Command IfEthQosRuleEntry	Eth RX QOS rule table	Eth RX QOS rule table
IfEthQosRuleClassif IfEthQosRulePrio		196 197

/Modem/Control/Interfaces/Ethernet/IP encap-decap/Signalling

Command SySigIp	Signalling IP		Signalling IP
Location	/Modem/Control/Interfaces/Ethernet/IP encap-decap/Signalling		
Description	Configuration of the signalling IP address. The signalling IP address is used for various control functions such as ACM messaging.		
RMCP Command	sip	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SySigIp	
	OID	1.3.6.1.4.1.5835.3.1.1.95.1.1	
Values	Factory Default	String Description	
	239.1.0.1	length : 0 .. 15 format : \d{1,3}\.\d{1,3}\.\d{1,3}\.\d{1,3}	

Command IfEnableModDemodSig	mod-demod signalling		mod-demod signalling
Location	/Modem/Control/Interfaces/Ethernet/IP encap-decap/Signalling		
Description	Configuration command to enable or disable modulator to demodulator signalling. This signalling traffic can be used to lock a DVB-S2 demodulator or for information sharing between modulator and demodulator.		
RMCP Command	Mds	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfEnableModDemodSig	
	OID	1.3.6.1.4.1.5835.3.1.4.1.239.1.1	
Values	Factory Default	Enumeration	Value
	enabled	Disabled Enabled	0 1

/Modem/Control/Interfaces/Ethernet/IP termination/Network

Only valid for the following processing modes:

- Eth (TSoIP)
- Eth (S2BBFoE)
- Eth (ntS2BBFoE)

Command BuDecOwnIpaddrA		Own IP address A			
Location	/Modem/Control/Interfaces/Ethernet/IP termination/Network				
Description	Configuration of the IP address of Ethernet interface A.				
RMCP Command	Oaa	Access	Normal user : RW Expert user : RW		
SNMP	Table	ntcDevsMod01BurstDemodEntry			
	Command	ntcDevsMod01BuDecOwnIpaddrA			
	OID	1.3.6.1.4.1.5835.3.1.15.1.3.1.1			
Values	Factory Default	String Description			
	192.168.254.2	length : 0 .. 15 format : \d{1,3}.\d{1,3}.\d{1,3}.\d{1,3}			

Command BuDecOwnNetMaskA		Own netmask A			
Location	/Modem/Control/Interfaces/Ethernet/IP termination/Network				
Description	Configuration of the network mask of Ethernet interface A.				
RMCP Command	Ana	Access	Normal user : RW Expert user : RW		
SNMP	Table	ntcDevsMod01BurstDemodEntry			
	Command	ntcDevsMod01BuDecOwnNetMaskA			
	OID	1.3.6.1.4.1.5835.3.1.15.1.5.1.1			
Values	Factory Default	String Description			
	255.255.255.0	length : 0 .. 15 format : \d{1,3}.\d{1,3}.\d{1,3}.\d{1,3}			

Command BuDecOwnIpaddrB		Own IP Address B			
Location	/Modem/Control/Interfaces/Ethernet/IP termination/Network				
Description	Configuration of the IP address of Ethernet interface B.				
RMCP Command	Oab	Access	Normal user : RW Expert user : RW		
SNMP	Table	ntcDevsMod01BurstDemodEntry			
	Command	ntcDevsMod01BuDecOwnIpaddrB			
	OID	1.3.6.1.4.1.5835.3.1.15.1.4.1.1			
Values	Factory Default	String Description			

Command BuDecOwnIpaddrB		Own IP Address B	Own IP Address B
	192.168.254.3	length : 0 .. 15 format : \d{1,3}\.\d{1,3}\.\d{1,3}\.\d{1,3}	

Command BuDecOwnNetMaskB		Own netmask B	Own netmask B
Location	/Modem/Control/Interfaces/Ethernet/IP termination/Network		
Description	Configuration of the network mask of Ethernet interface B.		
RMCP Command	Anb		Access Normal user : RW Expert user : RW
	Table	ntcDevsMod01BurstDemodEntry	
	Command	ntcDevsMod01BuDecOwnNetMaskB	
SNMP	OID	1.3.6.1.4.1.5835.3.1.15.1.6.1.1	
	Values	Factory Default	String Description
		255.255.255.0	length : 0 .. 15 format : \d{1,3}\.\d{1,3}\.\d{1,3}\.\d{1,3}

Command SyBuDecIPGateWay		Default Gateway Address	If gateway address
Location	/Modem/Control/Interfaces/Ethernet/IP termination/Network		
Description	Configuration command of the IP address of the default gateway.		
RMCP Command	DGw		Access Normal user : RW Expert user : RW
	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyBuDecIPGateWay	
SNMP	OID	1.3.6.1.4.1.5835.3.1.1.1.75.1.1	
	Values	Factory Default	String Description
		192.168.254.206	length : 0 .. 15 format : \d{1,3}\.\d{1,3}\.\d{1,3}\.\d{1,3}

Command IfEthMcastIf		Multicast interface	Multicast interface
Location	/Modem/Control/Interfaces/Ethernet/IP termination/Network		
	Only valid for Eth (TSoIP) processing mode.		
Description	Configuration command to select the interface that must carry the incoming or outgoing multicast IP traffic.		
RMCP Command	Mif		Access Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfEthMcastIf	

Command IfEthMcastIf		Multicast interface	Multicast interface
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.4.1.191.1.1	
Values	Factory Default	Enumeration	Value
	none	None Interface A Interface B	0 1 2

/Modem/Control/Interfaces/Ethernet/IP termination/MPEG over IP



Only valid for Eth (TSoIP) processing mode.

Command IfMPEGoUDPRXSettingsFormat		RX Format	RX Format
Location	/Modem/Control/Interfaces/Ethernet/IP termination/MPEG over IP		
Description	Configuration of the type of protocol stack that the transport stream packets are encapsulated on. This setting applies to the reception format of UDP packets. <ul style="list-style-type: none"> UDP: User datagram protocol. RTP: Real time transmission protocol. TS: MPEG transport stream. 		
RMCP Command	VRf	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfMPEGoUDPRXSettingsFormat	
	OID	1.3.6.1.4.1.5835.3.1.4.1.146.1.1	
Values	Factory Default	Enumeration	Value
	UDPTS	UDP/TS UDP/RTP/TS	0 1

Command IfMPEGoUDPRXSettingsType		RX IP type	RX IP type
Location	/Modem/Control/Interfaces/Ethernet/IP termination/MPEG over IP		
Description	Configuration of what type of network transmission is used. The type of IP addressing can be unicast or multicast. Remark: This setting applies to the reception of UDP packets.;		
RMCP Command	VRt	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfMPEGoUDPRXSettingsType	

Command IfMPEGoUDPRXSettings Type		RX IP type	RX IP type
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.4.1.149.1.1	
Values	<i>Factory Default</i>	<i>Enumeration</i>	<i>Value</i>
	multicast	Multicast Unicast	0 1

Command IfMPEGoUDPRXSettings Profile		RX Profile	RX Profile
Location	/Modem/Control/Interfaces/Ethernet/IP termination/MPEG over IP		
Description	Configuration of the profile of the transport stream over IP traffic. <ul style="list-style-type: none"> • CBR: Constant bitrate. • VBR: Variable bitrate. CBR can be used if the Ethernet rate is constant over time. Ethernet packets are received at regular moments in time. VBR needs to be configured if the Ethernet rate is bursty in nature. Sometimes lots of data is received, sometimes nothing is received. CBR can be used to slave the baud rate of the modulator onto the received Ethernet rate. In VBR mode, no slaving is possible. If the Ethernet rate is too low null packet stuffing is done. 		
RMCP Command	VRP	Access	Normal user : no access Expert user : RW
SNMP	<i>Table</i>	ntcDevsMod01InterfaceEntry	
	<i>Command</i>	ntcDevsMod01IfMPEGoUDPRXSettingsProfile	
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.4.1.148.1.1	
Values	<i>Factory Default</i>	<i>Enumeration</i>	<i>Value</i>
	cbr	CBR VBR	0 1

Command IfMPEGoUDPRXSettingsIP		RX Multicast IP	RX Multicast IP
Location	/Modem/Control/Interfaces/Ethernet/IP termination/MPEG over IP		
Description	Configuration of the multicast IP address for the incoming UDP stream. Remark: This setting is not applicable when the type of the incoming stream is unicast.		
RMCP Command	VRi	Access	Normal user : RW Expert user : RW
SNMP	<i>Table</i>	ntcDevsMod01InterfaceEntry	
	<i>Command</i>	ntcDevsMod01IfMPEGoUDPRXSettingsIP	
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.4.1.147.1.1	
Values	<i>Factory Default</i>	<i>String Description</i>	
	224.0.0.1	length : 0 .. 15 format : \d{1,3}.\d{1,3}.\d{1,3}.\d{1,3}	

Command	RX UDP port		
IfMPEGoUDPRXSettings			
UDPPort			
Location	/Modem/Control/Interfaces/Ethernet/IP termination/MPEG over IP		
Description	Configuration of the UDP port number for MPEG over UDP decapsulation. Remark: This setting applies to the reception of UDP packets.		
RMCP Command	VRp	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfMPEGoUDPRXSettingsUDPPort	
	OID	1.3.6.1.4.1.5835.3.1.4.1.150.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	NA	NA	9035
Expert Range (CU)			
0 .. 65535			

/Modem/Control/Interfaces/Ethernet/IP termination/S2BBF over IP



Only valid for Eth (S2BBFoE) processing mode.

Command	S2BBFoE rx UDP port		
IfDvbs2BboeRxUdpPort			
Location	/Modem/Control/Interfaces/Ethernet/IP termination/S2BBF over IP		
Description	This field defines the UDP port used for receiving DVB-S2 baseband frames over Ethernet from an external encapsulator (e.g.: EL860)		
RMCP Command	brU	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfDvbs2BboeRxUdpPort	
	OID	1.3.6.1.4.1.5835.3.1.4.1.134.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	NA	NA	12345
Expert Range (CU)			
0 .. 65535			

Command	S2BBFoE tx IP address		
IfDvbs2BboeTxIp			
Location	/Modem/Control/Interfaces/Ethernet/IP termination/S2BBF over IP		
Description	Configuration of the IP address to which DVB-S2 baseband frames will be transmitted over the Ethernet interface. This address can be a unicast or multicast IP address.		
RMCP Command	btl	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfDvbs2BboeTxIp	
	OID	1.3.6.1.4.1.5835.3.1.4.1.228.1.1	
Values	Factory Default	String Description	

Command IfDvbs2BboeTxIp		S2BBFoE tx IP address	S2BBFoE tx IP address
	0.0.0.0	length : 0 .. 15 format : \d{1,3}\.\d{1,3}\.\d{1,3}\.\d{1,3}	

Command IfDvbs2BboeTxUdpPort		S2BBFoE tx UDP port	S2BBFoE tx UDP port
Location	/Modem/Control/Interfaces/Ethernet/IP termination/S2BBF over IP		
Description	Configuration of the UDP port number to which DVB-S2 baseband frames will be transmitted over the Ethernet interface.		
RMCP Command	btU	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfDvbs2BboeTxUdpPort	
	OID	1.3.6.1.4.1.5835.3.1.4.1.229.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	NA	NA	12345
		0 .. 65535	

/Modem/Control/Interfaces/Ethernet/IP termination/S2BBF over IP/S2BBF oE instances

Structured Command IfDvbs2BboeRxInstances		S2BBFoE instances	S2BBFoE instances
Location	/Modem/Control/Interfaces/Ethernet/IP termination/S2BBF over IP/S2BBF oE instances		
Description	This command allows to configure the configuration data for the DVB-S2 baseband receivers in <i>a single-encapsulator environment</i> .		
RMCP Command	Bri array : [1 .. 4]	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfDvbs2BboeRxInstances	
	OID	1.3.6.1.4.1.5835.3.1.4.1.132.1.1.[1 .. 4]	
Variables			Page
IfDvbs2BboeRxEnable			234
IfDvbs2BboeRxMcastIpAddress			234

/Modem/Control/Interfaces/Ethernet/IP termination/ntS2BBF over IP



Only valid for Eth (ntS2BBFoE) processing mode.

Command IfDvbs2BbRxUdpPort		ntS2BBFoE UDP port	ntS2BBFoE UDP port
Location	/Modem/Control/Interfaces/Ethernet/IP termination/ntS2BBF over IP		
Description	This field defines the UDP port used for receiving DVB-S2 baseband frames over Ethernet from an external encapsulator (e.g.: AZ810)		
RMCP Command	bru	Access	Normal user : no access Expert user : R
	SNMP	Table	ntcDevsMod01InterfaceEntry
		Command	ntcDevsMod01IfDvbs2BbRxUdpPort
Values	OID	1.3.6.1.4.1.5835.3.1.4.1.130.1.1	
	GUI Unit	Cmd Unit	Factory Default (CU)
	NA	NA	12345
		Expert Range (CU)	
		0 .. 65535	

Command IfDvbs2BboeTxIp		S2BBFoE tx IP address	S2BBFoE tx IP address
Location	/Modem/Control/Interfaces/Ethernet/IP termination/ntS2BBF over IP		
Description	Configuration of the IP address to which DVB-S2 baseband frames will be transmitted over the Ethernet interface. This address can be a unicast or multicast IP address.		
RMCP Command	btl	Access	Normal user : RW Expert user : RW
	SNMP	Table	ntcDevsMod01InterfaceEntry
		Command	ntcDevsMod01IfDvbs2BboeTxIp
Values	OID	1.3.6.1.4.1.5835.3.1.4.1.228.1.1	
	Factory Default	String Description	
	0.0.0.0	length : 0 .. 15 format : \d{1,3}\.\d{1,3}\.\d{1,3}\.\d{1,3}	

Command IfDvbs2BboeTxUdpPort		S2BBFoE tx UDP port	S2BBFoE tx UDP port
Location	/Modem/Control/Interfaces/Ethernet/IP termination/ntS2BBF over IP		
Description	Configuration of the UDP port number to which DVB-S2 baseband frames will be transmitted over the Ethernet interface.		
RMCP Command	btU	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfDvbs2BboeTxUdpPort	
	OID	1.3.6.1.4.1.5835.3.1.4.1.229.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	NA	NA	12345
		Expert Range (CU)	
		0 .. 65535	

Command IfDvbs2BbRxEncapsTimetick		Encapsulation timetick	Encapsulation timeti
Location	/Modem/Control/Interfaces/Ethernet/IP termination/ntS2BBF over IP		
Description	This timetick defines the periodic interval for the encapsulation of baseband frames.		
RMCP Command	brt	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfDvbs2BbRxEncapsTimetick	
	OID	1.3.6.1.4.1.5835.3.1.4.1.124.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	ms	ms	30
		Expert Range (CU)	
		5 .. 999	

Command IfDvbs2BbRxBuffHeadroomMs		Buffer headroom	Buffer headroom
Location	/Modem/Control/Interfaces/Ethernet/IP termination/ntS2BBF over IP		
Description	The ntS2BBF receiver sends periodically volume requests to an external encapsulator. To avoid that the modulator buffer would be empty, we try to make sure that we always have a given headroom of bytes in this buffer. This modulator buffer headroom can be configured in milliseconds.		
RMCP Command	brh	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfDvbs2BbRxBuffHeadroomMs	
	OID	1.3.6.1.4.1.5835.3.1.4.1.203.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	ms	ms	10
		Expert Range (CU)	
		0 .. 5000	

Command IfDvbs2BbRxAvgCodingComprWin		Avg coding comp window			
Location	/Modem/Control/Interfaces/Ethernet/IP termination/ntS2BBF over IP				
Description	This is the number of encapsulation periods over which we calculate the average coding compression. See also IfDvbs2BbRxAvgCodingComprWin				
RMCP Command	acw	Access	Normal user : no access Expert user : RW		
SNMP	Table	ntcDevsMod01InterfaceEntry			
	Command	ntcDevsMod01IfDvbs2BbRxAvgCodingComprWin			
	OID	1.3.6.1.4.1.5835.3.1.4.1.202.1.1			
Values	GUI Unit	Cmd Unit	Factory Default (CU)		
	periods	periods	5		
			1 .. 64		

/Modem/Control/Modulation

/Modem/Control/Modulation/Main

Command MoACMMode		DVB-S2 Coding and Modulation mode			
Location	/Modem/Control/Modulation/Main				
	Only valid for DVB-S2 modes except for Air(XPE).				
Description	Configuration of the DVB-S2 coding and modulation mode. <ul style="list-style-type: none"> CCM : Constant coding and modulation. VCM : Variable coding and modulation. : Adaptive coding and modulation. When the DVB-S2 baseband frames input format is selected, the modulator is operating in ACM mode or in VCM mode in case the input is coming from a single baseband source. In ACM mode, the transmitted frames can consist of different baseband sources (different input stream identifiers) and every frame can be transmitted with different parameters (modcod, pilots and frame type).For non-baseband frame input format, the modulator is operating in CCM mode. 				
RMCP Command	ACM		Access Normal user : RW Expert user : RW		
SNMP	Table	ntcDevsMod01ModulatorEntry			
	Command	ntcDevsMod01MoACMMode			
	OID	1.3.6.1.4.1.5835.3.1.3.1.55.1.1			
Values	Factory Default	Enumeration	Value		
	ccm	CCM VCM ACM	0 1 2		

Command MoFecMod2		FEC-rate and modulation	FEC-rate and mod.
Location	/Modem/Control/Modulation/Main		
Used as variable of	Command(s)		Page
	IfStrConfig		79
	Only for DVB-S2 mode except for Air(XPE) processing modes.		
Description	<p>Configuration of the FEC-rate and modulation. The selection of the FEC-rate and modulation are coupled and depend on the present modulation standard and capability of the device.</p> <p>Because the selection of a new FEC-rate and/or modulation type changes the symbol rate and thus the bandwidth of the signal, transmit is disabled. After verification of the occupied bandwidth, the operator has to re-enable transmit to go back on air.</p> <p>In DVB-S2 mode which supports dynamic changes of FEC-rate and/or modulation, transmit is only disabled when the symbol rate changes i.e. when the rate priority command is set to "interface rate".</p> <p>Remark: The selection of a FEC-rate and/or modulation type for which the present symbol rate is outside the allowed limits, will be indicated by an incompatibility alarm. Only those selections possible with the current device capability will be listed.</p>		
RMC Command	TMx		Access Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoFecMod2	
	OID	1.3.6.1.4.1.5835.3.1.3.1.11.1.1	
Values	Factory Default	Enumeration	Value
	qPSKModulationRate34	QPSK no FEC (SKYPLEX) QPSK-1/2 QPSK-2/3 QPSK-3/4 QPSK-5/6 QPSK-6/7 QPSK-7/8 QPSK-1/4 QPSK-1/3 QPSK-2/5 QPSK-3/5 QPSK-4/5 QPSK-8/9 QPSK-9/10 16APSK-2/3 16APSK-3/4 16APSK-4/5 16APSK-5/6 16APSK-8/9 16APSK-9/10 32APSK-3/4 32APSK-4/5 32APSK-5/6 32APSK-8/9 32APSK-9/10 16QAM-3/4 16QAM-7/8	10 11 12 13 15 16 17 21 22 23 24 25 26 27 42 43 44 45 48 49 53 54 55 58 59 63 67

Command MoFecMod2	FEC-rate and modulation	FEC-rate and mod.
	8PSK-3/5	81
	8PSK-2/3	82
	8PSK-3/4	83
	8PSK-5/6	85
	8PSK-8/9	88
	8PSK-9/10	89

Command MoPilots	Physical Layer Pilot insertion	Pilot insertion
Location	/Modem/Control/Modulation/Main	
Used as variable of	Command(s)	Page
	IfStrConfig	79
	Only valid for DVB-S2 modes and XPE modes.	
Description	<p>Configuration command to enable or disable the insertion of DVB-S2 physical layer pilots.</p> <p>When enabled, every 16 slots (of 90 symbols) the modulator will insert 36 non-modulated symbols to aid in receiver synchronisation. This parameter is the same parameter as the one that can be entered in the DVB-S2 stream table.</p> <p>Remark: This is a CCM command.</p>	
RMC Command	ACP	Access Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry
	Command	ntcDevsMod01MoPilots
	OID	1.3.6.1.4.1.5835.3.1.3.1.81.1.1
Values	Factory Default	Enumeration
	off	Off On
		Value 0 1

Command MoFrameType		DVB-S2 FEC-Frame type	FEC-Frame type
Location	/Modem/Control/Modulation/Main		
Used as variable of	Command(s)		Page
	IfStrConfig		79
	Only valid for DVB-S2 modes and XPE modes.		
Description	Configuration of the DVB-S2 FEC-frame type. Two FEC-frame types are defined: <ul style="list-style-type: none">• Normal FEC-frames of 64800 bits or 8100 bytes.• Short FEC-frames of 16200 bits or 2025 bytes. This command configures if short or normal length frames need to be created by the encapsulator. Remark: Short frames introduce more overhead but give a shorter encapsulation delay. Short frames are 4 times shorter than normal frames.		
RMCP Command	ACF	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoFrameType	
	OID	1.3.6.1.4.1.5835.3.1.3.1.69.1.1	
Values	Factory Default	Enumeration	Value
	short	Short Normal	0 1

Command MoInpRate		Interface bitrate	Interface bitrate
Location	/Modem/Control/Modulation/Main		
	Not applicable for Air (TS) (multistream) processing mode.		
Description	Configuration of the interface bitrate. This command configures the (de)modulator input bitrate at the baseband interface. The actual range depends on the installed hardware and software capability of the device.		
RMCP Command	TRr	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoInpRate	
	OID	1.3.6.1.4.1.5835.3.1.3.1.14.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Mbps	bps	8.294.118
			55000 .. 110000000

Command MoSymRate		Symbol rate	Symbol rate
Location	/Modem/Control/Modulation/Main		
Description	Configuration of the symbol rate. The actual range depends on installed hardware and software capability.		
RMCP Command	TRs	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoSymRate	
	OID	1.3.6.1.4.1.5835.3.1.3.1.32.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Mbaud	baud	6.000.000
		Expert Range (CU)	
		50000 .. 68000000	

Command MoOpOutputFreq		Operational output frequency	Output frequency
Location	/Modem/Control/Modulation/Main		
Description	Configuration of the operational output frequency in case of an active L-band output.		
RMCP Command	OOF	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoOpOutputFreq	
	OID	1.3.6.1.4.1.5835.3.1.3.1.38.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	MHz	Hz	1.450.000.000
		Expert Range (CU)	
		-1e+38 .. 1e+38	

Command MoOutputLevel		Output level	Output level
Location	/Modem/Control/Modulation/Main		
Description	Read out of the output level in dBm. The actual range is determined by the gain of the converter (which depends on operating frequency) and the gain of an optional amplifier. Remark: The displayed level can be affected by introducing a level offset (see MoOLevelOffset).		
RMCP Command	OOL array : [1 .. 2]	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoOutputLevel	
	OID	1.3.6.1.4.1.5835.3.1.3.1.29.1.1.[1 .. 2]	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	dBm	dBm	-15
		Expert Range (CU)	
		-35 to +5	

Command MoGainCtrlMode		Gain control mode			
Location	/Modem/Control/Modulation/Main				
Description	Configuration of the output level gain control mode. The modulator output level accuracy can be controlled statically in the fixed manual gain control mode or by using an automatic gain feedback control loop. In some communication systems with multiple overall automatic gain control, it might be necessary to set the output level of the modulator to manual gain control. The automatic gain control mode is used to keep level changes in output level caused by gain drift of the amplifier stages of the modulator (due to temperature changes or ageing) small.				
RMCP Command	Gcm	Access	Normal user : no access Expert user : RW		
SNMP	Table	ntcDevsMod01ModulatorEntry			
	Command	ntcDevsMod01MoGainCtrlMode			
	OID	1.3.6.1.4.1.5835.3.1.3.1.12.1.1			
Values	Factory Default	Enumeration	Value		
	agc	MGC AGC	0 1		

Command MoOutLevelPlan		Output Level Plan			
Location	/Modem/Control/Modulation/Main				
Description	Configuration of the output level plan. The modulator features two output level plans: <ul style="list-style-type: none">Constant power: In this plan is the output power kept equal for the different modcods. This is the default mode of operation.Constant rim: In this plan, the outer ring of the symbol constellation is kept equal for the different modcods. As a consequence different modcods will be transmitted with different output power. The constant rim mode is used for VCM/ACM demodulator operation with a saturated transponder. It avoids excessive input back-off for QPSK, 8PSK and 16APSK modcods during VCM/ACM operation. Due to the dynamic level changes, this mode is only possible with manual gain control. Since the highest outer ring level occurs for a modcod of 32APSK-3/4, this modcod is used as the reference for the output power level setting. The other modcods will be transmitted with higher power:				
RMCP Command	olp	Access	Normal user : no access Expert user : RW		
SNMP	Table	ntcDevsMod01ModulatorEntry			
	Command	ntcDevsMod01MoOutLevelPlan			
	OID	1.3.6.1.4.1.5835.3.1.3.1.99.1.1			
Values	Factory Default	Enumeration	Value		
	const_Power	Const. Pwr Const. Rim	0 1		

Command	TX suppression on demod unlock	TX suppression on de	
Location	<code>/UnitFunction/Control/Modulation/Main</code>		
Description	<p>Use this command to decide if the transmission must continue during demod unlock or if it must be suppressed.</p> <p>Disabled: The modem keeps transmitting during a demod unlock. This option is used when the remote station is attended.</p> <p>Enabled: The modem stops transmitting during demod unlock. This option is used for example in a maritime network)</p>		
RMCP Command	tsd	Access Normal user : RW Expert user : RW	
SNMP	Table ntcDevsMod01ModulatorEntry Command ntcDevsMod01MoSuppressionByDemodUnlock OID 1.3.6.1.4.1.5835.3.1.3.1.177.1.1		
Values	Factory Default disabled	Enumeration Disabled Enabled	Value 0 1

Command MoOutputEnable		Modulator board Tx	Modulator board Tx
Location	/Modem/Control/Modulation/Main		
Description	 Only applicable for L-band modulators.  Configuration command to enable or disable the modulator output signal. The transmission is switched-off upon detection of a general device alarm of the modulator board. The general device alarm is the result of a OR-function of the incompatibility, external 10 MHz reference, external 10 MHz reference PLL and synthesizer lock alarm. When the general device alarm is resolved, transmission is switched back on. The following commands which modify the transmitted signal and its spectrum disable the transmission: <ul style="list-style-type: none"> • interface rate, • symbol rate, • Roll-off Factor, • modulation standard • output frequency. After such a change, the operator has to inspect the generated signal and then re-enable the transmit to go on-air. The operator requested transmit control state can be saved in the default boot configuration stored in memory slot 0 so that after (accidental) reboot the saved transmitter state is activated. Always Enable: <ul style="list-style-type: none"> • This parameter is used to keep transmitting when changes are made to the commands mentioned above. • This command should only be used by a qualified operator who is fully capable and responsible for preventing unwanted transmissions. 		
RMCP Command	TTm	Access	Normal user : RW Expert user : RW
SNMP	Table ntcDevsMod01ModulatorEntry Command ntcDevsMod01MoOutputEnable OID 1.3.6.1.4.1.5835.3.1.3.1.28.1.1		
Values	Factory Default	Enumeration	Value
	disable	Disabled Enabled Always Enabled	0 1 2

Command MoCaMod		Carrier modulation	Carrier modulation
Location	/Modem/Control/Modulation/Main		
Description	Configuration command to control carrier modulation: <ul style="list-style-type: none"> • Pure carrier: Non-modulated output signal. • Modulation on: Operational modulated carrier signal. • Test modulation CLK/n: Carrier modulated by a rotating vector with a period of baudrate/n, results in a single spectral line at +CLK/n offset from carrier. This mode is used for calibration and verification 		

Command MoCaMod		Carrier modulation	
	of spectrum polarity.		
RMCP Command	TMm	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoCaMod	
	OID	1.3.6.1.4.1.5835.3.1.3.1.7.1.1	
Values	Factory Default	Enumeration	Value
	caModulationOn	Pure carrier On Clock/8 Clock/4 Clock/16	0 1 2 4 5

/Modem/Control/Modulation/DVB-S2 Streams

/Modem/Control/Modulation/DVB-S2 Streams/DVB-S2 Streams/

Structured Command IfStrConfig		DVB-S2 Streams			
Location	/Modem/Control/Modulation/DVB-S2 Streams				
Description	Configuration of the DVB-S2 streams used for Ethernet traffic. The command IfStrConfigStreamId must be used in the filter configuration and is equal to the array index. Several filters can belong to the same stream. A stream defines the DVB-S2 baseband frame parameters like: FEC-rate and modulation, ISI number, use of pilots and frame type. These settings are only applicable in DVB-S2 mode of the interface card (e.g. when using XPE encapsulation).				
RMCP Command	ISR array : [1 .. 35]		Access		
SNMP	Table	ntcDevsMod01InterfaceExtEntry			
	Command	ntcDevsMod01IfStrConfig			
	OID	1.3.6.1.4.1.5835.3.1.4000.1.7.1.1.[1 .. 35]			
Variables					
IfStrConfigStreamId	183				
IfStrConfigEnable	184				
MoFecMod2	72				
MoISI	82				
MoPilots	73				
MoFrameType	74				

/Modem/Control/Modulation/BasebandFraming



Only valid for DVB-S2 and single stream modes.

Command MoDFLMode	DVB-S2 DFL encapsulation mode	DFL mode	
Location	/Modem/Control/Modulation/BasebandFraming		
Description	<p>Configuration of the data field length mode. When operating with non-baseband frame input formats (i.e. a MPEG transport stream input or generic input streams) the raw input stream is encapsulated into DVB-S2 baseband frames. The payload size of these frames is referred to as data field length and the maximum possible data field length is determined by the selected frame type and modcod.</p> <p>Two data field length encapsulation modes are defined:</p> <ul style="list-style-type: none"> • Automatic: Upon selection of frame type and/or modcod, the data field length size is automatically set to the corresponding maximum payload size and the sync distance is set to 0. • Manual : Upon selection of frame type and/or modcod, the data field length size remains at the previous value of the baseband data field length (MoDFL) variable as long as this value is supported by the new frame type and modcod. In case the baseband data field length (MoDFL) variable exceeds the maximum payload size, the data field length value will be clipped to the maximum. Also the sync distance value will be kept or clipped. 		
RMCP Command	DFM array : [1 .. 2]	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoDFLMode	
	OID	1.3.6.1.4.1.5835.3.1.3.1.64.1.1.[1 .. 2]	
Values	Factory Default	Enumeration	Value
	auto	Auto Man	0 1

Command MoDFL		Rx Baseband DFL	Rx Baseband DFL
Location	/Modem/Control/Modulation/BasebandFraming		
Description	<p>Configuration of the data field length. This variable specifies the baseband data field length size (in bytes) for encapsulation of user data into DVB-S2 baseband frames.</p> <p>When a modulator is operating with non-baseband frame input formats (i.e. a MPEG transport stream input or generic input streams), the raw input stream is encapsulated into DVB-S2 baseband frames. The payload size of these frames is referred to as data field length and the maximum possible data field length is determined by the selected frame type and modcod.</p> <p>Remark: This variable is only applicable for non-baseband frame input formats.</p> <p>In case of a demodulator, the data field length value is read-only and is determined via baseband header info.</p>		
RMCP Command	DFL array : [1 .. 2]	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoDFL	
	OID	1.3.6.1.4.1.5835.3.1.3.1.63.1.1.[1 .. 2]	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	bytes	bytes	376
		Expert Range (CU)	
		0 .. 8191	

Command MoSYNCD		Baseband Sync distance	Sync distance
Location	/Modem/Control/Modulation/BasebandFraming		
Description	<p>Configuration of the baseband sync distance (in bytes) which specifies the initial position within the baseband frame of the sync marker. In case the data field length is an integer multiple of the user packet length, this position will be maintained over all baseband frames.</p> <p>Remark: This command is only applicable for non-baseband frame input stream formats.</p>		
RMCP Command	SCD	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoSYNCD	
	OID	1.3.6.1.4.1.5835.3.1.3.1.82.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	bytes	bytes	0
		Expert Range (CU)	
		0 .. 8191	

Command MoISI		Input Stream Identifier	ISI
Location	/Modem/Control/Modulation/BasebandFraming		
Used as variable of	Command(s)		Page
	IfStrConfig		79
Description	<p>Configuration of the DVB-S2 input stream identifier or ISI which is present in the second byte position of the MATYPE field in the baseband header of a DVB-S2 baseband frame. It is a single byte identifying the encapsulated stream in case of multiple input streams. When the modulator input format consists of baseband frames, this value is used for filtering the matching stream for dedicated processing like network clock reference insertion or monitoring.</p> <p>In all other cases (e.g. a MPEG transport stream or generic stream inputs), this input stream identifier value is filled-in in the MATYPE field of the generated baseband frames.</p> <p>Remark: On a demodulator interface the input stream identifier values are used for filtering the matching stream and determining the output interface.</p>		
RMCP Command	ISI array : [1 .. 2]		Access Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoISI	
	OID	1.3.6.1.4.1.5835.3.1.3.1.70.1.1.[1 .. 2]	
Values	Factory Default	String Description	
	AB	length : 2 (fixed) format : Hexadecimal chars	

/Modem/Control/Modulation/ACM control

Command MoAcmCtrlEnable		ACM Ctrl	ACM Ctrl
Location	/Modem/Control/Modulation/ACM control		
Description	Configuration command to enable or disable the ACM controller.		
RMCP Command	ace		Access Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoAcmCtrlEnable	
	OID	1.3.6.1.4.1.5835.3.1.3.1.120.1.1	
Values	Factory Default	Enumeration	Value
	disabled	Disabled Enabled	0 1

Command MoAcmCtrlMinModcod		MIN Modcod	MIN Modcod
Location	/Modem/Control/Modulation/ACM control		
Description	Configuration of the lowest modcod that can be used by the ACM controller. This field is used to avoid the use of some modcods that may not be supported by the attached demodulators.		
RMCPE Command	ami	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoAcmCtrlMinModcod	
	OID	1.3.6.1.4.1.5835.3.1.3.1.122.1.1	
Values	Factory Default	Enumeration	Value
	qPSKModulationRate14	QPSK no FEC (SKYPLEX) QPSK-1/2 QPSK-2/3 QPSK-3/4 QPSK-5/6 QPSK-6/7 QPSK-7/8 QPSK-1/4 QPSK-1/3 QPSK-2/5 QPSK-3/5 QPSK-4/5 QPSK-8/9 QPSK-9/10 16APSK-2/3 16APSK-3/4 16APSK-4/5 16APSK-5/6 16APSK-8/9 16APSK-9/10 32APSK-3/4 32APSK-4/5 32APSK-5/6 32APSK-8/9 32APSK-9/10 16QAM-3/4 16QAM-7/8 8PSK-3/5 8PSK-2/3 8PSK-3/4 8PSK-5/6 8PSK-8/9 8PSK-9/10	10 11 12 13 15 16 17 21 22 23 24 25 26 27 42 43 44 45 48 49 53 54 55 58 59 63 67 81 82 83 85 88 89

Command MoAcmCtrlMaxModcod		MAX Modcod	
Location	/Modem/Control/Modulation/ACM control		
RMCP Command	amm	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoAcmCtrlMaxModcod	
	OID	1.3.6.1.4.1.5835.3.1.3.1.121.1.1	
Values	Factory Default	Enumeration	Value
x32APSKModulationRate910		QPSK no FEC (SKYPLEX) 10 QPSK-1/2 11 QPSK-2/3 12 QPSK-3/4 13 QPSK-5/6 15 QPSK-6/7 16 QPSK-7/8 17 QPSK-1/4 21 QPSK-1/3 22 QPSK-2/5 23 QPSK-3/5 24 QPSK-4/5 25 QPSK-8/9 26 QPSK-9/10 27 16APSK-2/3 42 16APSK-3/4 43 16APSK-4/5 44 16APSK-5/6 45 16APSK-8/9 48 16APSK-9/10 49 32APSK-3/4 53 32APSK-4/5 54 32APSK-5/6 55 32APSK-8/9 58 32APSK-9/10 59 16QAM-3/4 63 16QAM-7/8 67 8PSK-3/5 81 8PSK-2/3 82 8PSK-3/4 83 8PSK-5/6 85 8PSK-8/9 88 8PSK-9/10 89	

Command MoAcmCtrlCommFailModcod		Comm failure Modcod	Comm failure Modcod
Location	/Modem/Control/Modulation/ACM control		
Description	Configuration of the modcod that needs to be selected when the communication with the demodulator fails.		
RMCP Command	cfm	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoAcmCtrlCommFailModcod	
	OID	1.3.6.1.4.1.5835.3.1.3.1.119.1.1	
Values	Factory Default	Enumeration	Value
	lowestModcod	lowestModcod QPSK no FEC (SKYPLEX) QPSK-1/2 QPSK-2/3 QPSK-3/4 QPSK-5/6 QPSK-6/7 QPSK-7/8 QPSK-1/4 QPSK-1/3 QPSK-2/5 QPSK-3/5 QPSK-4/5 QPSK-8/9 QPSK-9/10 16APSK-2/3 16APSK-3/4 16APSK-4/5 16APSK-5/6 16APSK-8/9 16APSK-9/10 32APSK-3/4 32APSK-4/5 32APSK-5/6 32APSK-8/9 32APSK-9/10 16QAM-3/4 16QAM-7/8 8PSK-3/5 8PSK-2/3 8PSK-3/4 8PSK-5/6 8PSK-8/9 8PSK-9/10	0 10 11 12 13 15 16 17 21 22 23 24 25 26 27 42 43 44 45 48 49 53 54 55 58 59 63 67 81 82 83 85 88 89

Command MoAcmCtrlMinMargSpec		Min margin			
Location	/Modem/Control/Modulation/ACM control				
Description	Configuration of the margin specification for the ACM controller before going to a lower modcod. Different margin specifications for different modcods can be specified in the following way: 1-10:0.50 11-28:1.0 which means that for modcods 1 to 10 a difference of 0.5 dB is needed between the theoretical Es/No for a given modcod and the measured Es/No before changing the current modcod, for modcods 11 to 28 a difference of 1 dB is necessary.				
RMCP Command	mms	Access	Normal user : no access Expert user : RW		
SNMP	Table	ntcDevsMod01ModulatorEntry			
	Command	ntcDevsMod01MoAcmCtrlMinMargSpec			
	OID	1.3.6.1.4.1.5835.3.1.3.1.136.1.1			
Values	Factory Default	String Description			
		length : 0 .. 30 format : any chars			

Command MoAcmCtrlTgtMargSpec		Tgt margin			
Location	/Modem/Control/Modulation/ACM control				
Description	Configuration of the margin specification for the ACM controller before going to a higher modcod. Different margin specifications for different modcods can be specified in the following way: 1-10:0.50 11-28:1.0 which means that for modcods 1 to 10 a difference of 0.5 dB is needed between the theoretical Es/No for a given modcod and the measured Es/No before changing the current modcod, for modcods 11 to 28 a difference of 1 dB is necessary.				
RMCP Command	tms	Access	Normal user : no access Expert user : RW		
SNMP	Table	ntcDevsMod01ModulatorEntry			
	Command	ntcDevsMod01MoAcmCtrlTgtMargSpec			
	OID	1.3.6.1.4.1.5835.3.1.3.1.137.1.1			
Values	Factory Default	String Description			
		length : 0 .. 30 format : any chars			

Command MoAcmCtrlDistortSpec		Distortion			
Location	/Modem/Control/Modulation/ACM control				
Description	Configuration of the distortion specification for the ACM controller.				
RMCP Command	Dst	Access	Normal user : no access Expert user : RW		
SNMP	Table	ntcDevsMod01ModulatorEntry			
	Command	ntcDevsMod01MoAcmCtrlDistortSpec			

Command MoAcmCtrlDistortSpec		Distortion	Distortion
	OID	1.3.6.1.4.1.5835.3.1.3.1.135.1.1	
Values	Factory Default	String Description	
		length : 0 .. 30 format : any chars	

Command MoAcmCtrlMonitorOnly		ACM monitoring only	ACM monitoring only
Location	/Modem/Control/Modulation/ACM control		
Description	Configuration command to enable a special ACM monitoring mode. When this field is enabled, the ACM controller will only monitor the system and not actually change the modcod. This is useful to simulate the real behaviour.		
RMC Command	amo	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoAcmCtrlMonitorOnly	
	OID	1.3.6.1.4.1.5835.3.1.3.1.123.1.1	
Values	Factory Default	Enumeration	Value
	disabled	Disabled Enabled	0 1

Command MoAcmFwSigPlane		ACM fw sig plane	ACM fw sig plane
Location	/Modem/Control/Modulation/ACM control		
Description	Select control plane for ACM controller forward signalling: • MonCon management IP network • Inband RF channel		
RMC Command	afp	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoAcmFwSigPlane	
	OID	1.3.6.1.4.1.5835.3.1.3.1.157.1.1	
Values	Factory Default	Enumeration	Value
	moncon_ip	Moncon IP mngrt LAN Inband RF	0 1

/Modem/Control/Modulation/ACM control/Demod table

Structured Command MoAcmDmSupvEntry		ACM demodulator supervision table	Demod table
Location	/Modem/Control/Modulation/ACM control/Demod table		
Description	Configuration of the demodulator supervision parameters for the ACM controller. The demodulator supervision parameters provides the mapping between modulator and demodulator based on the demodulator IP address and the DVB-S2 stream identifier.		
RMC Command	dse array : [1 .. 32]	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoAcmDmSupvEntry	
	OID	1.3.6.1.4.1.5835.3.1.3.1.131.1.1.[1 .. 32]	
Variables			Page
MoAcmDmSupvIp MoAcmDmSupvStrid			197 197

/Modem/Control/Modulation/PHY

Only valid for DVB-S2.

Command MoPLSSignature		Physical Layer Scrambler signature	PLS signature
Location	/Modem/Control/Modulation/PHY		
Description	Configuration of the physical layer scrambler that scrambles all of the physical layer frames except for their header parts. The sequence is reset at the start of the frame body. The physical layer scrambler signature assumes values in the range 0 and 262141. In case of broadcasting services, the default PLS signature (value = 0) shall be used to avoid manual receiver setting or synchronisation delays.		
RMC Command	PSS	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoPLSSignature	
	OID	1.3.6.1.4.1.5835.3.1.3.1.77.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	NA	NA	0 .. 262141

Command MoSpectInv		Tx spectrum inversion	Tx spectrum inversion
Location	/Modem/Control/Modulation/PHY		
Description	<p>Configuration command to enable or disable spectrum inversion. The spectrum at IFL and at RF is coupled by the installed up-converter module and can be deduced from the frequency conversion formula. If the L-band frequency is subtracted from the local oscillator frequency, the spectrum is inverted in the converter module. If in this case the direct spectrum is required, the spectrum must also be inverted at IFL.</p> <p>Remark: The direct spectrum is conform with NTELSAT specification IESS-308 (Rev.8 - pages 18 & 69) and with the DVB standard ETS 300 421 (December 1994).</p>		
RMCP Command	TMi array : [1 .. 2]	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoSpectInv	
	OID	1.3.6.1.4.1.5835.3.1.3.1.40.1.1.[1 .. 2]	
Values	Factory Default	Enumeration	Value
	directSpectrum	Direct Inverted	1 2

Command MoLinPredMode		Linear predistortion	Linear predistortion
Location	/Modem/Control/Modulation/PHY		
	This predistortion feature is optional and password upgradeable.		
Description	<p>Configuration command that enables or disables the linear pre-distortion filter. The purpose of linear pre-distortion is to compensate for transponder amplitude and group-delay distortions. This becomes especially important when operating at high baudrates and higher order modulation formats. The pre-distortion filter coefficients must be calculated off-line and require transponder amplitude and group-delay characteristics as input. The resulting coefficient data can be uploaded via the MoWaffirCoef command.</p>		
RMCP Command	LPM	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoLinPredMode	
	OID	1.3.6.1.4.1.5835.3.1.3.1.98.1.1	
Values	Factory Default	Enumeration	Value
	disable	Disabled Enabled	0 1

Command MoNonLinPredMode		Nonlinear predistortion	Nonlinear pred
Location	/Modem/Control/Modulation/PHY		
	This predistortion feature is optional and password upgradeable.		
Description	<p>Configuration command to enable or disable the non-linear pre-distortion function. Non-linear pre-distortion can substantially improve the overall performance of the satellite link. The pre-distortion function compensates for the am/am and am/pm effects caused by driving the satellite transponder close to saturation. Hence it is clear that the pre-distortion itself depends on the actual transponder being used and the operating point (= nominal transmit level).</p> <p>The pre-distortion data must be calculated off-line and requires transponder m/am and am/pm characteristics and operating level as input.</p> <p>Remark: Pre-distortion data also depends on the modulation format (QPSK,8PSK,16APSK,32APSK) and on the actual constellation; i.e. different APSK modcods having different amplitude ring-ratios. Therefore, for handling ACM operation with dynamically varying modcods, the off-line calculation tool will calculate a set of data-tables which can be uploaded to the modulator and stored in internal flash. For each symbol to be transmitted, the modulator performs an amplitude and phase correction on the symbol. The value "L" specifies the length of the symbol history (number of symbols)</p> <p>taken into account for correcting each transmit symbol :</p> <ul style="list-style-type: none"> • L = 1: Static pre-distortion, uses only the current symbol. • L = 3: Dynamic pre-distortion using the current, previous and next symbols. • L = 5: Dynamic pre-distortion using the current, two previous and two next symbols. The Modulator implementation can handle CCM/VCM/ACM modes with the following L-values : • L = 5 for QPSK and 8PSK modulation formats. • L = 3 for 16APSK and 32APSK modulation formats. 		
RMC Command	NPm	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoNonLinPredMode	
	OID	1.3.6.1.4.1.5835.3.1.3.1.102.1.1	
Values	Factory Default	Enumeration	Value
	disable	Disabled Enabled	0 1

Command MoAmplEq		Amplitude slope equaliser		Slope equaliser		
Location	/Modem/Control/Modulation/PHY					
Description	Configuration of the amplitude slope equaliser. An amplitude slope in the up-converter or in the high power amplifier can be compensated by using this equaliser which has a maximum range of ± 2 dB/50 MHz. This is done by changing the corresponding control parameter in steps of one unit in the range of ± 7 units.					
RMCp Command	TLe	Access		Normal user : no access Expert user : RW		
SNMP	Table	ntcDevsMod01ModulatorEntry				
	Command	ntcDevsMod01MoAmplEq				
	OID	1.3.6.1.4.1.5835.3.1.3.1.1				
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	units	units	0	-7 .. 7		

Command MoExcBw		Roll-off factor		Roll-off factor		
Location	/Modem/Control/Modulation/PHY					
Description	Configuration of the roll-off factor. The excess bandwidth defines the root cosine roll-off factor for the matched filter at the modulator output. Remark: A change of the excess bandwidth disables transmit.					
RMCp Command	TFr		Access	Normal user : RW Expert user : RW		
SNMP	Table	ntcDevsMod01ModulatorEntry				
	Command	ntcDevsMod01MoExcBw				
	OID	1.3.6.1.4.1.5835.3.1.3.1.9.1.1				
Values	Factory Default		Enumeration	Value		
	x25RCRO		35% 25% 20%	1 2 3		

Command MoMonOutputMode		Monitoring output mode	Monitor output mode
Location	/Modem/Control/Modulation/PHY		
Description	Configuration of the monitoring output functional mode. <ul style="list-style-type: none"> Always on: The monitor output signal is continuously active irrespective of the operational output status. Follow Tx: The monitor output status follows the operational output status. When transmit is off, the monitor output will also be disabled. 		
RMCp Command	MOM		Access Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	

Command MoMonOutputMode		Monitoring output mode	Monitor output mode
Values	Command	ntcDevsMod01MoMonOutputMode	
	OID	1.3.6.1.4.1.5835.3.1.3.1.52.1.1	
Factory Default	Enumeration	Value	
always_on	Always on Follow Tx	0 1	

Command MoOccBw		Occupied bandwidth	Occupied bandwidth
Location	/Modem/Control/Modulation/PHY		
Description	Readout of the occupied bandwidth or readout of the -26 dB bandwidth of the signal. This is calculated as the symbol rate multiplied with (1 + a) with a = the selected roll-off factor.		
RMCP Command	Tfb	Access	
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoOccBw	
	OID	1.3.6.1.4.1.5835.3.1.3.1.25.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	MHz	Hz	8.100.000
	Expert Range (CU)		
1000 .. 999999999			

Modem/Control/ODU

Command ODPow		Outdoor power supply	Outdoor power supply
Location	/Unit/Control/ODU		
Description	Configuration command to enable or disable the outdoor power supply as delivered by the outdoor unity and LNB controller unit.		
RMCP Command	ODp		Access
SNMP	Table	ntcDevsMod01ODUEntry	
	Command	ntcDevsMod01ODPPow	
	OID	1.3.6.1.4.1.5835.3.1.14.1.14.1.1	
Values	Factory Default	Enumeration	Value
	disabled	Disabled Enabled	0 1

/Modem/Control/Modulation/AES

Command MoAESEncryptionCtrl		Global Encryption	Global Encryption
Location	/Modem/Control/Modulation/AES		
Description	Used to select if the Global Encryption key is used for all ISI or ISI specific encryption settings are used. <ul style="list-style-type: none"> • global: AES encryption enabled with global key (one key for all streams) • isi : AES encryption enabled with individual keys for each stream ISI 		
RMC Command	mMc	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoAESEncryptionCtrl	
	OID	1.3.6.1.4.1.5835.3.1.3.1.164.1.1	
Values	Factory Default	Enumeration	Value
	global	Global Isi	0 1

Command MoAESEnableEncGlobal		Encryption Global	Encryption Global
Location	/Modem/Control/Modulation/AES/Global		
Description	This method is used to enable/disable Global AES encryption/decryption. If encryption is disabled, then the Global key is disabled (ignored) If encryption is enabled, then the encryption is via the global settings.		
RMC Command	mMg	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoAESEnableEncGlobal	
	OID	1.3.6.1.4.1.5835.3.1.3.1.161.1.1	
Values	Factory Default	Enumeration	Value
	off	Off On	0 1

Command MoAESKeyParityGlob		Global Key Parity			
Location	/Modem/Control/Modulation/AES/Global				
Description	This variable is used for the Global key parity selection (odd/even) for each ISI <ul style="list-style-type: none"> • odd: use Odd key • even: use Even key 				
RMCP Command	mGp		Access		
			Normal user : RW Expert user : RW		
SNMP	Table	ntcDevsMod01ModulatorEntry			
	Command	ntcDevsMod01MoAESKeyParityGlob			
	OID	1.3.6.1.4.1.5835.3.1.3.1.166.1.1			
Values	Factory Default	Enumeration	Value		
	odd	Odd Even	0 1		

Command MoAESEncEvenGlobalKey		Global Encrypted Even Key	Global Encrypted Even Key
Location	/Modem/Control/Modulation/AES/Global		
Description	This is the Global EVEN encrypted key entered by the user and decrypted with the group key. The key can be either 64bits or 128bits long, depending on the key length setting. If 64bit length is selected then the key has to be encrypted using DES. If 128bit length is selected then the key has to be encrypted using AES. The key is a hexadecimal key. <ul style="list-style-type: none"> • 64bits - 8 bytes (16 bytes text string) • 128bits - 16 bytes (32 bytes text string) 		
RMCP Command	mGe		Access
			Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoAESEncEvenGlobalKey	
	OID	1.3.6.1.4.1.5835.3.1.3.1.162.1.1	
Values	Factory Default	String Description	
	FFFFFFFFFFFF	length : 0 .. 32 format : Hexadecimal chars	

Command MoAESEncOddGlobalKey		Global Encrypted Odd Key	Global Encrypted Odd
Location	/Modem/Control/Modulation/AES/Global		
Description	<p>This is the Global ODD encrypted key entered by the user and decrypted with the group key. The key can be either 64bits or 128bits long, depending on the key length setting. If 64bit length is selected then the key has to be encrypted using DES. If 128bit length is selected then the key has to be encrypted using AES.</p> <p>The key is a hexadecimal key.</p> <ul style="list-style-type: none"> • 64bits - 8 bytes (16 bytes text string) • 128bits - 16 bytes (32 bytes text string) 		
RMCP Command	mGo		Access Normal user : RW Expert user : RW
SNMP	Table ntcDevsMod01ModulatorEntry Command ntcDevsMod01MoAESEncOddGlobalKey OID 1.3.6.1.4.1.5835.3.1.3.1.163.1.1		
Values	Factory Default FFFFFFFFFFFFFF String Description length : 0 .. 32 FFFFFFFFFFFFFF format : Hexadecimal chars FFFF		

Command MoAESEvenGlobalKey		Global Even Key	Global Even Key
Location	/Modem/Control/Modulation/AES/Global		
Description	<p>This is the AES Global EVEN key (non-encrypted) entered by the user. This can be either 64bits or 128bits long, depending on the key length setting. The value is entered as a hexadecimal value:</p> <ul style="list-style-type: none"> • 64 bits - 8 bytes (16 text bytes) • 128 bits - 16 bytes (32 text bytes) 		
RMCP Command	mGE		Access Normal user : RW Expert user : RW
SNMP	Table ntcDevsMod01ModulatorEntry Command ntcDevsMod01MoAESEvenGlobalKey OID 1.3.6.1.4.1.5835.3.1.3.1.165.1.1		
Values	Factory Default FFFFFFFFFFFFFF String Description length : 0 .. 32 FFFFFFFFFFFFFF format : Hexadecimal chars FFFF		

Command MoAESOddGlobalKey		Global Odd Key			
Location	/Modem/Control/Modulation/AES/Global				
Description	This is the AES Global ODD key (non-encrypted) entered by the user. This can be either 64bits or 128bits long, depending on the key length setting. The value is entered as a hexadecimal value: <ul style="list-style-type: none"> • 64 bits - 8 bytes (16 text bytes) • 128 bits - 16 bytes (32 text bytes) 				
RMCP Command	mGO		Access		
	<i>Table</i>		ntcDevsMod01ModulatorEntry		
	<i>Command</i>		ntcDevsMod01MoAESOddGlobalKey		
Values	<i>OID</i>		1.3.6.1.4.1.5835.3.1.3.1.167.1.1		
	<i>Factory Default</i>	<i>String Description</i>			
	FFFFFFFFFFFFFF	length : 0 .. 32			
	FFFFFFFFFFFFFF	format : Hexadecimal chars			
FFFF					

Command MoAESEnableEncISI		Encryption Id			
Location	/Modem/Control/Modulation/AES/Keys 1-4				
Description	This method is used to enable/disable AES encryption per KeyId/ISI 0 - Encryption on ISI is disable. 1 - Encryption on ISI is enabled.				
RMCP Command	mEi array : [1 .. 4]		Access		
	<i>Table</i>		ntcDevsMod01ModulatorExtEntry		
	<i>Command</i>		ntcDevsMod01MoAESEnableEncISI		
Values	<i>OID</i>		1.3.6.1.4.1.5835.3.1.3000.1.11.1.1.[1 .. 4]		
	<i>Factory Default</i>	<i>Enumeration</i>	<i>Value</i>		
	off	Off	0		
		On	1		

Command MoAESKeyISI		ISI for Key Id			
Location	/Modem/Control/Modulation/AES/Keys 1-4				
Description	This method is used to set/map the ISI to a encryption/decryption key. Duplication of ISI to another key is invalid. Range of value is: 0 to 255. Default: 255				
RMCP Command	mei array : [1 .. 4]		Access		
	<i>Table</i>		ntcDevsMod01ModulatorExtEntry		
	<i>Command</i>		ntcDevsMod01MoAESKeyISI		
<i>OID</i>	1.3.6.1.4.1.5835.3.1.3000.1.15.1.1.[1 .. 4]				

Command MoAESKeyISI		ISI for Key Id	ISI for Key Id
Values	Factory Default	String Description	
	FF	length : 0 .. 2 format : Hexadecimal chars	

Command MoAESKeyParityISI		Key Parity Id	Key Parity Id
Location	/Modem/Control/Modulation/AES/Keys 1-4		
Description	This variable is used for the key parity selection (odd/even) for each ISI <ul style="list-style-type: none"> • odd: use Odd key • even: use Even key 		
RMCP Command	mKp array : [1 .. 4]		Access Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorExtEntry	
	Command	ntcDevsMod01MoAESKeyParityISI	
	OID	1.3.6.1.4.1.5835.3.1.3000.1.16.1.1.[1 .. 4]	
Values	Factory Default	Enumeration	Value
	odd	Odd Even	0 1

Command MoAESEncEvenKeyISI		Encrypted Even Key	Encrypted Even Key %
Location	/Modem/Control/Modulation/AES/Keys 1-4		
Description	This is the EVEN encrypted key entered by the user and decrypted with the group key. The key can be either 64bits or 128bits long, depending on the key length setting. If 64bit length is selected then the key has to be encrypted using DES. If 128bit length is selected then the key has to be encrypted using AES. The key is a hexadecimal key. <ul style="list-style-type: none"> • 64bits - 8 bytes (16 bytes text string) • 128bits - 16 bytes (32 bytes text string) 		
RMCP Command	mek array : [1 .. 4]		Access Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorExtEntry	
	Command	ntcDevsMod01MoAESEncEvenKeyISI	
	OID	1.3.6.1.4.1.5835.3.1.3000.1.12.1.1.[1 .. 4]	
Values	Factory Default	String Description	
	FFFFFFFFFFFFFFFFFF FFFFFFFFFFFFFFFFFF FFFF	length : 0 .. 32 format : Hexadecimal chars	

Command MoAESEncOddKeyISI		Encrypted Odd Key	Encrypted Odd Key
Location	/Modem/Control/Modulation/AES/Keys 1-4		
Description	<p>This is the ODD encrypted key entered by the user and decrypted with the group key. The key can be either 64bits or 128bits long, depending on the key length setting. If 64bit length is selected then the key has to be encrypted using DES. If 128bit length is selected then the key has to be encrypted using AES. The key is a hexadecimal key.</p> <ul style="list-style-type: none"> • 64bits - 8 bytes (16 bytes text string) • 128bits - 16 bytes (32 bytes text string) 		
RMCP Command	mok array : [1 .. 4]		Access Normal user : RW Expert user : RW
SNMP	Table ntcDevsMod01ModulatorExtEntry Command ntcDevsMod01MoAESEncOddKeyISI OID 1.3.6.1.4.1.5835.3.1.3000.1.13.1.1.[1 .. 4]		
Values	Factory Default	String Description FFFFFFFFFFFFFFFF FFFFFFFFFFFFFFFF FFFF	
Command MoAESEvenKeyISI		Even Key	Even Key
Location	/Modem/Control/Modulation/AES/Keys 1-4		
Description	<p>This is the AES EVEN key (non-encrypted) entered by the user. This can be either 64bits or 128bits long, depending on the key length setting. The value is entered as a hexadecimal value:</p> <ul style="list-style-type: none"> • 64 bits - 8 bytes (16 text bytes) • 128 bits - 16 bytes (32 text bytes) 		
RMCP Command	mEk array : [1 .. 4]		Access Normal user : RW Expert user : RW
SNMP	Table ntcDevsMod01ModulatorExtEntry Command ntcDevsMod01MoAESEvenKeyISI OID 1.3.6.1.4.1.5835.3.1.3000.1.14.1.1.[1 .. 4]		
Values	Factory Default	String Description FFFFFFFFFFFFFFFF FFFFFFFFFFFFFFFF FFFF	

Command MoAESEvenKeyISI		Even Key	Even Key
Location	/Modem/Control/Modulation/AES/Keys 1-4		
Description	<p>This is the AES EVEN key (non-encrypted) entered by the user. This can be either 64bits or 128bits long, depending on the key length setting. The value is entered as a hexadecimal value:</p> <ul style="list-style-type: none"> • 64 bits - 8 bytes (16 text bytes) • 128 bits - 16 bytes (32 text bytes) 		
RMCP Command	mEk array : [1 .. 4]		Access Normal user : RW Expert user : RW
SNMP	Table ntcDevsMod01ModulatorExtEntry Command ntcDevsMod01MoAESEvenKeyISI OID 1.3.6.1.4.1.5835.3.1.3000.1.14.1.1.[1 .. 4]		
Values	Factory Default	String Description FFFFFFFFFFFFFFFF FFFFFFFFFFFFFFFF FFFF	

Command MoAESOddKeyISI		Odd Key	Odd Key
Location	/Modem/Control/Modulation/AES/Keys 1-4		
Description	<p>This is the AES ODD key (non-encrypted) entered by the user. This can be either 64bits or 128bits long, depending on the key length setting. The value is entered as a hexadecimal value:</p> <ul style="list-style-type: none"> • 64 bits - 8 bytes (16 text bytes) • 128 bits - 16 bytes (32 text bytes) 		
RMCP Command	mOk array : [1 .. 4]	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorExtEntry	
	Command	ntcDevsMod01MoAESOddKeyISI	
	OID	1.3.6.1.4.1.5835.3.1.3000.1.17.1.1.[1 .. 4]	
Values	Factory Default	String Description	
	FFFFFFFFFFFFFF	length : 0 .. 32 format : Hexadecimal chars	

/Modem/Control/Demodulation

Command DmACMMode		DVB-S2 Coding and Modulation mode	DVB-S2 mode
Location	/Modem/Control/Demodulation		
Description	<p>Configuration of the DVB-S2 coding and modulation mode.</p> <p>The DVB-S2 standard defines adaptive coding and modulation (ACM) and constant coding and modulation (CCM). The modulation parameters in ACM and CCM mode are:</p> <ul style="list-style-type: none"> • Modcod: Definition which coding and modulation is used. • Pilot insertion: Presence or not of pilots in the physical layer frame. • Frame type: Short frames (2025 bytes) or normal frames (8100 bytes). • Definition CCM: Constant coding and modulation parameters are fixed for all input streams (components). The user can change the settings of these parameters. • Definition auto-CCM: CCM mode with auto detection of the parameters. The adaptable parameters are part of the received physical layer frame that way the user can not change any of these parameters. Best practise is to set the demodulator in auto-CCM mode. In this mode, the demodulator will extract the demodulation parameters (modcod, pilots and frame type) from the incoming stream. The demodulator board will look at the physical layer header of the first received DVB-S2 baseband frame to extract the demodulation parameters. It will use those parameters for all other received DVB-S2 baseband frames. In CCM mode, the user has to tell the demodulator manually what demodulation parameters to use. • Definition ACM: Adaptive coding and modulation parameters can vary on a frame by frame basis (even for a single component). The adaptable parameters are part of the received physical layer frame. This way the user can not change any of these parameters. ACM is needed to handle the discontinuous data stream. The modulator board receives DVB-S2 baseband frames from the gigabit Ethernet 		

Command DmACMMode		DVB-S2 Coding and Modulation mode		DVB-S2 mode
		interface board. If the encapsulator does not generate enough DVB-S2 baseband frames, the modulator board will stuff the stream with dummy physical layer frames.		
RMCP Command	ACm		Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01DemodulatorEntry		
	Command	ntcDevsMod01DmACMMode		
	OID	1.3.6.1.4.1.5835.3.1.13.1.40.1.1		
Values	Factory Default		Enumeration	Value
	ccm		CCM Auto-CCM ACM	0 1 2

Command DmlInput		Input selection	Input selection
Location	/Modem/Control/Demodulation		
Description	Configuration of the demodulator input. It specifies which input signal, IFL 1 ,IFL 2 or IF is passed to the demodulator.		
RMCP Command	XBs		Access
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmlInput	
	OID	1.3.6.1.4.1.5835.3.1.13.1.13.1.1	
Values	Factory Default		Value
	ifl1in		IFL 1 in IFL 2 in IF in

Command CvRxRfFreq		Receive frequency	Receive frequency
Location	/Modem/Control/Demodulation		
Description	Configuration of the RF input frequency of the converter between 950 and 2150 MHz.		
RMCP Command	RFf	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01ConverterEntry	
	Command	ntcDevsMod01CvRxRfFreq	
	OID	1.3.6.1.4.1.5835.3.1.7.1.12.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	MHz	Hz	1.170000 950000000 .. 2150000000

Command DmIntRate		Interface rate		Interface rate		
Location	/Modem/Control/Demodulation					
Description	Configuration of the nominal interface rate. When automatic detection (ACM or auto-CCM) of FEC and modulation mode is enabled, the operator can only enter a specific symbol rate while the interface rate will indicate auto. In DVB-DSNG mode, this parameter is always manually adaptable.					
RMCP Command	RRr	Access		Normal user : RW Expert user : RW		
SNMP	Table	ntcDevsMod01DemodulatorEntry				
	Command	ntcDevsMod01DmIntRate				
	OID	1.3.6.1.4.1.5835.3.1.13.1.14.1.1				
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Mbps	bps	33.000000	1290000 .. 110000000		

Command DmSynRate		Symbol rate	Symbol rate
Location	/Modem/Control/Demodulation		
Description	Configuration of the nominal symbol rate. The actual possible range depends on the hardware installed and can be limited by a software capability key.		
RMCP Command	RRs	Access	
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmSynRate	
	OID	1.3.6.1.4.1.5835.3.1.13.1.25.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Mbaud	baud	27.500000
			-1e+38 .. 1e+38

Command DmAcqRan		Acquisition range (ptp)	Acquisition range (p
Location	/Modem/Control/Demodulation		
Description	Configuration of the range for the carrier acquisition sweep (peak-to-peak). A larger acquisition range will allow locking more easily on an unstable frequency but will also increase demodulator synchronisation time.		
RMCP Command	RDr	Access	
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmAcqRan	
	OID	1.3.6.1.4.1.5835.3.1.13.1.3.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	KHz	Hz	1.000.000
			50000 ,,,, 7500000

Command DmFECDemod2		FEC-rate and modulation	FEC-rate and mod.
Location	/Modem/Control/Demodulation		
Description	Configuration of the forward error correction coding & modulation. This variable is only visible in constant coding and modulation mode.		
RMCp Command	RMx	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmFECDemod2	
	OID	1.3.6.1.4.1.5835.3.1.13.1.11.1.1	
Values	Factory Default	Enumeration	Value
	qPSKModulationRate34	Dummy PLFRAMES QPSK no FEC (SKYPLEX) QPSK-1/2 QPSK-2/3 QPSK-3/4 QPSK-5/6 QPSK-6/7 QPSK-7/8 QPSK-auto QPSK-1/4 QPSK-1/3 QPSK-2/5 QPSK-3/5 QPSK-4/5 QPSK-8/9 QPSK-9/10 16APSK-2/3 16APSK-3/4 16APSK-4/5 16APSK-5/6 16APSK-8/9 16APSK-9/10 32APSK-3/4 32APSK-4/5 32APSK-5/6 32APSK-8/9 32APSK-9/10 16QAM-3/4 16QAM-7/8 16QAM-auto 8PSK-3/5 8PSK-2/3 8PSK-3/4 8PSK-auto 8PSK-5/6 8PSK-8/9 8PSK-9/10 Auto	0 10 11 12 13 15 16 17 19 21 22 23 24 25 26 27 42 43 44 45 48 49 53 54 55 58 59 63 67 69 81 82 83 84 85 88 89 99

Command DmExcBWStat		Actual roll-off factor	Actual roll-off fact
Location	/Modem/Monitor/Demodulation		
Description	Readout of the actual used roll-off factor in cases when the automatic roll-off detection is used.		
RMCP Command	Rfr	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmExcBWStat	
	OID	1.3.6.1.4.1.5835.3.1.13.1.9.1.1	
Values	Factory Default	Enumeration	Value
	x25RCRO	35% 25% 20%	1 2 3

Command DmAftDecBER		Bit error ratio after RS	Bit err. ratio after
Location	/Modem/Monitor/Demodulation		
Description	Readout of the estimated bit error rate of the output data. This figure is calculated from the pre-Reed-Solomon decoder byte error rate.		
RMCP Command	Rub	Access	Normal user : no access Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmAftDecBER	
	OID	1.3.6.1.4.1.5835.3.1.13.1.4.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	NA	NA	0 .. 1

Command DmPilots		DVB-S2 Physical Layer Pilots	Pilots
Location	/Modem/Control/Demodulation		
Description	Configuration of the DVB-S2 physical layer pilot detection. The following options are possible: <ul style="list-style-type: none">• Auto : Auto detection of the presence of pilots.• On : Pilots are present in the received signal.• Off : Pilots are not present in the received signal. Remark: This is a constant coding and modulation command.		
RMCP Command	ACp	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmPilots	
	OID	1.3.6.1.4.1.5835.3.1.13.1.52.1.1	
Values	Factory Default	Enumeration	Value

Command DmPilots		DVB-S2 Physical Layer Pilots	Pilots
	off	Off On	0 1

Command DmFrameType		DVB-S2 FEC-Frame type	FEC-Frame type
Location	/Modem/Control/Demodulation		
Description	This variable is only visible in CCM mode and allows to configure the DVB-S2 forward error correction (FEC) frame type : <ul style="list-style-type: none"> Normal: FEC-frames of 64800 bits or 8100 bytes. Short: FEC-frames of 16200 bits or 2025 bytes. 		
RMCP Command	ACf	Access	Normal user : RW Expert user : RW
	SNMP	Table	ntcDevsMod01DemodulatorEntry
		Command	ntcDevsMod01DmFrameType
		OID	1.3.6.1.4.1.5835.3.1.13.1.54.1.1
Values	Factory Default	Enumeration	Value
	short	Short Normal	0 1

Command DmISIControl		ISI Control	ISI Control
Location	/Modem/Control/Demodulation		
Description	Configuration command to control of the input stream identifier (ISI) filter: <ul style="list-style-type: none"> Enabled: ISI filtering is active. Disabled: No ISI filtering. 		
RMCP Command	ISc	Access	Normal user : no access Expert user : RW
	SNMP	Table	ntcDevsMod01DemodulatorEntry
		Command	ntcDevsMod01DmISIControl
		OID	1.3.6.1.4.1.5835.3.1.13.1.46.1.1
Values	Factory Default	Enumeration	Value
	disabled	Enabled Disabled	0 1

Command DmSpecInv		Rx spectrum inversion	Rx spectrum inversion
Location	/Modem/Control/Demodulation		
Description	Configuration command for the received spectrum. The selection of the auto mode allows the device to solve the spectrum ambiguity when the status of the received spectrum is unknown. When the status of the received spectrum is known (spectrum inversion on or off), do not use the auto mode since it will increase the acquisition time. In a converter, the auto mode is not available and spectral inversion has to be set manually.		
RMCP Command	RMi	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmSpecInv	
	OID	1.3.6.1.4.1.5835.3.1.13.1.23.1.1	
Values	Factory Default	Enumeration	Value
	invertedSpectrum	Auto Direct Inverted	0 1 2

Command DmPLSSignature		Physical Layer Scrambler signature	PLS signature
Location	/Modem/Control/Demodulation		
Description	Configuration of the physical layer scrambler (PLSCRAMBLER) signature. The physical layer scrambler scrambles all of the physical layer frames except for their header parts. The sequence is reset at the start of the frame body. The physical layer scrambler signature assumes values in the range between 0 and 262141. It indicates the spreading sequence number. The use of different physical layer scrambling sequences allows a reduction of interference correlation between different services. For the same purpose, it is possible to reuse a shifted version of the same sequence in different satellite beams. Furthermore the spreading sequence number can be unequivocally associated to each satellite operator or satellite or transponder, thus permitting identification of an interfering signal via the physical layer scrambling signature detection. There is no explicit signaling method to convey the spreading sequence number to the receiver. In case of broadcasting services, the default physical layer scrambler signature (value = 0) shall be used, to avoid manual receiver setting or synchronisation delays.		
RMCP Command	Pss	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmPLSSignature	
	OID	1.3.6.1.4.1.5835.3.1.13.1.73.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU) Expert Range (CU)
	NA	NA	0 .. 262141

Command IfOutputClock		Output clock selection	Output clock sel.
Location	/Modem/Control/Demodulation		
Description	<p>Configuration of the clock for the data output at the interface. This is also the output clock for the de-framer buffer.</p> <p>Selections:</p> <ul style="list-style-type: none"> The satellite received clock. An externally provided clock at interface rate. An internally generated clock. Remark: If the satellite or the external clock is not valid or present when selected then the controller falls automatically back to the internal clock. On the remote side, normal operation mode is to select the satellite receive clock. Then the interface clock is adjusted via a clock recovery loop to match the satellite clock. When the internal clock is selected as interface clock, then the fixed fall back clock is used for data output. 		
RMCP Command	Rlc	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfOutputClock	
	OID	1.3.6.1.4.1.5835.3.1.4.1.38.1.1	
Values	Factory Default	Enumeration	Value
	satellite	Internal Satellite External External G703 1 External G703 2 External HSSI G703 155 Mbit/s MMF SMF	3 4 6 7 8 9 10 11 12

Command DmExcBW		Roll-off factor	Roll-off factor
Location	/Modem/Control/Demodulation		
Description	Configuration of the matched filter excess bandwidth. In auto mode, 35% is selected for DVB-QPSK modes and 25% for 8PSK and 16QAM according to the DVB standard. Selecting 25% manually in QPSK will result in some bandwidth saving and will not result in any significant BER performance degradation (0.1 - 0.2 dB).		
RMCP Command	RFr	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmExcBW	
	OID	1.3.6.1.4.1.5835.3.1.13.1.8.1.1	
Values	Factory Default	Enumeration	Value
	x25RCRO	Auto 35% 25%	0 1 2

Command DmExcBW	Roll-off factor	Roll-off factor
	20%	3

Command DmPidFilteringControl	PID filtering		PID filtering
Location	/Modem/Control/Demodulation		
Description	Enable or disable PID filtering.		
RMCP Command	dpf	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmPidFilteringControl	
	OID	1.3.6.1.4.1.5835.3.1.13.1.149.1.1	
Values	Factory Default	Enumeration	Value
	enabled	Disabled Enabled	0 1

/Modem/Control/Demodulation/Backup carrier

Command DmBuRxRfFreq	Backup receive frequency	Backup receive frequ	
Location	/Modem/Control/Demodulation/Backup carrier		
Description	Controls the RF input frequency for the backup carrier configuration.		
RMCP Command	BRF array : [1 .. 2]	Access	
SNMP	Table	ntcDevsMod01DemodulatorExtEntry	
	Command	ntcDevsMod01DmBuRxRfFreq	
	OID	1.3.6.1.4.1.5835.3.1.13000.1.17.1.1.[1 .. 2]	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	MHz	Hz	1.170000
			950000000 .. 2150000000

Command DmBuSynRate	Backup symbol rate	Backup symbol rate %
Location	/Modem/Control/Demodulation/Backup carrier	
Description	Backup nominal symbol rate, used when we fail to lock on the primary demodulator parameters.	
RMCP Command	BSR array : [1 .. 2]	Access

Command DmBuSynRate		Backup symbol rate	Backup symbol rate %
SNMP	Table	ntcDevsMod01DemodulatorExtEntry	
	Command	ntcDevsMod01DmBuSynRate	
	OID	1.3.6.1.4.1.5835.3.1.13000.1.18.1.1.[1 .. 2]	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Mbaud	baud	27.500000
		Expert Range (CU)	
		-1e+38 .. 1e+38	

Command DmBuSwitchTimeout		Carrier switch delay	Carrier switch delay
Location	/Modem/Control/Demodulation/Backup carrier		
Description	Minimum time interval (in seconds) between consecutive demodulator carrier switch operations.		
RMCP Command	DST	Access	Normal user : RW Expert user : RW
	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmBuSwitchTimeout	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	sec	sec	60
		Expert Range (CU)	
		2 .. 1000	

Command DmBuEnable		Carrier switching enable	Carrier switching en
Location	/Modem/Control/Demodulation/Backup carrier		
Description	This configuration variable is used to enable switching between demodulation carriers.		
RMCP Command	BDM		Access
			Normal user : RW Expert user : RW
	Table	ntcDevsMod01DemodulatorEntry	
SNMP	Command	ntcDevsMod01DmBuEnable	
	OID	1.3.6.1.4.1.5835.3.1.13.1.146.1.1	
Values	Factory Default	Enumeration	Value
	disabled	Disabled Enabled	0 1

Command DmBuSwitchCnt		Carrier switch count	Carrier switch count
Location	/Modem/Control/Demodulation/Backup carrier		
Description	The number of times we have dynamically switched to another carrier (with or without success).		
RMCP Command	csc	Access	Normal user : R Expert user : R

Command DmBuSwitchCnt		Carrier switch count	Carrier switch count
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmBuSwitchCnt	
	OID	1.3.6.1.4.1.5835.3.1.13.1.147.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	events	events	0 .. 4294967295

/Modem/Control/Demodulation/ACM client

Command MoAcmRtSigPlane		ACM rt sig plane	ACM rt sig plane
Location	/Modem/Control/Demodulation/ACM client		
Description	Select control plane for ACM controller return signalling: <ul style="list-style-type: none"> MonCon management IP network Inband RF channel 		
RMCP Command	arp		Access Normal user : no access Expert user : RW
	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoAcmRtSigPlane	
SNMP	OID	1.3.6.1.4.1.5835.3.1.3.1.158.1.1	
	Values	Factory Default	Enumeration
		moncon_ip	Moncon IP mngrt LAN Inband RF
			0 1

/Modem/Control/Demodulation/AES

Command DmAESEncryptionCtrl		Global Encryption	Global Encryption
Location	/Modem/Control/Demodulation/AES		
Description	Used to select if the Global Encryption key is used for all ISI or ISI specific encryption settings are used. <ul style="list-style-type: none"> Global : AES encryption enabled with global key (one key for all streams) isi : AES encryption enabled with individual keys for each stream ISI 		
RMCP Command	dMc		Access Normal user : no access Expert user : RW
	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmAESEncryptionCtrl	
SNMP	OID	1.3.6.1.4.1.5835.3.1.13.1.133.1.1	
	Values	Factory Default	Enumeration
		global	Global
			0

Command DmAESEncryptionCtrl		Global Encryption	Global Encryption
		lsi	1

Command DmAESEnableEncGlobal		Encryption Global	Encryption Global
Location	/Modem/Control/Demodulation/AES/Global		
Description	This method is used to enable/disable Global AES encryption/decryption. If encryption is disabled, then the Global key is disabled (ignored) If encryption is enabled, then the encryption is via the global settings.		
RMCP Command	dMg	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmAESEnableEncGlobal	
	OID	1.3.6.1.4.1.5835.3.1.13.1.130.1.1	
Values	Factory Default	Enumeration	Value
	off	Off On	0 1

Command DmAESKeyParityGlob		Global Key Parity	Global Key Parity
Location	/Modem/Control/Demodulation/AES/Global		
Description	This variable is used for the Global key parity selection (odd/even) for each ISI <ul style="list-style-type: none"> • odd : use Odd key • even : use Even key 		
RMCP Command	dGp	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmAESKeyParityGlob	
	OID	1.3.6.1.4.1.5835.3.1.13.1.135.1.1	
Values	Factory Default	Enumeration	Value
	odd	Odd Even Unencrypted Undetermined	0 1 2 3

Command DmAESEncEvenGlobalKey		Global Encrypted Even Key	Global Encrypted Even
Location	/Modem /Control/Demodulation/AES/Global		
Description	<p>This is the Global EVEN encrypted key entered by the user and decrypted with the group key. The key can be either 64bits or 128bits long, depending on the key length setting. If 64bit length is selected then the key has to be encrypted using DES. If 128bit length is selected then the key has to be encrypted using AES. The key is a hexadecimal key.</p> <ul style="list-style-type: none"> • 64bits - 8 bytes (16 bytes text string) • 128bits - 16 bytes (32 bytes text string) 		
RMCP Command	dGe	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmAESEncEvenGlobalKey	
	OID	1.3.6.1.4.1.5835.3.1.13.1.131.1.1	
Values	Factory Default	String Description	
	FFFFFFFFFFFFFFFFFF	length : 32 (fixed) format : Hexadecimal chars	

Command DmAESEncOddGlobalKey		Global Encrypted Odd Key	Global Encrypted Odd
Location	/Modem/Control/Demodulation/AES/Global		
Description	<p>This is the Global ODD encrypted key entered by the user and decrypted with the group key. The key can be either 64bits or 128bits long, depending on the key length setting. If 64bit length is selected then the key has to be encrypted using DES. If 128bit length is selected then the key has to be encrypted using AES. The key is a hexadecimal key.</p> <ul style="list-style-type: none"> • 64bits - 8 bytes (16 bytes text string) • 128bits - 16 bytes (32 bytes text string) 		
RMCP Command	dGo	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmAESEncOddGlobalKey	
	OID	1.3.6.1.4.1.5835.3.1.13.1.132.1.1	
Values	Factory Default	String Description	
	FFFFFFFFFFFFFFFFFF	length : 32 (fixed) format : Hexadecimal chars	

Command DmAESEvenGlobalKey		Global Even Key			
Location	/Modem/Control/Demodulation/AES/Global				
Description	This is the AES Global EVEN key (non-encrypted) entered by the user. This can be either 64bits or 128bits long, depending on the key length setting. The value is entered as a hexadecimal value: <ul style="list-style-type: none"> • 64 bits - 8 bytes (16 text bytes) • 128 bits - 16 bytes (32 text bytes) 				
RMCP Command	dGE		Access Normal user : RW Expert user : RW		
SNMP	<i>Table</i>	ntcDevsMod01DemodulatorEntry			
	<i>Command</i>	ntcDevsMod01DmAESEvenGlobalKey			
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.13.1.134.1.1			
Values	<i>Factory Default</i>	<i>String Description</i>			
	FFFFFFFFFFFF	length : 0 .. 32 format : Hexadecimal chars			
	FFFF				

Command DmAESOddGlobalKey		Global Odd Key			
Location	/Modem/Control/Demodulation/AES/Global				
Description	This is the AES Global ODD key (non-encrypted) entered by the user. This can be either 64bits or 128bits long, depending on the key length setting. The value is entered as a hexadecimal value: <ul style="list-style-type: none"> • 64 bits - 8 bytes (16 text bytes) • 128 bits - 16 bytes (32 text bytes) 				
RMCP Command	dGO		Access Normal user : RW Expert user : RW		
SNMP	<i>Table</i>	ntcDevsMod01DemodulatorEntry			
	<i>Command</i>	ntcDevsMod01DmAESOddGlobalKey			
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.13.1.136.1.1			
Values	<i>Factory Default</i>	<i>String Description</i>			
	FFFFFFFFFFFF	length : 0 .. 32 format : Hexadecimal chars			
	FFFF				

Command DmAESEnableEncISI		Encryption Id			
Location	/Modem/Control/Demodulation/AES/Keys 1-4				
Description	This method is used to enable/disable AES encryption per KeyId/ISI 0 - Encryption on ISI is disable. 1 - Encryption on ISI is enabled.				
RMCP Command	dEi array : [1 .. 4]		Access Normal user : RW Expert user : RW		
SNMP	<i>Table</i>	ntcDevsMod01DemodulatorExtEntry			

Command DmAESEnableEncSI		Encryption Id	Encryption Id
Values	Command	ntcDevsMod01DmAESEnableEncSI	
	OID	1.3.6.1.4.1.5835.3.1.13000.1.8.1.1.[1 .. 4]	
Values	Factory Default	Enumeration	Value
	off	Off On	0 1

Command DmAESKeyISI		ISI for Key Id	ISI for Key Id
Location	/Modem/Control/Demodulation/AES/Keys 1-4		
Description	This method is used to set/map the ISI to a encryption/decryption key. Duplication of ISI to another key is invalid. Range of value is: 0 to 255. Default: 255		
RMCP Command	dei array : [1 .. 4]	Access	Normal user : RW Expert user : RW
SNMP	Table ntcDevsMod01DemodulatorExtEntry Command ntcDevsMod01DmAESKeyISI OID 1.3.6.1.4.1.5835.3.1.13000.1.12.1.1.[1 .. 4]		
Values	Factory Default	String Description	
	FF	length : 0 .. 2 format : Hexadecimal chars	

Command DmAESKeyParityISI		Key Parity Id	Key Parity Id
Location	/Modem/Control/Demodulation/AES/Keys 1-4		
Description	This variable is used for the key parity selection (odd/even) for each ISI <ul style="list-style-type: none"> odd : use Odd key even : use Even key 		
RMCP Command	dKp array : [1 .. 4]	Access	Normal user : R Expert user : R
SNMP	Table ntcDevsMod01DemodulatorExtEntry Command ntcDevsMod01DmAESKeyParityISI OID 1.3.6.1.4.1.5835.3.1.13000.1.13.1.1.[1 .. 4]		
Values	Factory Default	Enumeration	Value
	odd	Odd Even Unencrypted Undetermined	0 1 2 3

Command DmAESEncEvenKeyISI		Encrypted Even Key	Encrypted Even Key %
Location	/Modem/Control/Demodulation/AES/Keys 1-4		
Description	<p>This is the EVEN encrypted key entered by the user and decrypted with the group key. The key can be either 64bits or 128bits long, depending on the key length setting. If 64bit length is selected then the key has to be encrypted using DES. If 128bit length is selected then the key has to be encrypted using AES. The key is a hexadecimal key.</p> <ul style="list-style-type: none"> • 64bits - 8 bytes (16 bytes text string) • 128bits - 16 bytes (32 bytes text string) 		
RMCP Command	dek array : [1 .. 4]		Access Normal user : RW Expert user : RW
SNMP	Table ntcDevsMod01DemodulatorExtEntry Command ntcDevsMod01DmAESEncEvenKeyISI OID 1.3.6.1.4.1.5835.3.1.13000.1.9.1.1.[1 .. 4]		
Values		Factory Default FFFFFFFFFFFFFF FFFFFFFFFFFFFF FFFF	String Description length : 32 (fixed) format : Hexadecimal chars

Command DmAESEncOddKeyISI		Encrypted Odd Key	Encrypted Odd Key
Location	/Modem/Control/Demodulation/AES/Keys 1-4		
Description	<p>This is the ODD encrypted key entered by the user and decrypted with the group key. The key can be either 64bits or 128bits long, depending on the key length setting. If 64bit length is selected then the key has to be encrypted using DES. If 128bit length is selected then the key has to be encrypted using AES. The key is a hexadecimal key.</p> <ul style="list-style-type: none"> • 64bits - 8 bytes (16 bytes text string) • 128bits - 16 bytes (32 bytes text string) 		
RMCP Command	dok array : [1 .. 4]		Access Normal user : RW Expert user : RW
SNMP	Table ntcDevsMod01DemodulatorExtEntry Command ntcDevsMod01DmAESEncOddKeyISI OID 1.3.6.1.4.1.5835.3.1.13000.1.10.1.1.[1 .. 4]		
Values		Factory Default FFFFFFFFFFFFFF FFFFFFFFFFFFFF FFFF	String Description length : 32 (fixed) format : Hexadecimal chars

Command DmAESEvenKeyISI		Even Key	Even Key
Location	/Modem/Control/Demodulation/AES/Keys 1-4		
Description	<p>This is the AES EVEN key (non-encrypted) entered by the user.</p> <p>This can be either 64bits or 128bits long, depending on the key length setting.The value is entered as a hexadecimal value:</p> <ul style="list-style-type: none"> • 64 bits - 8 bytes (16 text bytes) • 128 bits - 16 bytes (32 text bytes) 		
RMCP Command	dEk array : [1 .. 4]	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01DemodulatorExtEntry	
	Command	ntcDevsMod01DmAESEvenKeyISI	
	OID	1.3.6.1.4.1.5835.3.1.13000.1.11.1.1.[1 .. 4]	
Values	Factory Default	String Description	
	FFFFFFFFFFFFFF	length : 0 .. 32	
	FFFFFFFFFFFFFF	format : Hexadecimal chars	
Command DmAESOddKeyISI		Odd Key	Odd Key
Location	/Modem/Control/Demodulation/AES/Keys 1-4		
Description	<p>This is the AES ODD key (non-encrypted) entered by the user.</p> <p>This can be either 64bits or 128bits long, depending on the key length setting.The value is entered as a hexadecimal value:</p> <ul style="list-style-type: none"> • 64 bits - 8 bytes (16 text bytes) • 128 bits - 16 bytes (32 text bytes) 		
RMCP Command	dOk array : [1 .. 4]	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01DemodulatorExtEntry	
	Command	ntcDevsMod01DmAESOddKeyISI	
	OID	1.3.6.1.4.1.5835.3.1.13000.1.14.1.1.[1 .. 4]	
Values	Factory Default	String Description	
	FFFFFFFFFFFFFF	length : 0 .. 32	
	FFFFFFFFFFFFFF	format : Hexadecimal chars	

Command DmAESOddKeyISI		Odd Key	Odd Key
Location	/Modem/Control/Demodulation/AES/Keys 1-4		
Description	<p>This is the AES ODD key (non-encrypted) entered by the user.</p> <p>This can be either 64bits or 128bits long, depending on the key length setting.The value is entered as a hexadecimal value:</p> <ul style="list-style-type: none"> • 64 bits - 8 bytes (16 text bytes) • 128 bits - 16 bytes (32 text bytes) 		
RMCP Command	dOk array : [1 .. 4]	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01DemodulatorExtEntry	
	Command	ntcDevsMod01DmAESOddKeyISI	
	OID	1.3.6.1.4.1.5835.3.1.13000.1.14.1.1.[1 .. 4]	
Values	Factory Default	String Description	
	FFFFFFFFFFFFFF	length : 0 .. 32	
	FFFFFFFFFFFFFF	format : Hexadecimal chars	

/Modem/Monitor

/Modem/Monitor/Interfaces

/Modem/Monitor/Interfaces/Ethernet



Only valid for the following modes:

- Eth(IP)
- Eth(S2BBFoE)
- Eth(ntS2BBFoE)

Command SyUnitRedunOperState		Unit redundancy state		Unit redundancy stat		
Location	/Modem/Monitor/Interfaces/Ethernet					
Description	This variable indicates whether the unit is active or standby in a redundant configuration.					
RMCP Command	uro		Access	Normal user : R Expert user : R		
SNMP	Table	ntcDevsMod01SystemEntry				
	Command	ntcDevsMod01SyUnitRedunOperState				
	OID	1.3.6.1.4.1.5835.3.1.1.1.106.1.1				
Values	Factory Default		Enumeration	Value		
	active		Standby Active	0 1		

Command IfDevMacAddrA		MAC address A		MAC address A		
Location	/Modem/Monitor/Interfaces/Ethernet					
Description	Readout of the Ethernet physical MAC address of the interface A.					
RMCP Command	EmA		Access	Normal user : R Expert user : R		
SNMP	Table	ntcDevsMod01InterfaceEntry				
	Command	ntcDevsMod01IfDevMacAddrA				
	OID	1.3.6.1.4.1.5835.3.1.4.1.79.1.1				
Values	Factory Default		String Description			
	00:06:39:00:10:5D		length : 17 (fixed) format : ^([da-fA-F]{2}:){5}[da-fA-F]{2}\$			

Command IfltfaStatus		Phy Status A		Phy Status A		
Location	/Modem/Monitor/Interfaces/Ethernet					
Description	Human readable status of Ethernet physical status of interface A.					
RMCP Command	Ipa		Access	Normal user : R Expert user : R		
SNMP	Table	ntcDevsMod01InterfaceEntry				
	Command	ntcDevsMod01IfltfaStatus				
	OID	1.3.6.1.4.1.5835.3.1.4.1.97.1.1				
Values	Factory Default	String Description				
		length : 0 .. 40 format : any chars				

Command IfDevMacAddrB		MAC address B		MAC address B		
Location	/Modem/Monitor/Interfaces/Ethernet					
Description	Readout of the Ethernet physical MAC address of the interface B.					
RMCP Command	EmB		Access	Normal user : R Expert user : R		
SNMP	Table	ntcDevsMod01InterfaceEntry				
	Command	ntcDevsMod01IfDevMacAddrB				
	OID	1.3.6.1.4.1.5835.3.1.4.1.80.1.1				
Values	Factory Default	String Description				
	00:06:39:00:10:5E	length : 17 (fixed) format : ^([\\da-fA-F]{2}:){5}[\\da-fA-F]{2}\$				

Command IfltfbStatus		Phy Status B		Phy Status B		
Location	/Modem/Monitor/Interfaces/Ethernet					
Description	Human readable status of Ethernet physical status of interface B.					
RMCP Command	Ipb		Access	Normal user : R Expert user : R		
SNMP	Table	ntcDevsMod01InterfaceEntry				
	Command	ntcDevsMod01IfltfbStatus				
	OID	1.3.6.1.4.1.5835.3.1.4.1.98.1.1				
Values	Factory Default	String Description				
		length : 0 .. 40 format : any chars				

Command IfEthStatsRXPackets		#Eth RX	#Eth RX
Location	/Modem/Monitor/Interfaces/Ethernet		
Description	Readout of the number of Ethernet packets that are received at the input.		
RMCP Command	IEP	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfEthStatsRXPackets	
	OID	1.3.6.1.4.1.5835.3.1.4.1.87.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Packets	Packets	0 .. 4294967295

Command IfEthStatsRXNoMatch		#Eth RX Ignored	#Eth RX Ignored
Location	/Modem/Monitor/Interfaces/Ethernet		
Description	Readout of the number of Ethernet packets that were ignored because no filter matched.		
RMCP Command	IEI	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfEthStatsRXNoMatch	
	OID	1.3.6.1.4.1.5835.3.1.4.1.86.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Packets	Packets	0 .. 4294967295

Command IfEthStatsRXCongDropped		#Eth RX Congested	#Eth RX Congested
Location	/Modem/Monitor/Interfaces/Ethernet		
Description	Readout of the number of Ethernet packets that were dropped because of congestion.		
RMCP Command	IEC	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfEthStatsRXCongDropped	
	OID	1.3.6.1.4.1.5835.3.1.4.1.209.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Packets	Packets	0 .. 4294967295

Command IfProxyARPRespCount		#Proxy ARP Resp	#Proxy ARP Resp
Location	/Modem/Monitor/Interfaces/Ethernet		
Description	Readout of the number of ARP requests that has been answered by the proxy ARP agent.		
RMCP Command	pac	Access	Normal user : R Expert user : R
	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfProxyARPRespCount	
SNMP	OID	1.3.6.1.4.1.5835.3.1.4.1.199.1.1	
	Values	GUI Unit	Cmd Unit Factory Default (CU) Expert Range (CU)
		Packets	0 .. 4294967295

Command IfProxyARPIgnoredCount		#Proxy ARP ignored	#Proxy ARP ignored
Location	/Modem/Monitor/Interfaces/Ethernet		
Description	Readout of the number of ARP requests that has been ignored by the proxy ARP agent because the IP address does not belong in any remote subnet.		
RMCP Command	pai	Access	Normal user : R Expert user : R
	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfProxyARPIgnoredCount	
SNMP	OID	1.3.6.1.4.1.5835.3.1.4.1.198.1.1	
	Values	GUI Unit	Cmd Unit Factory Default (CU) Expert Range (CU)
		Packets	0 .. 4294967295

Command IfEthStatsReset		Reset Ethernet Counters	Reset Ethernet Count
Location	/Modem/Monitor/Interfaces/Ethernet		
Description	Configuration when the Ethernet statistics counters (which are updated during processing) are reset internally. <ul style="list-style-type: none"> Once: The counters are reset when this command is processed and returns to the never state. Never: The counters continue to run freely. Reset each period: the counters are set to zero when a statistics period (5 s) is reached. 		
RMCP Command	IEr	Access	Normal user : RW Expert user : RW
	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfEthStatsReset	
SNMP	OID	1.3.6.1.4.1.5835.3.1.4.1.88.1.1	

Command IfEthStatsReset		Reset Ethernet Counters	Reset Ethernet Count
Values	<i>Factory Default</i>	<i>Enumeration</i>	<i>Value</i>
	never	Each period (5 s) Never Once	0 1 2

Command IfGbeConfigError		Last config error	Last config error
Location	/Modem/Monitor/Interfaces/Ethernet		
	Applicable for the whole unit and not only for the Ethernet interface.		
Description	Readout of the error string describing the last configuration error.		
RMCP Command	GCE	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfGbeConfigError	
	OID	1.3.6.1.4.1.5835.3.1.4.1.193.1.1	
Values	Factory Default	String Description	
		length : 0 .. 120 format : any chars	

Command IfGbeSwError		Last software error	Last software error
Location	/Modem/Monitor/Interfaces/Ethernet		
	Applicable for the whole unit and not only for the Ethernet interface.		
Description	Readout of the most recent software error message (if any). A fatal error message survives a soft reset. This message is fully cleared after a hard reset.		
RMCP Command	sem	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfGbeSwError	
	OID	1.3.6.1.4.1.5835.3.1.4.1.214.1.1	
Values	Factory Default	String Description	
		length : 0 .. 130 format : any chars	

Command IfGbeSwErrCount		#Software errors	#Software errors
Location	/Modem/Monitor/Interfaces/Ethernet		
	Applicable for the whole unit and not only for the Ethernet interface.		
Description	Readout of the number of software errors encountered on this system. A fatal error inside the counter survives a soft reset. The counter is fully cleared when a hard reset occurs.		
RMCP Command	sec	Access	Normal user : R Expert user : R
SNMP	Table Command OID	ntcDevsMod01InterfaceEntry ntcDevsMod01IfGbeSwErrCount 1.3.6.1.4.1.5835.3.1.4.1.213.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU) Expert Range (CU)
	errors	errors	0 .. 4294967295

Structured Command IfBBCounters		Baseband Counters	Baseband Counters		
Location	/Modem/Monitor/Interfaces/Ethernet				
	Only valid for DVB-S2 modes.				
Description	Readout of the baseband counters: transmit counters, receive counters and drop counters.				
RMCP Command	IBc	Access	Normal user : R Expert user : R		
SNMP	Table Command OID	ntcDevsMod01InterfaceEntry ntcDevsMod01IfBBCounters 1.3.6.1.4.1.5835.3.1.4.1.57.1.1			
Variables					
IfBBTXCounter					
IfBBTXBBFCounter					
IfBBRXCounter					
IfBBRXBBFCounter					
IfBBRXdDropCounter					
IfBBRXTSCrcErr					
IfBBRXBBFCrcErr					
Page					
198					
198					
198					
198					
198					
199					
199					
199					

Structured Command IfBbTxEthqStats		BB TX Eth queue status	BB TX Eth queue stat
Location	/Modem/Monitor/Interfaces/Ethernet		
	Only valid for DVB-S2 modes.		
Description	Readout of the baseband TX Ethernet queue status. This queue contains the frames that travel from the Ethernet interface to the baseband interface.		
RMCP Command	bte	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfBbTxEthqStats	
	OID	1.3.6.1.4.1.5835.3.1.4.1.206.1.1	
Variables			Page
IfBbTxEthqCurFilling IfBbTxEthqMaxFilling			199 200

Command IfBBCntRst		Baseband counters reset	Baseband counters re
Location	/Modem/Monitor/Interfaces/Ethernet		
	Only valid for DVB-S2 modes.		
Description	This command resets the following baseband counters : IfBBTxCounter , IfBBRxCounter and IfBBRxDropCounter .		
RMCP Command	BCr	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfBBCntRst	
	OID	1.3.6.1.4.1.5835.3.1.4.1.55.1.1	
Values	Factory Default	Enumeration	Value
	never	Each second Never Once	0 1 2

Command IfBBTXInfrate		BB TX Interface rate		BB TX Interface rate		
Location	/Modem/Monitor/Interfaces/Ethernet					
	Only valid for DVB-S2 modes.					
Description	Readout of the actual interface rate on the interface towards the modulator.					
RMC Command	bir	Access		Normal user : R Expert user : R		
SNMP	Table	ntcDevsMod01InterfaceEntry				
	Command	ntcDevsMod01IfBBTXInfrate				
	OID	1.3.6.1.4.1.5835.3.1.4.1.177.1.1				
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	bps	bps	0	0 .. 4294967295		

Command IfBBTXNPStuffingRate		BB TX NP stuffing rate		BB TX NP stuffing ra		
Location	/Modem/Monitor/Interfaces/Ethernet					
	Only valid for DVB-S2 modes.					
Description	Readout of the null packet stuffing rate towards the modulator.					
RMC Command	bts	Access		Normal user : R Expert user : R		
SNMP	Table	ntcDevsMod01InterfaceEntry				
	Command	ntcDevsMod01IfBBTXNPStuffingRate				
	OID	1.3.6.1.4.1.5835.3.1.4.1.178.1.1				
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	bps	bps	0	0 .. 4294967295		

Command IfBBTXEstimOutpRate		BB TX Estim output rate		BB TX Estim output r		
Location	/Modem/Monitor/Interfaces/Ethernet					
	Only valid for DVB-S2 modes.					
Description	Readout of the estimated output rate towards the modulator.					
RMC Command	btr	Access		Normal user : R Expert user : R		
SNMP	Table	ntcDevsMod01InterfaceEntry				
	Command	ntcDevsMod01IfBBTXEstimOutpRate				
	OID	1.3.6.1.4.1.5835.3.1.4.1.176.1.1				
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		

Command IfBBTXEstimOutpRate		BB TX Estim output rate		BB TX Estim output r
	bps	bps	0	0 .. 4294967295

Command IfBBTxDvbs2FillingLevel		BB TX DVB-S2 filling level	BB TX DVB-S2 filling	
Location	/Modem/Monitor/Interfaces/Ethernet			
	Only valid for DVB-S2 modes.			
Description	This is the average percentage of valid data that is present in the DVB-S2 baseband frames. The remaining bytes are padded.			
RMCP Command	bfl	Access	Normal user : R Expert user : R	
SNMP	Table	ntcDevsMod01InterfaceEntry		
	Command	ntcDevsMod01IfBBTxDvbs2FillingLevel		
	OID	1.3.6.1.4.1.5835.3.1.4.1.175.1.1		
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	%	%	0	-1e+38 .. 1e+38

Command IfBBRXEstimBitRate		BB RX Estim raw bitrate	BB RX Estim raw bitr
Location	/Modem/Monitor/Interfaces/Ethernet		
Description	Readout of the estimated bitrate received from the demodulator.		
RMCP Command	Brb	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfBBRXEstimBitRate	
	OID	1.3.6.1.4.1.5835.3.1.4.1.173.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	bps	bps	0 .. 4294967295

Command IfBBRXEstimFrameRate		BB RX Estim raw framerate	BB RX Estim raw fram
Location	/Modem/Monitor/Interfaces/Ethernet		
Description	Readout of the estimated framerate received from the demodulator.		
RMCP Command	Brf	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfBBRXEstimFrameRate	
	OID	1.3.6.1.4.1.5835.3.1.4.1.174.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	fps	fps	0 .. 4294967295

Command IfBBRXChannelDrop		BB RX Channel Dropped	BB RX Channel Dro
Location	/Modem/Monitor/Interfaces/Ethernet		
Description	<p>Readout of the number of frames dropped during reception from a channel queue inside FPGA. Frames are dropped when the reception buffer risks overflow. This prevents the traffic streams from interfering with each other. This counter accounts for either DVB-S2 baseband frames or DVB-S transport stream frames dependant on the MdProcMode setting and queue type.</p> <p>The index identifies the queue.</p> <p>Index 1 = Ethernet Rx traffic (baseband frames or transport stream).</p> <p>Index 2 = ASI 1 Tx traffic (transport stream).</p> <p>Index 3 = ASI 2 Tx traffic (transport stream).</p> <p>Index 4 = ASI 3 Tx traffic (transport stream).</p>		
RMCP Command	chd array : [1 .. 5]	Access	Normal user : R Expert user : R
SNMP	Table ntcDevsMod01InterfaceExtEntry Command ntcDevsMod01IfBBRXChannelDrop OID 1.3.6.1.4.1.5835.3.1.4000.1.6.1.1.[1 .. 5]		
Values	GUI Unit	Cmd Unit	Factory Default (CU) Expert Range (CU)
	Frames	Frames	0 0 .. 4294967295

/Modem/Monitor/Interfaces/Ethernet/Packet Mon

Only valid for DVB-S2 modes.

Command IfPacketLogAction		Action	Action
Location	/Modem/Monitor/Interfaces/Ethernet/Packet Mon		
Description	<p>Packet log action: configure the action taken when a packet is logged. These are the options:</p> <ul style="list-style-type: none"> • Log binary. • Log decoded: In a more readable format, showing IP addresses etc... • Counting: Packet counter + bitrate. • Rx to packet monitor: This option extracts the traffic to the packet monitor. 		
RMCP Command	pla	Access	Normal user : no access Expert user : RW
SNMP	Table ntcDevsMod01InterfaceEntry Command ntcDevsMod01IfPacketLogAction OID 1.3.6.1.4.1.5835.3.1.4.1.219.1.1		
Values	Factory Default	Enumeration	Value
	logBinary	Log binary Log decoded	0 1

Command IfPacketLogAction		Action	Action
		Count Rx to packet mon	2 3

Command IfPacketLogFiltPat		Filter	Filter
Location	/Modem/Monitor/Interfaces/Ethernet/Packet Mon		
Description	Configuration of the packet log filter. Only packets that match this filter are logged. This filter exists of a sequence of criteria that are combined as a logical AND. Possible criteria are: • eth.dst==00:11:22:33:44:55 (hex) • eth.src==00:11:22:33:44:55 (hex) • ip.src==1.2.3.4 • ip.dst==1.2.3.4 • udp.dst==5001 (or 0x1389) • raw[12]==ab (hex) <small>Remark: To remove the packet filter, you can enter a dummy string of 1 character (e.g. "-").</small>		
RMCP Command	pfi	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfPacketLogFiltPat	
	OID	1.3.6.1.4.1.5835.3.1.4.1.220.1.1	
Values	Factory Default	String Description	
		length : 0 .. 128 format : any chars	

Command IfPacketLogFilter		Probe	Probe
Location	/Modem/Monitor/Interfaces/Ethernet/Packet Mon		
Description	Configuration of the packet log probe to define which packets can be logged to the packet log buffer.		
RMCP Command	plf	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfPacketLogFilter	
	OID	1.3.6.1.4.1.5835.3.1.4.1.196.1.1	
Values	Factory Default	Enumeration	Value
	allErrors	All errors No logging All Eth packets All EthRx packets All EthTx packets All EthRx errors All EthTx errors ARP Rx packets ARP Tx packets	0 1 2 3 4 5 6 7 8

Command IfGbePacketLogReason		Reason	Reason
Location	/Modem/Monitor/Interfaces/Ethernet/Packet Mon		
Description	Readout of the string that stores the reason for which the packet in the log buffer was logged. This can for instance display the error cause for which the packet has been logged.		
RMC Command	Plr		Access Normal user : no access Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfGbePacketLogReason	
	OID	1.3.6.1.4.1.5835.3.1.4.1.195.1.1	
Values	Factory Default	String Description	
		length : 0 .. 50 format : any chars	

Command IfGbePacketLog		Packet	Packet
Location	/Modem/Monitor/Interfaces/Ethernet/Packet Mon		
Description	Readout of the packet log buffer in which the head of the first discarded packet is stored. As long as the buffer is not read, the content of the buffer stays the same (= the first dropped packet). When the buffer is read, the next discarded packet will overwrite the buffer.		
RMC Command	Plb		Access Normal user : no access Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfGbePacketLog	
	OID	1.3.6.1.4.1.5835.3.1.4.1.194.1.1	
Values	Factory Default	String Description	
		length : 0 .. 200 format : any chars	

/Modem/Monitor/Interfaces/Ethernet/Packet Gen



Only valid for DVB-S2 modes.

Command IfPacketGenProbe		Probe	Probe
Location	/Modem/Monitor/Interfaces/Ethernet/Packet Gen		
Description	Configuration at which point the packet generator should insert packets.		
RMC Command	pgp		Access Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfPacketGenProbe	

Command IfPacketGenProbe		Probe	Probe
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.4.1.218.1.1	
Values	<i>Factory Default</i>	<i>Enumeration</i>	<i>Value</i>
	ethRxlf	Eth RX interface	0

Command IfPacketGenFormat		Packet format	Packet format
Location	/Modem/Monitor/Interfaces/Ethernet/Packet Gen		
Description	<p>Configuration of the packet generator format. The packet generator is a UDP packet generator that is compatible with iPerf software in UDP mode.</p> <p>Typical use cases for the traffic generator and traffic monitor:</p> <ul style="list-style-type: none"> • Generate traffic on a modulator and monitor this traffic on a demodulator. • Generate traffic from an iPerf client on a PC and monitor this traffic on a modulator or demodulator (via a modulator). • Generate traffic on a modulator and monitor this traffic on an iPerf server on a PC (via a demodulator).The generator format can be defined by space-separated sequence of the following criteria: • vlan==5 • eth.dst==00:11:22:33:44:55 (hex) • eth.src==00:11:22:33:44:55 (hex) • ip.src==1.2.3.4 • ip.dst==1.2.3.4 • ip.len==1200 • udp.dst==5001 (or 0x1389) • raw[12]==ab (hex)The destination UDP port defaults to 5001 (just like in iPerf). In most situations, it is sufficient to configure a destination IP address and a VLAN, if VLANs are used.Example for setting up a traffic generator on a modulator that sends data to a traffic monitor on a demodulator:1) Configure the packet monitor on the demodulator: - Action = rx to packet monitor - Filter = ip.dst==2.2.2.2 - Probe = All EthTx packets2) Configure the packet generator on the modulator: - Probe = Eth RX interface - Packet format = vlan==5 ip.dst==2.2.2.2 - Bitrate = 1000000 - Bytes to transmit = 1000000The packet monitor will stop itself, when the last packet of a session has been received. This last packet is detected by a negative sequence id in an iperf-proprietary part of the packet. 		
RMCP Command	pgf	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfPacketGenFormat	
	OID	1.3.6.1.4.1.5835.3.1.4.1.217.1.1	
Values	Factory Default	String Description	
		length : 0 .. 128 format : any chars	

Command IfPacketGenBitRate		Bitrate	Bitrate
Location	/Modem/Monitor/Interfaces/Ethernet/Packet Gen		
Description	Configuration of the bitrate for the packet generator.		
RMCP Command	pgb	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfPacketGenBitRate	
	OID	1.3.6.1.4.1.5835.3.1.4.1.215.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	bps	bps	10000
		Expert Range (CU)	
		0 .. 4294967295	

Command IfPacketGenBytesToTx		Bytes to transmit	Bytes to transmit
Location	/Modem/Monitor/Interfaces/Ethernet/Packet Gen		
Description	Configuration of the number of bytes to be transmitted by the traffic generator. When you enter a value higher than 134217727, the traffic generator will transmit packets forever (until you change this value to 0).		
RMCP Command	pgn	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfPacketGenBytesToTx	
	OID	1.3.6.1.4.1.5835.3.1.4.1.216.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	bytes	bytes	0
		Expert Range (CU)	
		0 .. 4294967295	

/Modem/Monitor/Interfaces/Ethernet/IP termination/MPEG over IP Statistics



Only valid for mode Eth (TSoIP).

Command IfMPEGoUDPStatsReset		Statistics Counters Mode		Statistics Counters			
Location	/Modem/Monitor/Interfaces/Ethernet/IP termination/MPEG over IP Statistics						
Description	Configuration command to specify when the MPEG over UDP statistics counters are reset internally. <ul style="list-style-type: none"> Reset each period: The counters are set to zero when a statistics period (5 seconds) is reached. Never: The counters continue to run freely. Reset on get: Reset each time the values are readout. 						
RMCP Command	IVr			Access	Normal user : RW Expert user : RW		
SNMP	Table	ntcDevsMod01InterfaceEntry					
	Command	ntcDevsMod01IfMPEGoUDPStatsReset					
	OID	1.3.6.1.4.1.5835.3.1.4.1.152.1.1					
Values	Factory Default	Enumeration	Value				
	never	Reset each period (5 s) Never Reset on Get	0 1 2				

Structured Command IfMPEGoUDPStats		MPEG over UDP Stats	MPEG over UDP Stats
Location	/Modem/Monitor/Interfaces/Ethernet/IP termination/MPEG over IP Statistics		
Description	Readout of the MPEG over UDP statistics. The statistics are updated periodically (5 seconds).		
RMCP Command	VsE	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfMPEGoUDPStats	
	OID	1.3.6.1.4.1.5835.3.1.4.1.151.1.1	
Variables			Page
IfMPEGoUDPStatsRXMtuPackets			200
IfMPEGoUDPStatsRXMtuBytes			200
IfMPEGoUDPStatsRXMtuRate			200
IfMPEGoUDPStatsRXMtuDrop			201
IfMPEGoUDPStatsRXPopTimeouts			201
IfMPEGoUDPStatsRXMpegPackets			201
IfMPEGoUDPStatsRXPushTimeouts			201
IfMPEGoUDPStatsTXMpegPackets			202

Structured Command	MPEG over UDP Stats	MPEG over UDP Stats
IfMPEGoUDPStats		
IfMPEGoUDPStatsTXMpegDrop	202	
IfMPEGoUDPStatsTXPopTimeouts	202	
IfMPEGoUDPStatsTXMtuPackets	202	
IfMPEGoUDPStatsTXMtuBytes	203	
IfMPEGoUDPStatsTXMtuRate	203	
IfMPEGoUDPStatsTXPushTimeouts	203	

Command	RX RTP Sync Src	RX RTP Sync Src	
IfRTPStatsRXSyncSrc			
Location	/Modem/Monitor/Interfaces/Ethernet/IP termination/MPEG over IP Statistics		
Description	Readout of the synchronisation source identifier of the last real time protocol packet received.		
RMCP Command	IRS	Access Normal user : R Expert user : R	
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfRTPStatsRXSyncSrc	
	OID	1.3.6.1.4.1.5835.3.1.4.1.168.1.1	
Values	GUI Unit	Cmd Unit	
	NA	0	Factory Default (CU)
			Expert Range (CU)
			0 .. 4294967295

Command	RX RTP Sequence	RX RTP Sequence	
IfRTPStatsRXSeq			
Location	/Modem/Monitor/Interfaces/Ethernet/IP termination/MPEG over IP Statistics		
Description	Readout of the next expected real time protocol sequence number in the real time protocol header of received packets.		
RMCP Command	IRs	Access Normal user : R Expert user : R	
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfRTPStatsRXSeq	
	OID	1.3.6.1.4.1.5835.3.1.4.1.167.1.1	
Values	GUI Unit	Cmd Unit	
	NA	0	Factory Default (CU)
			Expert Range (CU)
			0 .. 4294967295

Command IfRTPStatsRXDrop		RX RTP Dropped	RX RTP Dropped
Location	/Modem/Monitor/Interfaces/Ethernet/IP termination/MPEG over IP Statistics		
Description	Readout of the number of transport stream frames dropped during packet reordering. This is possible if a transport stream frame is received out of the reordering window.		
RMCP Command	IRd	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfRTPStatsRXDrop	
	OID	1.3.6.1.4.1.5835.3.1.4.1.164.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Packets	Packets	0 .. 4294967295

Command IfRTPStatsRXResync		RX RTP Resync	RX RTP Resync
Location	/Modem/Monitor/Interfaces/Ethernet/IP termination/MPEG over IP Statistics		
Description	Readout of the number of times that transport stream reordering failed and resynchronization on a new sequence number took place.		
RMCP Command	IRr	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfRTPStatsRXResync	
	OID	1.3.6.1.4.1.5835.3.1.4.1.166.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Times	Times	0 .. 4294967295

Command IfRTPStatsRXTimeouts		RX RTP Timeouts	RX RTP Timeouts
Location	/Modem/Monitor/Interfaces/Ethernet/IP termination/MPEG over IP Statistics		
Description	Readout of the number of times a transport stream frame is not received in time. This is possible if a transport stream frame is missing in the stream.		
RMCP Command	IRt	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfRTPStatsRXTimeouts	
	OID	1.3.6.1.4.1.5835.3.1.4.1.169.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Times	Times	0 .. 4294967295

Command IfRTPStatsRXMaxTSCount		RX RTP TS tracking		RX RTP TS tracking		
Location	/Modem/Monitor/Interfaces/Ethernet/IP termination/MPEG over IP Statistics					
Description	Readout of the last tracking number that is internally assigned to a transport stream packet to perform reordering of transport stream packets in a real time protocol stream.					
RMCP Command	IRc	Access		Normal user : R Expert user : R		
SNMP	Table	ntcDevsMod01InterfaceEntry				
	Command	ntcDevsMod01IfRTPStatsRXMaxTSCount				
	OID	1.3.6.1.4.1.5835.3.1.4.1.165.1.1				
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	NA	NA	0	0 .. 4294967295		

Command IfMPEGoUDPStatsTXLastTSNbr		BB TX Last TS Number	BB TX Last TS Number
Location	/Modem/Monitor/Interfaces/Ethernet/IP termination/MPEG over IP Statistics		
Description	Readout of the MPEG transport stream last sequence number. In a processing mode that supports MPEG over IP, each MPEG transport stream packet is marked with a sequence number. This number is e.g. used as input for the rate tracking control loop from Ethernet towards the modulator.		
RMCP Command	Vst	Access	
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfMPEGoUDPStatsTXLastTSNbr	
	OID	1.3.6.1.4.1.5835.3.1.4.1.153.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	NA	NA	0 .. 4294967295

Command IfDvbs2BbRxAvgCodingCompr		Avg coding compression	Avg coding compressi
Location	/Modem/Monitor/Interfaces/Ethernet/IP termination/ntS2BBFoE Rx Statistics		
Description	This is the number of encapsulation periods over which we calculate the average coding compression. See also IfDvbs2BbRxAvgCodingCompr.		
RMCP Command	acc	Access	
SNMP	Table	ntcDevsMod01InterfaceEntry	

Command IfDvbs2BbRxAvgCodingCompr		Avg coding compression		Avg coding compressi
		Command ntcDevsMod01IfDvbs2BbRxAvgCodingCompr		
		OID 1.3.6.1.4.1.5835.3.1.4.1.201.1.1		
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	bytes/sym	bytes/sym	1	-1e+38 .. 1e+38

Structured Command IfVolreqStats		IP volume req stats	IP volume req stats
Location	/Modem/Monitor/Interfaces/Ethernet/IP termination/ntS2BBFoE Rx Statistics		
Description	Readout of the IP volume request statistics.		
RMCP Command	vst	Access	Normal user : no access Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfVolreqStats	
	OID	1.3.6.1.4.1.5835.3.1.4.1.221.1.1	
Variables			Page
IfVolreqStatsMovAvgVol			203
IfVolreqStatsMovMaxVol			204
IfVolreqStatsMovMinVol			204

Structured Command IfDvbs2BboerxErrors		ntS2BBFoE Rx error counters	ntS2BBFoE Rx error c
Location	/Modem/Monitor/Interfaces/Ethernet/IP termination/ntS2BBFoE Rx Statistics		
Description	Error counters for all ntS2BBFoE receivers in total		
RMCP Command	brR	Access	Normal user : no access Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfDvbs2BboerxErrors	
	OID	1.3.6.1.4.1.5835.3.1.4.1.141.1.1	
Variables			Page
IfDvbs2BboerxFrames			184
IfDvbs2BboerxErrEncapId			185
IfDvbs2BboerxErrEncapDisabled			185
IfDvbs2BboerxErrSequence			185
IfDvbs2BboerxErrIpVol0			186

Structured Command IfDvbs2BboerxCurStats		ntS2BBFoE current statistics		current statistics		
Location	/Modem/Monitor/Interfaces/Ethernet/IP termination/ntS2BBFoE Rx Statistics					
Description	Statistics (current interval) for the ntS2BBFoE receiver instances					
RMCP Command	brs array : [1 .. 4]		Access	Normal user : no access Expert user : R		
SNMP	Table	ntcDevsMod01InterfaceExtEntry				
	Command	ntcDevsMod01IfDvbs2BboerxCurStats				
	OID	1.3.6.1.4.1.5835.3.1.4000.1.14.1.1.[1 .. 4]				
Variables				Page		
IfDvbs2BboerxCurlpVolume				186		
IfDvbs2BboerxCurPaddingVolume				186		
IfDvbs2BboerxCurSymbolVolume				187		

Structured Command IfDvbs2BboerxIntervalStats		ntS2BBFoE interval statistics		Interval statistics		
Location	/Modem/Monitor/Interfaces/Ethernet/IP termination/ntS2BBFoE Rx Statistics					
Description	Statistics (previous interval) for the ntS2BBFoE receiver instances					
RMCP Command	brS array : [1 .. 4]		Access	Normal user : R Expert user : R		
SNMP	Table	ntcDevsMod01InterfaceExtEntry				
	Command	ntcDevsMod01IfDvbs2BboerxIntervalStats				
	OID	1.3.6.1.4.1.5835.3.1.4000.1.15.1.1.[1 .. 4]				
Variables				Page		
IfDvbs2BboerxIntervalIpVolume				187		
IfDvbs2BboerxIntervalPadVolume				188		
IfDvbs2BboerxIntervalSymVolume				188		

/Modem/Monitor/Interfaces/Ethernet/IP termination/S2BBFoE Rx Statistics

Only valid for mode Eth (ntS2BBFoE).

Structured Command IfS2BBFoERxCounters		S2BBFoE RX counters	S2BBFoE RX counters
Location	/Modem/Monitor/Interfaces/Ethernet/IP termination/S2BBFoE Rx Statistics		
	Only valid for DVB-S2 modes.		
Description	Readout of the DVB-S2 baseband frames over Ethernet RX counters. The following counters are read out: IfS2BBFoERxFramesRxed , IfS2BBFoERxTranspHdrErrors , IfS2BBFoERxDflErrors and IfS2BBFoERxAcmErrors .		
RMCP Command	s2e	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfS2BBFoERxCounters	
	OID	1.3.6.1.4.1.5835.3.1.4.1.171.1.1	
Variables			Page
IfS2BBFoERxFramesRxed			204
IfS2BBFoERxTranspHdrErrors			204
IfS2BBFoERxDflErrors			205
IfS2BBFoERxAcmErrors			205

/Modem/Monitor/Interfaces/Ethernet/ipencap/Protocols/ULE Statistics

Only valid for the following modes:

- Eth(IP)
- Air(TS)

Command IfUleStatsReset		Statistics Counters Mode	Statistics Counters
Location	/Modem/Monitor/Interfaces/Ethernet/ipencap/Protocols/ULE Statistics		
Description	Configuration command to specify when the ULE statistics counters are reset internally. <ul style="list-style-type: none"> • Reset each period: The counters are set to zero when a statistics period (5 s) is reached. • Never: The counters continue to run freely. • Reset on get: The counter is reset each time the values are gotten. 		
RMCP Command	IUr	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfUleStatsReset	
	OID	1.3.6.1.4.1.5835.3.1.4.1.112.1.1	

Command IfUleStatsReset		Statistics Counters Mode		Statistics Counters	
Values	<i>Factory Default</i>	<i>Enumeration</i>	<i>Value</i>		
	never	Reset each period (5 s) Never Reset on Get	0 1 2		

Structured Command IfUleStats		ULE Stats		ULE Stats			
Location	/Modem/Monitor/Interfaces/Ethernet/ipencap/Protocols/ULE Statistics						
Description					Readout of the ULE encapsulation statistics. The statistics are updated periodically (5s). <ul style="list-style-type: none"> • Statistics Counter Mode: The type of reset for all statistics counter in this web page Never does not reset all counters and they are incrementing continuously. Reset each period (5s)resets all counters every 5 seconds. The counters show the measured values over the last 5 seconds. • Encap IN Ethernet: Readout of the number of Ethernet packets received on the Ethernet input. • Encap IN Ethernet: Readout of the number of Ethernet bytes received on the Ethernet input. • Encap IN Bitrate: Readout of the average input bitrate. • Encap OUT TS: Readout of the number of transport stream packets generated by encapsulator. • Decap OUT Ethernet: Readout of the number of Ethernet packets transmitted on the Ethernet output. • Decap OUT Ethernet: Readout of the number of Ethernet bytes transmitted on the Ethernet output. • Decap OUT Bitrate: Readout of the average output bitrate. • Decap IN TS: Readout of the number of transport stream packets processed by the decapsulator. 		
RMC P Command	UsE		Access	Normal user : R Expert user : R			
SNMP	Table	ntcDevsMod01InterfaceEntry					
	Command	ntcDevsMod01IfUleStats					
	OID	1.3.6.1.4.1.5835.3.1.4.1.111.1.1					
Variables					Page		
IfUleStatsTXMtuPackets					205		
IfUleStatsTXMtuBytes					205		
IfUleStatsTXMtuRate					206		
IfUleStatsTXMpegPackets					206		
IfUleStatsTXPopTimeouts					206		
IfUleStatsTXPushTimeouts					206		
IfUleStatsTIdle					207		
IfUleStatsRXMtuPackets					207		
IfUleStatsRXMtuBytes					207		
IfUleStatsRXMtuRate					207		
IfUleStatsRXMpegPackets					208		
IfUleStatsRXPopTimeouts					208		
IfUleStatsRXPushTimeouts					208		
IfUleStatsRXCRCErrors					208		
IfUleStatsRXIdle					208		

/Modem/Monitor/Interfaces/Ethernet/ipencap/Protocols/MPE Statistics

Only valid for the following modes:

- Eth(IP)
- Air(TS)

Command IfMpeStatsReset		Statistics Counters Mode	Statistics Counters
Location	/Modem/Monitor/Interfaces/Ethernet/ipencap/Protocols/MPE Statistics		
Description	Configuration command to specify when the MPE statistics counters are reset internally. <ul style="list-style-type: none"> • Reset each period: The counters are set to zero when a statistics period (5 seconds) is reached. • Never: The counters continue to run freely. • Reset on get: Reset each time the values are readout. 		
RMCP Command	IMr	Access	Normal user : RW Expert user : RW
	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfMpeStatsReset	
Values	OID	1.3.6.1.4.1.5835.3.1.4.1.163.1.1	
	Factory Default	Enumeration	Value
	never	Reset each period (5 s) Never Reset on Get	0 1 2

Structured Command IfMpeStats		Mpe Stats	Mpe Stats
Location	/Modem/Monitor/Interfaces/Ethernet/ipencap/Protocols/MPE Statistics		
Description	Readout of the MPE encapsulation statistics. The statistics are updated periodically (5 seconds).		
RMCP Command	MsE	Access	Normal user : R Expert user : R
	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfMpeStats	
Variables	OID	1.3.6.1.4.1.5835.3.1.4.1.162.1.1	
		Page	
	IfMpeStatsTXMtuPackets IfMpeStatsTXMtuBytes IfMpeStatsTXMtuRate IfMpeStatsTXMpegPackets IfMpeStatsRXMtuPackets IfMpeStatsRXMtuBytes IfMpeStatsRXMtuRate IfMpeStatsRXMpegPackets IfMpeStatsRXCRCErrors		209 209 209 209 210 210 210 210 211

/Modem/Monitor/Interfaces/Ethernet/ipencap/Protocols/Datapipe Statistics

Only valid for the following modes:

- Eth(IP)
- Air(TS)

Command IfDPStatsReset		Statistics Counters Mode	Statistics Counters
Location	/Modem/Monitor/Interfaces/Ethernet/ipencap/Protocols/Datapipe Statistics		
Description	<p>Command to configure when the datapiping statistics counters are reset internally.</p> <ul style="list-style-type: none"> • Reset each period: The counters are set to zero when a statistics period (5 seconds) is reached. • Never: The counters continue to run freely. • Reset on get: Each time the counters are gotten, the counter is reset. 		
RMCP Command	IDr	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfDPStatsReset	
	OID	1.3.6.1.4.1.5835.3.1.4.1.78.1.1	
Values	Factory Default	Enumeration	Value
	never	Reset each period (5 s) Never Reset on Get	0 1 2

Structured Command IfDPStats		Datapipe Stats	Datapipe Stats
Location	/Modem/Monitor/Interfaces/Ethernet/ipencap/Protocols/Datapipe Statistics		
Description	Readout of the datapiping encapsulation/decapsulation statistics.		
RMCP Command	DsE	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfDPStats	
	OID	1.3.6.1.4.1.5835.3.1.4.1.77.1.1	
Variables			Page
IfDPStatsTXMtuPackets			211
IfDPStatsTXMtuBytes			211
IfDPStatsTXMtuRate			211
IfDPStatsTXMpegPackets			212
IfDPStatsTXPopTimeouts			212
IfDPStatsTXPushTimeouts			212
IfDPStatsTXIdle			212
IfDPStatsRXMtuPackets			213

Structured Command IfDPStats	Datapipe Stats	Datapipe Stats
IfDPStatsRXMtuBytes		213
IfDPStatsRXMtuRate		213
IfDPStatsRXMpegPackets		213
IfDPStatsRXPopTimeouts		214
IfDPStatsRXPushTimeouts		214
IfDPStatsRXIdle		214

/Modem/Monitor/Interfaces/Ethernet/ipencap/Protocols/XPE Statistics

Command IfGBSStatsReset	Statistics Counters Mode		Statistics Counters
Location	/Modem/Monitor/Interfaces/Ethernet/ipencap/Protocols/XPE Statistics		
Description	Configuration command to specify when the XPE statistics counters are reset internally: <ul style="list-style-type: none"> Reset each period: The counters are set to zero when a statistics period (5 seconds) is reached. Never: The counters continue to run freely. Reset on get: Reset each time the values are readout. 		
RMC Command	IGr		Access Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfGBSStatsReset	
	OID	1.3.6.1.4.1.5835.3.1.4.1.96.1.1	
Values	Factory Default	Enumeration	Value
	never	Reset each period (5s) Never Reset on Get	0 1 2

Structured Command IfGBSStats	XPE Stats		XPE Stats		
Location	/Modem/Monitor/Interfaces/Ethernet/ipencap/Protocols/XPE Statistics				
Description	Readout of the XPE encapsulation statistics.				
RMC Command	GsE		Access Normal user : R Expert user : R		
SNMP	Table	ntcDevsMod01InterfaceEntry			
	Command	ntcDevsMod01IfGBSStats			
	OID	1.3.6.1.4.1.5835.3.1.4.1.95.1.1			
Variables					
IfGBSStatsTXEthPackets	215				
IfGBSStatsTXEthBytes	215				
IfGBSStatsTXEthRate	215				
IfGBSStatsTXPopTimeouts	215				
IfGBSStatsTxBBFrames	216				
IfGBSStatsTxBBBytes	216				

Structured Command	XPE Stats	XPE Stats
IfGBSStats		
IfGBSStatsTXPushTimeouts		216
IfGBSStatsRXBBFrames		216
IfGBSStatsRXBBBytes		217
IfGBSStatsRXPopTimeouts		217
IfGBSStatsRXCRCErrors		217
IfGBSStatsRXDropped		217
IfGBSStatsRXEthPackets		218
IfGBSStatsRXEthBytes		218
IfGBSStatsRXEthRate		218
IfGBSStatsRXPushTimeouts		218

/Modem/Monitor/Interfaces/Ethernet/ipencap/Protocols/GSE Statistics

Command IfGSEStatsReset		Statistics Counters Mode	Statistics Counters
Location	/Modem/Monitor/Interfaces/Ethernet/ipencap/Protocols/GSE Statistics		
Description	<p>Determine when the GSE statistics counters are reset internally.</p> <ul style="list-style-type: none"> Reset each period: the counters are set to zero when a statistics period (5 s) is reached. Never: the counters continue to run freely. Reset on Get: reset each time the values are gotten 		
RMCP Command	gsr	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfGSEStatsReset	
	OID	1.3.6.1.4.1.5835.3.1.4.1.277.1.1	
Values	Factory Default		Enumeration
	never		Reset each period (5s)
		Never	0
		Reset on Get	1
			2

Structured Command IfGSEStats		GSE Stats		GSE Stats					
Location	/Modem/Monitor/Interfaces/Ethernet/ipencap/Protocols/GSE Statistics								
Description	GSE encapsulation statistics. The statistics are updated periodically (5s).								
RMCPC Command	gsE		Access	Normal user : R Expert user : R					
SNMP	Table	ntcDevsMod01InterfaceEntry							
	Command	ntcDevsMod01IfGSEStats							
	OID	1.3.6.1.4.1.5835.3.1.4.1.276.1.1							
Variables					Page				
IfGSEStatsTXEthPackets					219				
IfGSEStatsTXEthBytes					222				

Structured Command IfGSEStats	GSE Stats	GSE Stats
IfGSEStatsTXEthRate		219
IfGSEStatsTXPopTimeouts		219
IfGSEStatsTXBBFrames		220
IfGSEStatsTXXBBBytes		220
IfGSEStatsTXPushTimeouts		220
IfGSEStatsTXFragmented		220
IfGSEStatsRXBBFrames		221
IfGSEStatsRXBBBytes		221
IfGSEStatsRXPopTimeouts		221
IfGSEStatsRXCRCErrors		221
IfGSEStatsRXDropped		221
IfGSEStatsRXEthPackets		222
IfGSEStatsRXEthBytes		222
IfGSEStatsRXEthRate		222
IfGSEStatsRXPushTimeouts		222
IfGSEStatsRXFragmented		223

Command DmDecapModcodStatGSE	Decapsulated MODCOD	Decapsulated MODCOD
Location	/Modem/Monitor/Interfaces/Ethernet/ipencap/Protocols/GSE Statistics	
Description	Returns the highest modcod of the baseband frames decapsulated during the last second	
RMCp Command	gsD	Access Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry
	Command	ntcDevsMod01DmDecapModcodStatGSE
	OID	1.3.6.1.4.1.5835.3.1.13.1.137.1.1
Values	Factory Default	Enumeration
	nothingReceived	Nothing received QPSK-1/2 QPSK-2/3 QPSK-3/4 QPSK-5/6 QPSK-6/7 QPSK-7/8 QPSK-1/4 QPSK-1/3 QPSK-2/5 QPSK-3/5 QPSK-4/5 QPSK-8/9 QPSK-9/10 16APSK-2/3 16APSK-3/4 16APSK-4/5 16APSK-5/6 16APSK-8/9 16APSK-9/10 32APSK-3/4
		0 11 12 13 15 16 17 21 22 23 24 25 26 27 42 43 44 45 48 49 53

Command	Decapsulated MODCOD	Decapsulated MODCOD
DmDecapModcodStatGSE	32APSK-4/5 32APSK-5/6 32APSK-8/9 32APSK-9/10 8PSK-3/5 8PSK-2/3 8PSK-3/4 8PSK-5/6 8PSK-6/7 8PSK-7/8 8PSK-8/9 8PSK-9/10	54 55 58 59 81 82 83 85 86 87 88 89

/Modem/Monitor/Interfaces/Ethernet/ipencap/VLAN Statistics

Structured Command	Ethernet kernel statistics	Ethernet kernel stat
IfVLANStats		
Location	/Modem/Monitor/Interfaces/Ethernet/ipencap/VLAN Statistics	
Description	Readout of the Ethernet kernel statistics per VLAN per Interface.	
RMCP Command	IVs array : [1 .. 33]	Access Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry
	Command	ntcDevsMod01IfVLANStats
	OID	1.3.6.1.4.1.5835.3.1.4.1.113.1.1.[1 .. 33]
Variables		
IfVLANStatsActive		
IfVLANStatsName		
IfVLANStatsTxPackets		
IfVLANStatsTxBytes		
IfVLANStatsRxPackets		
IfVLANStatsRxBytes		

Command	QOS stats reset	QOS stats reset
IfQosStatsReset		
Location	/Modem/Monitor/Interfaces/Ethernet/ipencap/QOS Statistics	
Description	This command allows to reset the quality of service statistics.	
RMCP Command	qsr	Access Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry
	Command	ntcDevsMod01IfQosStatsReset
	OID	1.3.6.1.4.1.5835.3.1.4.1.234.1.1
Values	<i>Factory Default</i>	<i>Enumeration</i>
	none	None Now
		0 1

Structured Command IfQosStatsEntry		Eth RX QOS statistics	Eth RX QOS statistic
Location	/Modem/Monitor/Interfaces/Ethernet/ipencap/QOS Statistics		
Description	Readout of the Ethernet RX quality of service statistics per quality of service class.		
RMCP Command	eqs array : [1 .. 4]	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01InterfaceExtEntry	
	Command	ntcDevsMod01IfQosStatsEntry	
	OID	1.3.6.1.4.1.5835.3.1.4000.1.18.1.1.[1 .. 4]	
Variables			Page
IfQosStatsPriority IfQosStatsBytesDropped			224 224

Command IfAcmFwSigRxed		ACM fw sig rxed	ACM fw sig rxed
Location	/Modem/Monitor/Interfaces/Ethernet/ipencap/Signalling		
Description	Number of ACM forward signalling packets received.		
RMCP Command	asf	Access	Normal user : no access Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfAcmFwSigRxed	
	OID	1.3.6.1.4.1.5835.3.1.4.1.266.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	packets	packets	0
		Expert Range (CU)	
		0 .. 4294967295	

Command IfAcmFwSigFetched		ACM fw sig fetched	ACM fw sig fetched
Location	/Modem/Monitor/Interfaces/Ethernet/ipencap/Signalling		
Description	Nbr of ACM fw signalling packets fetched.		
RMCP Command	asF	Access	Normal user : no access Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfAcmFwSigFetched	
	OID	1.3.6.1.4.1.5835.3.1.4.1.265.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	packets	packets	0
		Expert Range (CU)	
		0 .. 4294967295	

Command IfAcmRtSigRxed		ACM rt sig rxed	ACM rt sig rxed
Location	/Modem/Monitor/Interfaces/Ethernet/ipencap/Signalling		
Description	Number of ACM return signalling packets received.		
RMC Command	arr	Access	Normal user : no access Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfAcmRtSigRxed	
	OID	1.3.6.1.4.1.5835.3.1.4.1.268.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	packets	packets	0 .. 4294967295

Command IfAcmRtSigFetched		ACM rt sig fetched	ACM rt sig fetched
Location	/Modem/Monitor/Interfaces/Ethernet/ipencap/Signalling		
Description	Number of ACM return signalling packets fetched.		
RMC Command	arf	Access	Normal user : no access Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfAcmRtSigFetched	
	OID	1.3.6.1.4.1.5835.3.1.4.1.267.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	packets	packets	0 .. 4294967295

Command IfIbSigTxed		Inband sig txed	Inband sig txed
Location	/Modem/Monitor/Interfaces/Ethernet/ipencap/Signalling		
Description	Number of in-band signalling packets transmitted.		
RMC Command	ist	Access	Normal user : no access Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfIbSigTxed	
	OID	1.3.6.1.4.1.5835.3.1.4.1.269.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	packets	packets	0 .. 4294967295

/Modem/Monitor/Modulation

Command MoMonOutputFreq		Monitor output frequency		Monitor output freq.		
Location	/Modem/Monitor/Modulation					
Description	Readout of the modulator L-band monitoring output frequency.					
RMCP Command	MOF	Access		Normal user : R Expert user : R		
SNMP	Table	ntcDevsMod01ModulatorEntry				
	Command	ntcDevsMod01MoMonOutputFreq				
	OID	1.3.6.1.4.1.5835.3.1.3.1.18.1.1				
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	MHz	Hz	1.450.000.000	0 .. 990000000000		

Command MoMonSpectInv		Monitor out spec. inv.	Monitor out spec. in
Location	/Modem/Monitor/Modulation		
Description	Readout of the output spectrum polarity.		
RMCP Command	MOS		Access Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoMonSpectInv	
	OID	1.3.6.1.4.1.5835.3.1.3.1.19.1.1	
Values	Factory Default	Enumeration	Value
	directSpectrum	Direct spectrum Inverted spectrum	1 2

Command ODMeasPow		OD power supply	OD power supply
Location	/Modem/Monitor/Modulation		
Description	Monitored value of the power supply to power the outdoor unit. If the measured voltage is below +6V, the control command to enable/disable the outdoor unit power supply will be suppressed.		
RMCP Command	opm	Access	
SNMP	Table	ntcDevsMod01ODUEntry	
	Command	ntcDevsMod01ODMeasPow	
	OID	1.3.6.1.4.1.5835.3.1.14.1.15.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Volt	Volt	0 .. 26

Command InpRateEstim		Estimated input bitrate		Estim input bitrate		
Location	/Modem/Monitor/Modulation					
Description	Readout of the estimated input bitrate. The concentrator provides an estimate of the input bitrate on every input channel in order to help the operator in determining a suitable output bitrate. Remark: Only applicable when an auxiliary ASI board is installed.					
RMCP Command	DIR	Access		Normal user : R Expert user : R		
SNMP	Table	ntcDevsMod01ModulatorEntry				
	Command	ntcDevsMod01InpRateEstim				
	OID	1.3.6.1.4.1.5835.3.1.3.1.51.1.1				
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Mbps	bps	0	0 .. 4294967295		

Command MoBufCont		Buffer contents		Buffer contents		
Location	/Modem/Monitor/Modulation					
Description	Readout of the content of the FIFO buffer between the interface and the modulator part. The buffer content is expressed in % of the physical buffer size. <ul style="list-style-type: none"> In DVB-S operation :The buffer is re-centred in case of underflow or overflow. When the device operates with external transmit clock, then a PLL loop maintains the buffer contents at the nominal set point. For the lower bit-rates, the nominal set point is reduced in order to minimize overall delay.The nominal buffer set-points are:a) Set-point = 50% when 1 Mbit/s <= interface rate.b) Set-point = 25% when 200 kbit/s <= interface rate < 1 Mbit/s.c) Set-point = 12.5% when 50 kbit/s <= interface rate < 200 kbit/s. The actual buffer contents varies as function of the timing format of the baseband input transport stream (for a detailed explanation see timing format).In byte mode, the actual average buffer contents will be close to the nominal set-point. In packet mode, the actual average buffer contents will be about half a DVB packet (188/2 = 94 bytes) above the nominal set-point due to the bursty nature of this format. In DVB-S2 operation :In DVB-S2 mode, data buffering occurs both in the input FIFO buffer and in the baseband processing circuits. The large input FIFO is mainly present for the asynchronous (internal transmit clock or stuffing mode) operation, but can cause excessive processing delays in the synchronous slaved mode (external transmit clock) with short-frames. Therefore the nominal buffer set-point is no longer fixed but user-programmable via the MoBufSetup and MoBufFramSetup commands.Remark: In addition, a minimum-delay mode is included (see MoDlyMode) which initializes the baseband circuits for minimum delay operation. In this case the input buffer will remain empty. 					
RMCP Command	Tip	Access		Normal user : R Expert user : R		
SNMP	Table	ntcDevsMod01ModulatorEntry				
	Command	ntcDevsMod01MoBufCont				
	OID	1.3.6.1.4.1.5835.3.1.3.1.5.1.1				

Command MoBufCont		Buffer contents		Buffer contents
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	%	%	49	0 .. 100

Command MoBufSize		Input buffer size		Input buffer size		
Location	/Modem/Monitor/Modulation					
Description	Readout of the physical size of the FIFO buffer between the interface and the modulator part.					
RMCP Command	ibs	Access		Normal user : no access Expert user : R		
	Table	ntcDevsMod01ModulatorEntry				
	Command	ntcDevsMod01MoBufSize				
SNMP	OID	1.3.6.1.4.1.5835.3.1.3.1.6.1.1				
	Values	GUI Unit	Cmd Unit	Factory Default (CU) Expert Range (CU)		
		bytes	bytes	2048 0 .. 16384		

Command MoOutLevelDet		Modulator output level measurement		Output level msmt.		
Location	/Modem/Monitor/Modulation					
Description	Readout of the modulator measured output level which is expressed in dBm and measured with a resolution of 0.1 dBm.					
RMCP Command	old	Access		Normal user : R Expert user : R		
	Table	ntcDevsMod01ModulatorEntry				
	Command	ntcDevsMod01MoOutLevelDet				
SNMP	OID	1.3.6.1.4.1.5835.3.1.3.1.75.1.1				
	Values	GUI Unit	Cmd Unit	Factory Default (CU) Expert Range (CU)		
		dBm	dBm	-15 -50 .. -10		

Command MoTxOffs		Transmit clock offset		Tx clock offset		
Location	/Modem/Monitor/Modulation					
Description	Readout of the transmit clock offset. This is the offset (in ppm) between the configured symbol rate and the actual symbol rate when the device operates with external transmit clock. This offset indication is not applicable if the internal transmit clock is selected or if the transmit clock is not synchronised to the interface clock.					
RMCP Command	Trd	Access		Normal user : R Expert user : R		
	Table	ntcDevsMod01ModulatorEntry				

Command MoTxOffs		Transmit clock offset	Tx clock offset
	Command	ntcDevsMod01MoTxOffs	
	OID	1.3.6.1.4.1.5835.3.1.3.1.36.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	ppm	ppm	0
		Expert Range (CU)	-500 .. 500

Command MoPhaseErrDev		Modulator clock phase error deviation	Phase error deviation
Location	/Modem/Monitor/Modulation		
Description	Readout of the modulator clock phase error deviation expressed in nanosecond. The clock phase error deviation is the average value of rectified phase error.		
RMCP Command	ped	Access	Normal user : no access Expert user : R
	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoPhaseErrDev	
SNMP	OID	1.3.6.1.4.1.5835.3.1.3.1.80.1.1	
	Values	GUI Unit	Cmd Unit
	ns	ns	0
		Factory Default (CU)	Expert Range (CU)

Command MoDelaySetup		Delay setpoint	Delay setpoint
Location	/Modem/Monitor/Modulation		
	Only valid for mode ASI (TS) <-> Air (TS) (fixed delay).		
Description	Readout of the active delay set-point expressed in nanoseconds. When the modulator is operating with external transmit clock, the transmit clock is slaved to the incoming data frames via a PLL circuit. This variable presents the current operating point (set-point) of the PLL.		
RMCP Command	mds	Access	Normal user : no access Expert user : R
	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoDelaySetup	
SNMP	OID	1.3.6.1.4.1.5835.3.1.3.1.65.1.1	
	Values	GUI Unit	Cmd Unit
	ns	ns	0
		Factory Default (CU)	Expert Range (CU)

Command	clock loop state	
MoClkLoopState		
Location	/Modem/Monitor/Modulation	
Description	Readout of the state of the clock tracking loop on the modulator board.	
RMCP Command	Cls	Access Normal user : no access Expert user : R
SNMP	Table	ntcDevsMod01ModulatorEntry
	Command	ntcDevsMod01MoClkLoopState
	OID	1.3.6.1.4.1.5835.3.1.3.1.61.1.1
Values	Factory Default	Enumeration
	dump	Dump Acq Lock Hold
		0 1 2 3

Command	main acquisition state	
MoMainState		
Location	/Modem/Monitor/Modulation	
Description	Readout of the modulator current main acquisition state.	
RMCP Command	mas	Access Normal user : no access Expert user : R
SNMP	Table	ntcDevsMod01ModulatorEntry
	Command	ntcDevsMod01MoMainState
	OID	1.3.6.1.4.1.5835.3.1.3.1.74.1.1
Values	Factory Default	Enumeration
	setup	Setup Unsync FramSync TbSync FullSync InputSync BbSync PISync
		0 1 2 3 4 5 6 7

Command	Gain control state	
MoGainCtrlState		
Location	/Modem/Monitor/Modulation	
Description	Readout of the modulator output level (gain) control state. When gain control is set to automatic gain control and the gain loop is settling, the display will indicate settling. In this short time the output level will approach the requested level.	
RMCP Command	GcS	Access Normal user : no access Expert user : R
SNMP	Table	ntcDevsMod01ModulatorEntry

Command MoGainCtrlState		Gain control state	
	Command	ntcDevsMod01MoGainCtrlState	
	OID	1.3.6.1.4.1.5835.3.1.3.1.13.1.1	
Values	Factory Default	Enumeration	Value
	AGC	MGC Settling AGC	0 1 2

Command MoTxStatus		Tx On			
Location	/Modem/Monitor/Modulation				
Description	Readout of the current transmit status. In case of a modulator, this status indication is used to drive the Tx On LED.				
RMCP Command	txs		Access		
SNMP	Table	ntcDevsMod01ModulatorEntry			
	Command	ntcDevsMod01MoTxStatus			
	OID	1.3.6.1.4.1.5835.3.1.3.1.37.1.1			
Values	Factory Default	Enumeration	Value		
	tx_off	OFF ON	0 1		

/Modem/Monitor/Modulation/Packets

Only valid for DVB-S2 modes.

Command MoInpPacketCnt		Input Packet count			
Location	/Modem/Monitor/Modulation/Packets				
Description	Input packet count. Readout of the total number of packets received by the modulator board on the interface of the gigabit Ethernet interface board since the last reset of the counters.				
RMCP Command	ipc	Access	Normal user : R Expert user : R		
SNMP	Table	ntcDevsMod01ModulatorEntry			
	Command	ntcDevsMod01MoInpPacketCnt			
	OID	1.3.6.1.4.1.5835.3.1.3.1.71.1.1			
Values	GUI Unit	Cmd Unit	Factory Default (CU)		
	NA	NA	0 .. 4294967295		

Command MoInpPacketRate		Input packetrate	Input packetrate
Location	/Modem/Monitor/Modulation/Packets		
Description	Readout of the estimated input packet rate expressed in packets per second.		
RMCP Command	ipr	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoInpPacketRate	
	OID	1.3.6.1.4.1.5835.3.1.3.1.72.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	pps	pps	0
			-1e+38 .. 1e+38

Command MoPacketRate		Estimated packetrate	Estimated packetrate
Location	/Modem/Monitor/Modulation/Packets		
Description	Readout of the estimated packet rate in packets per second.		
RMCP Command	mpo	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoPacketRate	
	OID	1.3.6.1.4.1.5835.3.1.3.1.79.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	pps	pps	0
			-1e+38 .. 1e+38

Command MoPacketCnt		Packet count	Packet count
Location	/Modem/Monitor/Modulation/Packets		
Description	Readout of the monitored packet count. All baseband packets on the modulator are counted.		
RMCP Command	mpc	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoPacketCnt	
	OID	1.3.6.1.4.1.5835.3.1.3.1.78.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	NA	NA	0 .. 4294967295

Command MoCntRst		Packet counters reset	Packet counters rst
Location	/Modem/Monitor/Modulation/Packets		
Description	Command to reset the packet counters. Click on "all" to reset the statistics counter described in the tables.		
RMCP Command	mcr		Access Normal user : no access Expert user : W
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoCntRst	
	OID	1.3.6.1.4.1.5835.3.1.3.1.62.1.1	
Values	Factory Default All		Enumeration Value 0

/Modem/Monitor/Modulation/Frames



Only valid for DVB-S2 modes.

Command MoDummyPLRate		Dummy Physical Layer frame-rate	Dummy PL rate
Location	/Modem/Monitor/Modulation/Frames		
Description	Readout of the dummy physical layer frames per second.		
RMCP Command	dfr	Access Normal user : R Expert user : R	
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoDummyPLRate	
	OID	1.3.6.1.4.1.5835.3.1.3.1.68.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU) fps 0
			Expert Range (CU) -1e+38 .. 1e+38

Command MoDummyPLCnT		Dummy Physical Layer frame-count	Dummy PL count
Location	/Modem/Monitor/Modulation/Frames		
Description	Readout of the total number of inserted dummy physical layer frames since the last reset of the counters.		
RMCP Command	dfc	Access Normal user : R Expert user : R	
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoDummyPLCnT	
	OID	1.3.6.1.4.1.5835.3.1.3.1.67.1.1	

Command MoDummyPLCnt		Dummy Physical Layer frame-count		Dummy PL count
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	NA	NA	0	0 .. 4294967295

Command MoPLEfficiency		Physical layer efficiency	PL efficiency
Location	/Modem/Monitor/Modulation/Frames		
Description	Readout of the physical layer efficiency of the DVB-S2 modulator. The physical layer efficiency is expressed in % and is calculated as the ratio between dummy physical layer frame symbol rate and available symbol rate. It is 100 % when no dummy physical layer frames are inserted.		
RMCP Command	ple	Access	
SNMP	Table Command OID	ntcDevsMod01ModulatorEntry ntcDevsMod01MoPLEfficiency 1.3.6.1.4.1.5835.3.1.3.1.76.1.1	
Values	GUI Unit %	Cmd Unit %	Factory Default (CU) 0 Expert Range (CU) 0 .. 100

Command MoBBLEfficiency		Baseband layer efficiency	BBL efficiency
Location	/Modem/Monitor/Modulation/Frames		
Description	Readout of the baseband layer efficiency of the DVB-S2 modulator. The baseband layer efficiency is expressed in % and is calculated as the ratio between used payload bytes and available payload bytes within the baseband frames. In other words, it represents the filling level of the DVB-S2 baseband frames.		
RMCP Command	ble	Access	
SNMP	Table Command OID	ntcDevsMod01ModulatorEntry ntcDevsMod01MoBBLEfficiency 1.3.6.1.4.1.5835.3.1.3.1.56.1.1	
Values	GUI Unit %	Cmd Unit %	Factory Default (CU) 0 Expert Range (CU) 0 .. 100

Command MoBBShortFrameRatio		Short frames	Short frames
Location	/Modem/Monitor/Modulation/Frames		
Description	Readout of the ratio of short-frames in the DVB-S2 modulator. It is expressed in % and is calculated as the ratio of short-frames over the total (optionally filtered) baseband frames.		
RMCP Command	sfr	Access	
SNMP	Table	ntcDevsMod01ModulatorEntry	

Command MoBBShortFrameRatio		Short frames	Short frames
Values	Command	ntcDevsMod01MoBBShortFrameRatio	
	OID	1.3.6.1.4.1.5835.3.1.3.1.57.1.1	
GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
%	%	0	0 .. 100

/Modem/Monitor/Modulation/ACM control

Command MoAcmDiagLog		ACM status	ACM status	
Location	/Modem/Monitor/Modulation/ACM control			
Description	Readout of the ACM controller diagnostics.			
RMCP Command	amb		Access	
SNMP	Table	ntcDevsMod01ModulatorEntry		
	Command	ntcDevsMod01MoAcmDiagLog		
	OID	1.3.6.1.4.1.5835.3.1.3.1.130.1.1		
Values	Factory Default	String Description		
		length : 0 .. 60 format : any chars		

Command MoAcmDemodLog		ACM current log	ACM current log	
Location	/Modem/Monitor/Modulation/ACM control			
Description	Readout of the current ACM controller log.			
RMCP Command	amd		Access	
SNMP	Table	ntcDevsMod01ModulatorEntry		
	Command	ntcDevsMod01MoAcmDemodLog		
	OID	1.3.6.1.4.1.5835.3.1.3.1.127.1.1		
Values	Factory Default	String Description		
		length : 0 .. 60 format : any chars		

Structured Command MoMonAcmDmSupvEntry		ACM demodulator monitoring table	Demod table
Location	/Modem/Monitor/Modulation/ACM control		
Description	Monitoring parameters for ACM enabled demodulators.		
RMCP Command	adm array : [1 .. 10]		Access

SNMP	Table	ntcDevsMod01ModulatorEntry
------	-------	----------------------------

Structured Command MoMonAcmDmSupvEntry		ACM demodulator monitoring table	Demod table
	Command	ntcDevsMod01MoMonAcmDmSupvEntry	
	OID	1.3.6.1.4.1.5835.3.1.3.1.159.1.1.[1 .. 10]	
Variables			Page
MoMonAcmDmSupvlp			226
MoMonAcmDmSupvStrid			226
MoMonAcmDmSupvEsno			227
MoMonAcmDmSupvModcod			227
MoMonAcmDmSupvNumRx			228
MoMonAcmDmSupvNumTo			228
MoMonAcmDmSupvNumCto			228

Structured Command MoMonAcmStreamEntry		ACM stream monitoring table	Stream table
Location	/Modem/Monitor/Modulation/ACM control		
Description	ACM stream monitoring entry.		
RMCP Command	asm array : [1 .. 35]	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoMonAcmStreamEntry	
	OID	1.3.6.1.4.1.5835.3.1.3.1.160.1.1.[1 .. 35]	
Variables			Page
MoMonAcmStreamStrid			225
MoMonAcmStreamFrameType			225
MoMonAcmStreamNChanges			225
MoMonAcmStreamModcod			225

Command MoAcmDemodLogToday		ACM history logs today	ACM history logs tod
Location	/Modem/Monitor/Modulation/ACM control		
Description	Readout of the history ACM controller logs of today.		
RMCP Command	amt	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoAcmDemodLogToday	
	OID	1.3.6.1.4.1.5835.3.1.3.1.128.1.1	
Values	Factory Default	String Description	
		length : 0 .. 200 format : any chars	

Command	ACM history logs yesterday		ACM history logs yes
Location	/Modem/Monitor/Modulation/ACM control		
Description	Readout of the history ACM controller logs of yesterday.		
RMC Command	amy	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoAcmDemodLogYestrD	
	OID	1.3.6.1.4.1.5835.3.1.3.1.129.1.1	
Values	Factory Default	String Description	
		length : 0 .. 200 format : any chars	

/Modem/Monitor/Demodulation

Structured Command		Receive level	Receive level
DmMeasAGCStruct			
Location	/Modem/Monitor/Demodulation		
Description	Readout of the receive level as derived from the automatic gain control (AGC) circuits of the front-end or in other words, the RF input level measured on the demodulator board.		
RMC Command	RSI	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmMeasAGCStruct	
	OID	1.3.6.1.4.1.5835.3.1.13.1.36.1.1	
Variables			Page
DmMeasAGCSat			174
DmMeasAGC			174

Structured Command		Input level	Input level
DmMeasAGCCoStruct			
Location	/Modem//Monitor/Demodulation		
Description	Readout of the power spectral density measured on the demodulator board. This is calculated from the received level minus 10xlog (symbol rate).		
RMC Command	RSc	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmMeasAGCCoStruct	
	OID	1.3.6.1.4.1.5835.3.1.13.1.34.1.1	

Structured Command DmMeasAGCCoStruct	Input level	Input level
Variables		Page
DmMeasAGCCoSat		174
DmMeasAGCCo		175

Structured Command DmMeasEbNoStruct	Eb/No estimation	Eb/No estimation
Location	/Modem/Monitor/Demodulation	
Description	Readout of the DVB-S demodulator channel Eb/No estimation. This Eb/No estimation is based on a symbol noise estimation. This estimation is calculated on all symbols, but is not very accurate (+/- 1dB). This variable is the concatenation of DmMeasEbNoSat and DmMeasEbNo .	
RMC Command	RSe	Access Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry
	Command	ntcDevsMod01DmMeasEbNoStruct
	OID	1.3.6.1.4.1.5835.3.1.13.1.38.1.1
Variables		Page
DmMeasEbNoSat		168
DmMeasEbNo		168

Command DmMPegCrcErrs	MPEG CRC errors	MPEG CRC errors
Location	/Modem/Monitor/Demodulation	
Description	Readout of the total counted MPEG errors. These accumulated counter can be reset by using the command for resetting counters.	
RMC Command	McE	Access Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry
	Command	ntcDevsMod01DmMPegCrcErrs
	OID	1.3.6.1.4.1.5835.3.1.13.1.47.1.1
Values	GUI Unit	Cmd Unit
		Factory Default (CU)
		0 .. 4294967295

Command DmMeasCarOff	Carrier frequency offset	Carrier freq. offset
Location	/Modem/Monitor/Demodulation	
Description	Readout of the measured carrier frequency offset in Hz of the received carrier frequency against the selected receive frequency.	
RMC Command	Rfd	Access Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry

Command DmMeasCarOff		Carrier frequency offset		Carrier freq. offset
	Command	ntcDevsMod01DmMeasCarOff		
	OID	1.3.6.1.4.1.5835.3.1.13.1.17.1.1		
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Hz	Hz	13.200	-1e+38 .. 1e+38

Command DmMeasClk		Symbol rate offset	Symbol rate offset	
Location	/Modem/Monitor/Demodulation			
Description	Readout of the measured offset in baud between the received symbol rate and the selected symbol rate.			
RMCP Command	Rrd	Access	Normal user : R Expert user : R	
	SNMP	Table	ntcDevsMod01DemodulatorEntry	
		Command	ntcDevsMod01DmMeasClk	
Values	OID	1.3.6.1.4.1.5835.3.1.13.1.18.1.1		
		GUI Unit	Cmd Unit	Factory Default (CU)
		baud	baud	132
		-1e+38 .. 1e+38		

Command DmMeasClkPpm		Symbol rate offset	Symbol rate offset	
Location	/Modem/Monitor/Demodulation			
Description	Readout of the measured offset in parts per million (ppm) between the received symbol rate and the selected symbol rate.			
RMCP Command	Rrp	Access	Normal user : R Expert user : R	
	SNMP	Table	ntcDevsMod01DemodulatorEntry	
		Command	ntcDevsMod01DmMeasClkPpm	
Values	OID	1.3.6.1.4.1.5835.3.1.13.1.39.1.1		
		GUI Unit	Cmd Unit	Factory Default (CU)
		ppm	ppm	132
		-1e+38 .. 1e+38		

Structured Command DmMeasEsNoStruct		Header Es/No estimation	Header Es/No estimat
Location	/Modem/Monitor/Demodulation		
Description	<p>This command reads out the concatenation of DmMeasEsNoSat and DmMeasEsNo. All DVB-S2 demodulators have an integrated Es/No estimator. Their Es/No estimation is made on the physical layer header symbols. Because it is done on known BPSK symbols, it is more accurate (+/- 0.3dB typically in a linear channel) than the DVB-S Eb/No estimation. But this header estimation has some consequences:</p> <ul style="list-style-type: none"> • It does not take into account some distortions on higher modulations, especially on 16APSK and 32APSK, due to saturation in amplifiers working with minimal output back off. BPSK signals are much less influenced by these non-linear effects of saturation. • There are only 90 header symbols/baseband frame of minimum 2K and maximum 32K symbols. Averaging the noise on many headers is required to have some stable reading. The header Es/No estimation is rather slow at lower symbol rates. • All non compensated disturbances are measured on the demodulated header symbols. Saturation and group delay distortion can cause a large difference compared to the Es/No measured with a spectrum analyser. This is typically the case with a high group delay distortion and high Es/No. • With the equalizer function enabled, group delay distortions are better compensated on the NTC/7044 than on the NTC/7062 board and Es/No indication is more accurate. Remark: The Es/No indication ranges from -2 dB to + 24 dB. 		
RMC Command	REs	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmMeasEsNoStruct	
	OID	1.3.6.1.4.1.5835.3.1.13.1.50.1.1	
Variables		Page	
DmMeasEsNoSat			189
DmMeasEsNo			189

Structured Command DmEstLinMarStruct		Link Margin Estimate	Link Margin Estimate
Location	/Modem/Monitor/Demodulation		
Description	<p>Readout of the indication of the receive margin before reaching the threshold point of a quasi error free operation (QEF) operation. In DVB-S, the Eb/No for quasi error free operation is taken from the DVB standards EN300421 and EN301210. Basically it is the margin in dB that subtracting the modcod dependenta signal can decrease in Eb/No before errors will have noticeable effects on the output transport stream. In DVB-S2, the link margin is derived from the true C/N value, including both linear and non-linear distortion.</p>		
RMC Command	Lms	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmEstLinMarStruct	

Structured Command DmEstLinMarStruct		Link Margin Estimate	Link Margin Estimate
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.13.1.75.1.1	
Variables			Page
DmEstLinMarSat			190
DmEstLinMar			190

Command DmFrameTypeStat		FEC-frame type detect	Frame type
Location	/Modem/Monitor/Demodulation		
Description		Reads out of the detected DVB-S2 FEC-frame type. DVB-S2 defines two FEC-frame types : <ul style="list-style-type: none">• Normal: FEC-frames of 64800 bits or 8100 bytes.• Short: FEC-frames of 16200 bits or 2025 bytes.	
RMCP Command		Acf	Access Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmFrameTypeStat	
	OID	1.3.6.1.4.1.5835.3.1.13.1.56.1.1	
Values	Factory Default	Enumeration	Value
	short	Short Normal	

Command DmFECDemodStat		Actual FEC-rate and modulation	Actual FEC-rate and
Location	/Modem/Monitor/Demodulation		
Description		Readout of the actual value of the forward error correction coding & modulation.	
RMCP Command		Rmx	Access Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmFECDemodStat	
	OID	1.3.6.1.4.1.5835.3.1.13.1.12.1.1	
Values	Factory Default	Enumeration	Value
	Dummy PLFRAMES	0	
	QPSK modulation -- no FEC (Skyplex only)	10	
	QPSK modulation -- rate 1/2 * 188/204	11	
	QPSK modulation -- rate 2/3 * 188/204	12	
	QPSK modulation -- rate 3/4 * 188/204	13	
	QPSK modulation -- rate 5/6 * 188/204	15	
	QPSK modulation -- rate 6/7 * 188/204	16	
	QPSK modulation -- rate 7/8 * 188/204	17	
	QPSK-1/4	21	
	QPSK-1/3	22	
	QPSK-2/5	23	

Command	Actual FEC-rate and modulation	Actual FEC-rate and
DmFECDemodStat		
	QPSK-3/5	24
	QPSK-4/5	25
	QPSK-8/9	26
	QPSK-9/10	27
	16APSK-2/3	42
	16APSK-3/4	43
	16APSK-4/5	44
	16APSK-5/6	45
	16APSK-8/9	48
	16APSK-9/10	49
	32APSK-3/4	53
	32APSK-4/5	54
	32APSK-5/6	55
	32APSK-8/9	58
	32APSK-9/10	59
	16QAM modulation -- no FEC (Skyplex only)	60
	16 QAM modulation -- rate 1/2 * 188/204	61
	16 QAM modulation -- rate 2/3 * 188/204	62
	16 QAM modulation -- rate 3/4 * 188/204	63
	16 QAM modulation -- rate 5/6 * 188/204	65
	16 QAM modulation -- rate 6/7 * 188/204	66
	16 QAM modulation -- rate 7/8 * 188/204	67
	16 QAM modulation -- rate 8/9 * 188/204	68
	8PSK modulation -- no FEC (Skyplex only)	80
	8PSK modulation -- rate 3/5 * 188/204	81
	8PSK modulation -- rate 2/3 * 188/204	82
	8PSK modulation -- rate 3/4 * 188/204	83
	8PSK modulation -- rate 5/6 * 188/204	85
	8PSK modulation -- rate 6/7 * 188/204	86
	8PSK modulation -- rate 7/8 * 188/204	87
	8PSK modulation -- rate 8/9 * 188/204	88
	8PSK-9/10	89

/Modem/Monitor/Demodulation/ModCodStats**/Modem/Monitor/Demodulation/ModCodStats/Demodulator S2 statistics**

Structured Command	Demodulator S2 statistics	Demodulator S2 stati
DmModCodStatStruct		
Location	/Modem/Monitor/Demodulation/ModCodStats/Demodulator S2 statistics	
Description	Readout of the modulation and coding statistics table.	
RMCP Command	Mss array : [1 .. 16]	Access Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorExtEntry
	Command	ntcDevsMod01DmModCodStatStruct
	OID	1.3.6.1.4.1.5835.3.1.13000.1.4.1.1.[1 .. 16]
Variables		
DmModCodStatModCod		
DmModCodStatFrameType		
	Page	
		168
		170

Structured Command DmModCodStatStruct	Demodulator S2 statistics	Demodulator S2 stati
DmModCodStatPilots		170
DmModCodStatFrameCnt		170
DmModCodStatUncorCnt		171
DmModCodStatSat		171
DmModCodStatChQEst		172
DmModCodStatChCDSat		172
DmModCodStatChCD		172
DmModCodStatChDistQEFSat		173
DmModCodStatChDistQEF		173

/Modem/Monitor/Demodulation/ACM client

Command DmAcmClientPoll	ACM poll		ACM poll
Location	/Modem/Monitor/Demodulation/ACM client		
Description	Readout of the latest ACM client poll message, that was received via the signalling channel.		
RMC Command	acp	Access	Normal user : no access Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmAcmClientPoll	
	OID	1.3.6.1.4.1.5835.3.1.13.1.101.1.1	
Values	Factory Default	String Description	
		length : 0 .. 200 format : any chars	

Command DmAcmClientEsnoVariation	Fading prediction		Fading prediction
Location	/Demodulator/Monitor/Demodulation/ACM client		
Description	Fading prediction value.		
RMC Command	hev	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmAcmClientEsnoVariation	
	OID	1.3.6.1.4.1.5835.3.1.13.1.128.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
			0
			-5 .. 50

Command DmAcmClientFeedback		ACM feedback			
Location	/Modem/Monitor/Demodulation/ACM client				
Description	Readout of the latest ACM client feedback string sent to the ACM controller.				
RMCP Command	acF	Access	Normal user : no access Expert user : R		
SNMP	Table	ntcDevsMod01DemodulatorEntry			
	Command	ntcDevsMod01DmAcmClientFeedback			
	OID	1.3.6.1.4.1.5835.3.1.13.1.97.1.1			
Values	Factory Default	String Description			
		length : 0 .. 200 format : any chars			

Command DmAcmClientLog		ACM log			
Location	/Modem/Monitor/Demodulation/ACM client				
Description	Readout of the ACM client log-file. The ACM client log keeps track of the following items: time stamp, Es/No, link margin referenced, requested modcod. The ACM client log-file has .csv as file-type. Remark: <ul style="list-style-type: none">• Link margin referenced: This is a fixed value for a given coding and modulation.• (s) = Short frames.• (n) = Normal frames.				
RMCP Command	acl	Access	Normal user : R Expert user : R		
SNMP	Table	ntcDevsMod01DemodulatorEntry			
	Command	ntcDevsMod01DmAcmClientLog			
	OID	1.3.6.1.4.1.5835.3.1.13.1.98.1.1			
Values	Factory Default	String Description			
		length : 0 .. 60 format : any chars			

Command DmAcmClientLogToday		ACM logs today			
Location	/Modem/Monitor/Demodulation/ACM client				
Description	Readout of the ACM client log-file of today.				
RMCP Command	act	Access	Normal user : R Expert user : R		
SNMP	Table	ntcDevsMod01DemodulatorEntry			
	Command	ntcDevsMod01DmAcmClientLogToday			
	OID	1.3.6.1.4.1.5835.3.1.13.1.99.1.1			
Values	Factory Default	String Description			

Command DmAcmClientLogToday		ACM logs today	ACM logs today
		length : 0 .. 120 format : any chars	
Command DmAcmClientLogYesterday		ACM logs yesterday	ACM logs yesterday
Location	/Modem/Monitor/Demodulation/ACM client		
Description	Readout of the ACM client log-file of yesterday.		
RMC Command	acy	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmAcmClientLogYesterday	
	OID	1.3.6.1.4.1.5835.3.1.13.1.100.1.1	
Values	Factory Default	String Description	
		length : 0 .. 120 format : any chars	

Config

In the configuration menu you can save and load up to 48 different operational configurations in permanent memory. You can define a configuration as the group of all device configuration parameters that can be set in the IP Satellite Modem. Only global system parameters are not saved in a configuration since they are written in permanent memory at the moment that they are set/changed. They are parameters that are common to all configurations such as: Device mode, RCMP version, Display contrast. Serial interface type, Device RCMP address, Serial baudrate, Device IP address, Device IP mask, Default gateway and Ethernet interface Alarm mode (normal, masked and forced). All other parameters are configuration parameters that can differ in the different stored configurations.



The config tab is not displayed in the tree view of the Graphical user interface (GUI). This function is located in the Function controls window of the GUI under the tab config.
We refer to the explanation of the GUI in the user manual of this device.

Special Command SyConfigLoadFlash		Load	Load
Location	/Config		
Description	Command used to load a configuration from permanent memory. Up to 48 different configurations can be loaded, however only valid configurations that have been previously saved by the operator can be loaded. The default boot configuration must always be stored in configuration 0 since this is the one that is loaded when the device (re)-boots. The top row on the LCD display indicates the last loaded configuration by the name given by the operator to the configuration number. Remark specific to modulators: Only the default boot configuration can store the status of L-band (IF) transmit since it is required that transmission resumes if there was an (accidental) power outage. Remember that in that case the default configuration 0 is loaded. The other configurations will save the transmit status as disabled and the operator will have to verify all parameters before enabling transmit to go on-air.		
RMCP Command	LCF	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyConfigLoadFlash	
	OID	1.3.6.1.4.1.5835.3.1.1.1.3.1.1	
Get Command Arguments		Set Command Arguments	
Command(s) / Variable(s)		Page	Command(s) / Variable(s)
none		SyConfigNum	230
Get Reply Values		Set Reply Values	
Command(s) / Variable(s)		Page	Command(s) / Variable(s)
SyLoadConfNum		231	SyConfigStatus
		230	

Special Command SyConfigSaveFlash	Save	Save
Location	/Config	
Description	Configuration command to save a configuration to permanent memory. Up to 48 different configurations can be saved. Remember that the default boot configuration has to be saved in configuration 0 since this is the one that is loaded when the device (re)-boots.	
RMCP Command	SCF	Access Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01SystemEntry
	Command	ntcDevsMod01SyConfigSaveFlash
	OID	1.3.6.1.4.1.5835.3.1.1.1.4.1.1
Get Command Arguments		Set Command Arguments
Command(s) / Variable(s)	Page	Command(s) / Variable(s)
none	none	SyConfigNum
Get Reply Values		Set Reply Values
Command(s) / Variable(s)	Page	Command(s) / Variable(s)
SySaveConfNum	231	SyConfigStatus

Special Command SyCfgName	Name	Name
Location	/Config	
Description	Configuration command for the configuration's name. The configuration name will be displayed on the front panel in order to allow easier identification of a certain saved configuration.	
RMCP Command	SCn	Access Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01SystemEntry
	Command	ntcDevsMod01SyCfgName
	OID	1.3.6.1.4.1.5835.3.1.1.1.58.1.1
Get Command Arguments		Set Command Arguments
Command(s) / Variable(s)	Page	Command(s) / Variable(s)
SyConfigNum	230	SyConfigNum SyConfigName
Get Reply Values		Set Reply Values
Command(s) / Variable(s)	Page	Command(s) / Variable(s)
SyConfigNum SyConfigName	230 231	SyConfigStatus

Structured Elements with Individual Access

Command DmMeasEbNoSat		Eb/No level clipping info		Eb/No lvl clipping			
Used as variable of	Command(s)			Page			
	DmMeasEbNoStruct			158			
Description	Readout of the Eb/No level clipping information. When reading saturated values for the Eb/No estimation, the clipping information will identify the direction of saturation or return equal if the value is within range.						
RMCP Command	Rse		Access	Normal user : R Expert user : R			
SNMP	Table	ntcDevsMod01DemodulatorEntry					
	Command	ntcDevsMod01DmMeasEbNoSat					
	OID	1.3.6.1.4.1.5835.3.1.13.1.37.1.1					
Values	Factory Default		Enumeration	Value			
	equal			0			
	>			1			
	<			2			

Command DmMeasEbNo		Eb/No estimation		Eb/No estimation			
Used as variable of	Command(s)			Page			
	DmMeasEbNoStruct			158			
Description	Readout of the Eb/No estimation in dB of the received signal.						
RMCP Command	Rle	Access			Normal user : R Expert user : R		
SNMP	Table	ntcDevsMod01DemodulatorEntry					
	Command	ntcDevsMod01DmMeasEbNo					
	OID	1.3.6.1.4.1.5835.3.1.13.1.19.1.1					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)			
	dB	dB	9.83	0 .. 25			

Command DmModCodStatModCod		FEC-rate and modulation		FEC-rate and mod.			
Used as variable of	Command(s)			Page			
	DmModCodStatStruct			162			
Description	Readout of the actual value of the forward error correction coding and modulation.						
RMCP Command	Msx		Access	Normal user : R Expert user : R			

Command DmModCodStatModCod		FEC-rate and modulation	FEC-rate and mod.
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmModCodStatModCod	
	OID	1.3.6.1.4.1.5835.3.1.13.1.69.1.1	
Values	Factory Default	Enumeration	Value
	QPSK-3/4	Dummy PLFRAMES QPSK modulation -- no FEC (Skyplex only) QPSK modulation -- rate 1/2 * 188/204 QPSK modulation -- rate 2/3 * 188/204 QPSK modulation -- rate 3/4 * 188/204 QPSK modulation -- rate 5/6 * 188/204 QPSK modulation -- rate 6/7 * 188/204 QPSK modulation -- rate 7/8 * 188/204 QPSK-1/4 QPSK-1/3 QPSK-2/5 QPSK-3/5 QPSK-4/5 QPSK-8/9 QPSK-9/10 16APSK-2/3 16APSK-3/4 16APSK-4/5 16APSK-5/6 16APSK-8/9 16APSK-9/10 32APSK-3/4 32APSK-4/5 32APSK-5/6 32APSK-8/9 32APSK-9/10 16QAM modulation -- no FEC (Skyplex only) 16 QAM modulation -- rate 1/2 * 188/204 16 QAM modulation -- rate 2/3 * 188/204 16 QAM modulation -- rate 3/4 * 188/204 16 QAM modulation -- rate 5/6 * 188/204 16 QAM modulation -- rate 6/7 * 188/204 16 QAM modulation -- rate 7/8 * 188/204 16 QAM modulation -- rate 8/9 * 188/204 8PSK modulation -- no FEC (Skyplex only) 8PSK modulation -- rate 3/5 * 188/204 8PSK modulation -- rate 2/3 * 188/204 8PSK modulation -- rate 3/4 * 188/204 8PSK modulation -- rate 5/6 * 188/204 8PSK modulation -- rate 6/7 * 188/204 8PSK modulation -- rate 7/8 * 188/204 8PSK modulation -- rate 8/9 * 188/204 8PSK-9/10	0 10 11 12 13 15 16 17 21 22 23 24 25 26 27 42 43 44 45 48 49 53 54 55 58 59 60 61 62 63 65 66 67 68 80 81 82 83 85 86 87 88 89

Command DmModCodStatFrameType		Frame type	Frame type
Used as variable of	Command(s)		Page
	DmModCodStatStruct		162
Description	Readout of the DVB-S2 forward error correction (FEC) frame type detected after reception: <ul style="list-style-type: none"> • Normal: FEC-frames of 64800 bits or 8100 bytes. • Short: FEC-frames of 16200 bits or 2025 bytes. 		
RMC Command	Msl	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmModCodStatFrameType	
	OID	1.3.6.1.4.1.5835.3.1.13.1.68.1.1	
Values	Factory Default	Enumeration	Value
	short	Short Normal	0 1

Command DmModCodStatPilots		Pilots	Pilots
Used as variable of	Command(s)		Page
	DmModCodStatStruct		162
Description	Readout of the actual value of the DVB-S2 physical layer pilot detection.		
RMC Command	Msp	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmModCodStatPilots	
	OID	1.3.6.1.4.1.5835.3.1.13.1.70.1.1	
Values	Factory Default	Enumeration	Value
	off	Off On	0 1

Command DmModCodStatFrameCnt		BB frame count	BB frame count
Used as variable of	Command(s)		Page
	DmModCodStatStruct		162
Description	Readout of the number of decoded baseband frames.		
RMC Command	Msf	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmModCodStatFrameCnt	
	OID	1.3.6.1.4.1.5835.3.1.13.1.67.1.1	

Command DmModCodStatFrameCnt		BB frame count		BB frame count
Values	<i>GUI Unit</i>	<i>Cmd Unit</i>	<i>Factory Default (CU)</i>	<i>Expert Range (CU)</i>
	frames	frames	0	0 .. 65535

Command DmModCodStatUncorCnt		Uncorrectable frame count	Uncor frame count
Used as variable of	<i>Command(s)</i>	<i>Page</i>	
	DmModCodStatStruct	162	
Description	Readout of the number of uncorrectable baseband frames.		
RMC Command	Msu	Access	Normal user : R Expert user : R
SNMP	<i>Table</i>	ntcDevsMod01DemodulatorEntry	
	<i>Command</i>	ntcDevsMod01DmModCodStatUncorCnt	
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.13.1.72.1.1	
Values	<i>GUI Unit</i>	<i>Cmd Unit</i>	<i>Factory Default (CU)</i>
	frames	frames	0
			0 .. 65535

Command DmModCodStatSat		Channel Es/No clipping info	Ch Es/No clipping
Used as variable of	<i>Command(s)</i>	<i>Page</i>	
	DmModCodStatStruct	162	
Description	Readout the channel quality estimation information of saturated values. The clipping info will identify the direction of saturation or return equal if the value is within range.		
RMC Command	Mqs	Access	Normal user : R Expert user : R
SNMP	<i>Table</i>	ntcDevsMod01DemodulatorEntry	
	<i>Command</i>	ntcDevsMod01DmModCodStatSat	
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.13.1.71.1.1	
Values	<i>Factory Default</i>	<i>Enumeration</i>	<i>Value</i>
	equal	> < *	0 1 2 3

Command DmModCodStatChQEst		Channel quality est		Channel quality est			
Used as variable of	Command(s)			Page			
	DmModCodStatStruct			162			
Description	Readout of the channel quality estimate. The channel quality estimation shows the Es/No minus the link margin estimation and is a measure for the Es/No including the effects of distortion whereas the Es/No only sees the C/N (as observed on a spectrum analyser) but without being able to take into account the effects of in-band distortion.						
RMCP Command	Msq	Access			Normal user : R Expert user : R		
	SNMP	Table	ntcDevsMod01DemodulatorEntry				
		Command	ntcDevsMod01DmModCodStatChQEst				
Values	OID	1.3.6.1.4.1.5835.3.1.13.1.66.1.1					
		GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
		dB	dB	0	-999.9 .. 999.9		

Command DmModCodStatChCDSat		C/D clipping		C/D clipping			
Used as variable of	Command(s)			Page			
	DmModCodStatStruct			162			
Description	Readout of the saturation indication of the C/D (carrier to distortion) value. An asterisk will be shown when the C/D values saturates. This is the result of a saturated channel quality estimate value.						
RMCP Command	MsS		Access	Normal user : R Expert user : R			
	SNMP	Table	ntcDevsMod01DemodulatorEntry				
		Command	ntcDevsMod01DmModCodStatChCDSat				
Values	OID	1.3.6.1.4.1.5835.3.1.13.1.78.1.1					
		Factory Default	Enumeration	Value			
		equal	*	0	1		

Command DmModCodStatChCD		C/D est		C/D est			
Used as variable of	Command(s)			Page			
	DmModCodStatStruct			162			
Description	Readout of the signal to (non-linear) distortion ratio estimate.						
RMCP Command	Mse	Access			Normal user : R Expert user : R		
	SNMP	Table	ntcDevsMod01DemodulatorEntry				
		Command	ntcDevsMod01DmModCodStatChCD				

Command DmModCodStatChCD		C/D est		C/D est
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.13.1.76.1.1		
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	dB	dB	0	-999.9 .. 999.9

Command DmModCodStatChDist QEFSat		Link margin clipping info	Link margin clipping info
Used as variable of	Command(s)		Page
	DmModCodStatStruct		162
Description	Readout of the link margin clipping information. It gives an indication of a clipped link margin when the channel quality value saturates to a maximum.		
RMCP Command	MqS		Access Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmModCodStatChDistQEFSat	
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.13.1.79.1.1	
Values	Factory Default	Enumeration	Value
	equal	*	0
		<	1
			2

Command DmModCodStatChDistQEF		Link margin est	Link margin est
Used as variable of	Command(s)		Page
	DmModCodStatStruct		162
Description	Readout of the link margin estimator. It gives an indication of the receive margin before reaching the threshold point of quasi error free operation. It is derived from the true C/N (carrier to noise) value, including both linear and non-linear distortion. This values is an estimate.		
RMCP Command	Msd	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmModCodStatChDistQEF	
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.13.1.65.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	frames	frames	0
			-999.9 .. 999.9

Command DmMeasAGCSat		AGC level clipping info	AGC lvl clipping	
Used as variable of	Command(s)			Page
	DmMeasAGCStruct			157
Description	Readout of the automatic gain control (AGC) level clipping information. When reading saturated values for the receive level, the clipping info will identify the direction of saturation or return equal if the receive level is within range.			
RMC Command	Rsl			Access Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry		
	Command	ntcDevsMod01DmMeasAGCSat		
	OID	1.3.6.1.4.1.5835.3.1.13.1.35.1.1		
Values	Factory Default		Enumeration	Value
	equal		>	0
	>		<	1
	<			2

Command DmMeasAGC		Receive level	Receive level	
Used as variable of	Command(s)			Page
	DmMeasAGCStruct			157
Description	Readout of the receive level expressed in dBm.			
RMC Command	Rll	Access		Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry		
	Command	ntcDevsMod01DmMeasAGC		
	OID	1.3.6.1.4.1.5835.3.1.13.1.15.1.1		
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	dBm	dBm	- 36.2	-70 .. -20

Command DmMeasAGCCoSat		AGCCo level clipping info	AGCCo lvl clipping	
Used as variable of	Command(s)			Page
	DmMeasAGCCoStruct			157
Description	Readout of the power spectral density level clipping information. When reading saturated values for the power spectral density, the clipping information will identify the direction of saturation or return equal if the power spectral density is within range.			
RMC Command	Rcs			Access Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry		

Command DmMeasAGCCoSat		AGCCo level clipping info	AGCCo lvl clipping
	Command	ntcDevsMod01DmMeasAGCCoSat	
	OID	1.3.6.1.4.1.5835.3.1.13.1.33.1.1	
Values	Factory Default	Enumeration	Value
	equal	> <	0 1 2

Command DmMeasAGCCo		Power spectral density	Power spectral densi
Used as variable of	Command(s)		Page
	DmMeasAGCCoStruct		157
Description	Readout of the power spectral density expressed in dBm/Hz.		
RMCP Command	Rlc	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmMeasAGCCo	
	OID	1.3.6.1.4.1.5835.3.1.13.1.16.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	dBm/Hz	dBm/Hz	- 125.6
			-140 .. -80

Command IfChConfigEthRxEnable		Active	Active
Used as variable of	Command(s)		Page
	IfChConfigEthRx		58
Description	Configuration command to enable or disable the Ethernet Rx configuration entry.		
RMCP Command	IRe	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfChConfigEthRxEnable	
	OID	1.3.6.1.4.1.5835.3.1.4.1.61.1.1	
Values	Factory Default	Enumeration	Value
	disabled	Disabled Enabled	0 1

Command IfChConfigEthRxVlanId		VLAN ID		VLAN ID		
Used as variable of	Command(s)			Page		
	IfChConfigEthRx			58		
Description	Configuration of the VLAN identifier for filtering received Ethernet packets in a channel configuration.					
RMCP Command	IRV	Access		Normal user : RW Expert user : RW		
SNMP	Table	ntcDevsMod01InterfaceEntry				
	Command	ntcDevsMod01IfChConfigEthRxVlanId				
	OID	1.3.6.1.4.1.5835.3.1.4.1.66.1.1				
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	NA	NA	0	0 .. 4095		

Command IfChConfigEthRxMac		Dest MAC address	Dest MAC address
Used as variable of	Command(s)	Page	
	IfChConfigEthRx	58	
Description	Configuration of the Ethernet MAC address in the filter channel configuration for received Ethernet packets. Remark: 00:00:00:00:00:00 indicates no filtering on MAC addresses.		
RMCP Command	IRM	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfChConfigEthRxMac	
	OID	1.3.6.1.4.1.5835.3.1.4.1.62.1.1	
Values	Factory Default	String Description	
	00:00:00:00:00:00	length : 17 (fixed) format : ^([\\da-fA-F]{2}:){5}[\\da-fA-F]{2}\$	

Command IfChConfigEthRxIp		Dest IP address	Dest IP address
Used as variable of	Command(s)	Page	
	IfChConfigEthRx	58	
Description	Configuration of the IP address in the filter channel configuration for received Ethernet packets. Remark: 0.0.0.0 indicates no filtering on IP addresses.		
RMCP Command	irl	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfChConfigEthRxIp	
	OID	1.3.6.1.4.1.5835.3.1.4.1.117.1.1	

Command IfChConfigEthRxIp		Dest IP address	Dest IP address
Values	Factory Default	String Description	
	0.0.0.0	length : 0 .. 15 format : \d{1,3}\.\d{1,3}\.\d{1,3}\.\d{1,3}	

Command IfChConfigEthRxIpMask		IP netmask	IP netmask
Used as variable of	Command(s)	Page	
	IfChConfigEthRx	58	
Description	Configuration of the IP netmask in the filter channel configuration for received Ethernet packets. Remark: 0.0.0.0 indicates no filtering on IP addresses.		
RMCP Command	irM	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfChConfigEthRxIpMask	
	OID	1.3.6.1.4.1.5835.3.1.4.1.118.1.1	
Values	Factory Default	String Description	
	0.0.0.0	length : 0 .. 15 format : \d{1,3}\.\d{1,3}\.\d{1,3}\.\d{1,3}	

Command IfChConfigEthRxStreamId		OUT Stream Id	OUT Stream Id
Used as variable of	Command(s)	Page	
	IfChConfigEthRx	58	
Description	Configuration of the stream index for DVB-S2 stream configurations. This is not the input stream identifier (ISI), but the array index number used for reference in the filter configurations.		
RMCP Command	IRi	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfChConfigEthRxStreamId	
	OID	1.3.6.1.4.1.5835.3.1.4.1.65.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	NA	NA	1
			Expert Range (CU)
			1 .. 35

Command IfChConfigEthRxPID		OUT PID		OUT PID		
Used as variable of	Command(s)			Page		
	IfChConfigEthRx			58		
Description	Configuration of the PID of the outgoing MPEG transport stream on which the incoming Ethernet packets in a channel configuration are transmitted.					
RMCP Command	IRP	Access		Normal user : RW Expert user : RW		
SNMP	Table	ntcDevsMod01InterfaceEntry				
	Command	ntcDevsMod01IfChConfigEthRxPID				
	OID	1.3.6.1.4.1.5835.3.1.4.1.63.1.1				
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	NA	NA	0	0 .. 8192		

Command IfChConfigEthRxAirMac		OUT Air-MAC address	OUT Air-MAC address
Used as variable of	Command(s)		Page
	IfChConfigEthRx		58
Description	Configuration of the air-MAC address if the encapsulator has enabled air MAC destination addressing.		
RMCP Command	IRA		Access Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfChConfigEthRxAirMac	
	OID	1.3.6.1.4.1.5835.3.1.4.1.60.1.1	
Values	Factory Default		String Description
	00:00:00:00:00:00		length : 17 (fixed) format : ^([\\da-fA-F]{2}):{5}[\\da-fA-F]{2}\$

Command IfChConfigEthRxPackingDelay		Packing delay	Packing delay
Used as variable of	Command(s)		Page
	IfChConfigEthRx		58
Description	Configuration of the maximum delay allowed during the packing process of a DVB-S2 baseband frame or a transport stream cell.		
RMCP Command	bsd	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfChConfigEthRxPackingDelay	
	OID	1.3.6.1.4.1.5835.3.1.4.1.119.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU) Expert Range (CU)

Command IfChConfigEthRxPackingDelay		Packing delay		Packing delay
	ms	ms	10	0 .. 1000

Command IfUleSettingsDestMac		Air-MAC mode	Air-MAC mode	
Used as variable of	Command(s)			Page
	IfUleSettings			59
Description	Variable that contains the destination Air-MAC addressing method used during ULE encapsulation or decapsulation.			
	<ul style="list-style-type: none"> • Air-MAC mode is disabled: No Air-MAC addressing is used. • Air-MAC mode is enabled: Air-MAC addressing is used. 			
RMCP Command	IUm		Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry		
	Command	ntcDevsMod01IfUleSettingsDestMac		
	OID	1.3.6.1.4.1.5835.3.1.4.1.109.1.1		
Values	Factory Default		Enumeration	Value
	disabled		Disabled Enabled	0 1

Command IfChConfigEthTxEnable		Active	Active	
Used as variable of	Command(s)			Page
	IfChConfigEthTx			58
Description	Configuration command to enable or disable the demodulator routes table entry.			
RMCP Command	ITe		Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry		
	Command	ntcDevsMod01IfChConfigEthTxEnable		
	OID	1.3.6.1.4.1.5835.3.1.4.1.69.1.1		
Values	Factory Default		Enumeration	Value
	disabled		Disabled Enabled	0 1

Command IfChConfigEthTxISI		IN ISI	IN ISI
Used as variable of	Command(s)		
	IfChConfigEthTx		
Description	Configuration of the DVB-S2 input stream identifier. The DVB-S2 input stream identifier or ISI is present in the second byte position of the MATYPE field in the baseband header of a DVB-S2 baseband frame. It is a single byte identifying the encapsulated stream in case of multiple input streams. When the modulator input format consists of baseband frames, this value is used for filtering the matching stream for dedicated processing like network clock reference insertion or monitoring. In all other cases (e.g. a MPEG transport stream or generic stream inputs), this input stream identifier value is filled-in in the MATYPE field of the generated baseband frames.		
RMC Command	ITi	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfChConfigEthTxISI	
	OID	1.3.6.1.4.1.5835.3.1.4.1.70.1.1	
Values	Factory Default	String Description	
	00	length : 0 .. 2 format : Hexadecimal chars	

Command IfChConfigEthTxPID		IN PID	IN PID
Used as variable of	Command(s)		
	IfChConfigEthTx		
Description	Configuration of the PID of the incoming MPEG transport stream from which the Ethernet packets in a channel configuration are extracted.		
RMC Command	ITP	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfChConfigEthTxPID	
	OID	1.3.6.1.4.1.5835.3.1.4.1.72.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	NA	NA	0 .. 8192

Command IfChConfigEthTxAirMac		IN Air-MAC address	IN Air-MAC address
Used as variable of	Command(s)		
	IfChConfigEthTx		
Description	Configuration of the Air-MAC address if the decapsulator has enabled the Air-MAC destination addressing.		
RMC Command	ITA	Access	Normal user : RW Expert user : RW

Command IfChConfigEthTxAirMac		IN Air-MAC address	IN Air-MAC address
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfChConfigEthTxAirMac	
	OID	1.3.6.1.4.1.5835.3.1.4.1.68.1.1	
Values	Factory Default		String Description
	00:00:00:00:00:00		length : 17 (fixed) format : ^([\\da-fA-F]{2}:){5}[\\da-fA-F]{2}\$

Command IfChConfigEthTxVlanId		OUT VLAN ID	OUT VLAN ID
Used as variable of	Command(s)		Page
	IfChConfigEthTx		58
Description	Configuration of the VLAN identifier to transmit the output Ethernet packets in a channel configuration.		
RMC Command	ITV	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfChConfigEthTxVlanId	
	OID	1.3.6.1.4.1.5835.3.1.4.1.74.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	NA	NA	0 .. 4095

Command IfChConfigEthTxMac		OUT MAC address	OUT MAC address
Used as variable of	Command(s)		Page
	IfChConfigEthTx		58
Description	Configuration of the Ethernet MAC address in the channel configuration for the transmission of Ethernet packets. Remark: 00:00:00:00:00:00 indicates no MAC address translation.		
RMC Command	ITM		Access Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfChConfigEthTxMac	
	OID	1.3.6.1.4.1.5835.3.1.4.1.71.1.1	
Values	Factory Default		String Description
	00:00:00:00:00:00		length : 17 (fixed) format : ^([\\da-fA-F]{2}:){5}[\\da-fA-F]{2}\$

Command IfUleSettingsCRC		CRC	CRC
Used as variable of	Command(s)		
	IfUleSettings		
Description	Variable that contains the CRC method used during ULE encapsulation or decapsulation. <ul style="list-style-type: none"> • CRC enabled: CRC calculation. • CRC disabled: No calculation, no check. • CRC fixed value: The CRC field has a fixed value 0x00007015, decapsulation checks the fixed value. 		
RMCP Command	IUc	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfUleSettingsCRC	
	OID	1.3.6.1.4.1.5835.3.1.4.1.108.1.1	
Values	Factory Default	Enumeration	Value
	enabled	Enabled Disabled Fixed Value	0 1 2

Command IfGBSSettingsDestMac		Air-MAC mode	Air-MAC mode
Used as variable of	Command(s)		
	IfGBSSettings		
Description	Configuration for destination Air-MAC addressing in case of XPE encapsulation: <ul style="list-style-type: none"> • Air-MAC addressing is enabled. • Air-MAC addressing is disabled. 		
RMCP Command	IGm	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfGBSSettingsDestMac	
	OID	1.3.6.1.4.1.5835.3.1.4.1.93.1.1	
Values	Factory Default	Enumeration	Value
	disabled	Disabled Enabled	0 1

Command IfGBSSettingsCRC		CRC		CRC			
Used as variable of	Command(s)			Page			
	IfGBSSettings			59			
Description	Configuration of the CRC calculation in case of XPE encapsulation or decapsulation: <ul style="list-style-type: none"> • Enabled: CRC calculation is used. • Disabled: No CRC calculation is used. Remark: When CRC calculation is disabled, the CRC is not send over the link. 						
RMCP Command	IGc		Access	Normal user : RW Expert user : RW			
SNMP	Table	ntcDevsMod01InterfaceEntry					
	Command	ntcDevsMod01IfGBSSettingsCRC					
	OID	1.3.6.1.4.1.5835.3.1.4.1.92.1.1					
Values	Factory Default		Enumeration	Value			
	disabled		Enabled Disabled	0 1			

Command IfGSESettingsDestMac		Air-MAC (6 byte label) mode		Air-MAC (6 byte labe			
Used as variable of	Command(s)			Page			
	IfGSESettings			60			
Description	GSE encapsulation label type mode: <ul style="list-style-type: none"> • Air-MAC (6 byte label) enabled • Air-MAC (6 byte label) disabled 						
RMCP Command	gsl		Access	Normal user : RW Expert user : RW			
SNMP	Table	ntcDevsMod01InterfaceEntry					
	Command	ntcDevsMod01IfGSESettingsDestMac					
	OID	1.3.6.1.4.1.5835.3.1.4.1.275.1.1					
Values	Factory Default		Enumeration	Value			
	disabled		Disabled Enabled	0 1			

Command IfStrConfigStreamId		Stream Id		Stream Id			
Used as variable of	Command(s)			Page			
	IfStrConfig			79			
Description	Configuration of the stream index for DVB-S2 stream configurations. This is not the input stream identifier but the array index number used for reference in the filter configurations.						
RMCP Command	ISi	Access		Normal user : RW Expert user : RW			

Command IfStrConfigStreamId		Stream Id	Stream Id
SNMP	<i>Table</i>	ntcDevsMod01InterfaceEntry	
	<i>Command</i>	ntcDevsMod01IfStrConfigStreamId	
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.4.1.106.1.1	
Values	<i>GUI Unit</i>	<i>Cmd Unit</i>	<i>Factory Default (CU)</i>
	NA	NA	1 .. 35

Command IfStrConfigEnable		Active	Active	
Used as variable of	<i>Command(s)</i>			<i>Page</i>
	IfStrConfig			79
Description	Configuration command to specify if the configuration entry is enabled or not.			
RMCP Command	ISe	<i>Access</i>	Normal user : RW Expert user : RW	
SNMP	<i>Table</i>	ntcDevsMod01InterfaceEntry		
	<i>Command</i>	ntcDevsMod01IfStrConfigEnable		
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.4.1.105.1.1		
Values	<i>Factory Default</i>	<i>Enumeration</i>	<i>Value</i>	
	disabled	Disabled Enabled	0 1	

Command IfDvbs2BboerxFrames		RX frames	RX frames	
Used as variable of	<i>Command(s)</i>			<i>Page</i>
	IfDvbs2BboerxErrors			134
Description	Readout of the ntS2BBFoE RX frame counter			
RMCP Command	brf	<i>Access</i>	Normal user : R Expert user : R	
SNMP	<i>Table</i>	ntcDevsMod01InterfaceEntry		
	<i>Command</i>	ntcDevsMod01IfDvbs2BboerxFrames		
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.4.1.142.1.1		
Values	<i>GUI Unit</i>	<i>Cmd Unit</i>	<i>Factory Default (CU)</i>	<i>Expert Range (CU)</i>
	Frames	Frames	0	0 .. 4294967295

Command IfDvbs2BboerxErrEncapId		Encap ID error		Encap ID error			
Used as variable of	Command(s)			Page			
	IfDvbs2BboerxErrors			134			
Description	Readout of the ntS2BBFoE RX error counter. The counter increases in case of a wrong encapsulator identifier.						
RMCP Command	bee	Access		Normal user : R Expert user : R			
SNMP	Table	ntcDevsMod01InterfaceEntry					
	Command	ntcDevsMod01IfDvbs2BboerxErrEncapId					
	OID	1.3.6.1.4.1.5835.3.1.4.1.139.1.1					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)			
	Frames	Frames	0	0 .. 4294967295			

Command IfDvbs2BboerxErrEncap		Encap disabled		Encap disabled			
Used as variable of	Command(s)			Page			
	IfDvbs2BboerxErrors			134			
Description	ntS2BBFoE RX error counter: encapsulator disabled						
RMCP Command	bed	Access		Normal user : R Expert user : R			
SNMP	Table	ntcDevsMod01InterfaceEntry					
	Command	ntcDevsMod01IfDvbs2BboerxErrEncapDisabled					
	OID	1.3.6.1.4.1.5835.3.1.4.1.138.1.1					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)			
	Frames	Frames	0	0 .. 4294967295			

Command IfDvbs2BboerxErr		Seq nbr error		Seq nbr error			
Used as variable of	Command(s)			Page			
	IfDvbs2BboerxErrors			134			
Description	Readout of the ntS2BBFoE RX error counter. The counter increases in case of a sequence number error (frame is not dropped).						
RMCP Command	bes	Access		Normal user : R Expert user : R			
SNMP	Table	ntcDevsMod01InterfaceEntry					
	Command	ntcDevsMod01IfDvbs2BboerxErrSequence					
	OID	1.3.6.1.4.1.5835.3.1.4.1.204.1.1					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)			

Command	Seq nbr error		Seq nbr error	
IfDvbs2BboerxErr Sequence				
	Frames	Frames	0	0 .. 4294967295

Command	IP volume = 0		IP volume = 0	
IfDvbs2BboerxErrIpVol0				
Used as variable of	Command(s)		Page	
	IfDvbs2BboerxErrors		134	
Description	Readout of the ntS2BBFoE RX error counter. This counter increases when there is a volume request mismatch between encapsulator and modulator.			
RMCP Command	bev	Access		Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry		
	Command	ntcDevsMod01IfDvbs2BboerxErrIpVol0		
	OID	1.3.6.1.4.1.5835.3.1.4.1.140.1.1		
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Frames	Frames	0	0 .. 4294967295

Command	IP volume		IP volume	
IfDvbs2BboerxCurIp Volume				
Used as variable of	Command(s)		Page	
	IfDvbs2BboerxCurStats		135	
Description	Readout of the IP volume of an ntS2BBFoE receiver, counted in the current measuring interval.			
RMCP Command	bci	Access		Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry		
	Command	ntcDevsMod01IfDvbs2BboerxCurIpVolume		
	OID	1.3.6.1.4.1.5835.3.1.4.1.135.1.1		
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Bytes	Bytes	0	0 .. 4294967295

Command	Padding volume		Padding volume	
IfDvbs2BboerxCurPadding Volume				
Used as variable of	Command(s)		Page	
	IfDvbs2BboerxCurStats		135	
Description	Readout of the padding volume of an ntS2BBFoE receiver, counted in the current measuring interval.			

Command IfDvbs2BboerxCurPaddingVolume		Padding volume	Padding volume
RMCP Command	bcp	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfDvbs2BboerxCurPaddingVolume	
	OID	1.3.6.1.4.1.5835.3.1.4.1.136.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU) Expert Range (CU)
	Bytes	Bytes	0 .. 0 .. 4294967295

Command IfDvbs2BboerxCurSymbolVolume		Symbol volume	Symbol volume
Used as variable of	Command(s)		Page
	IfDvbs2BboerxCurStats		135
Description	Readout of the symbol volume of a ntS2BBFoE receiver, counted in the current measuring interval.		
RMCP Command	bcs	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfDvbs2BboerxCurSymbolVolume	
	OID	1.3.6.1.4.1.5835.3.1.4.1.137.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU) Expert Range (CU)
	Symbols	Symbols	0 .. 0 .. 4294967295

Command IfDvbs2BboerxIntervallpVolume		IP volume	IP volume
Used as variable of	Command(s)		Page
	IfDvbs2BboerxIntervalStats		135
Description	Readout of the IP volume of an ntS2BBFoE receiver, counted in the previous measuring interval.		
RMCP Command	bii	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfDvbs2BboerxIntervallpVolume	
	OID	1.3.6.1.4.1.5835.3.1.4.1.143.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU) Expert Range (CU)
	Bytes	Bytes	0 .. 0 .. 4294967295

Command IfDvbs2BboerxIntervalPadVolume		Padding volume			
Used as variable of	Command(s)				
	IfDvbs2BboerxIntervalStats				
Description	Readout of the padding volume of an ntS2BBFoE receiver, counted in the previous measuring interval.				
RMCP Command	bip	Access	Normal user : R Expert user : R		
SNMP	Table	ntcDevsMod01InterfaceEntry			
	Command	ntcDevsMod01IfDvbs2BboerxIntervalPadVolume			
	OID	1.3.6.1.4.1.5835.3.1.4.1.144.1.1			
Values	GUI Unit	Cmd Unit	Factory Default (CU)		
	Bytes	Bytes	0 .. 4294967295		

Command IfDvbs2BboerxIntervalSymVolume		Symbol volume	Symbol volume
Used as variable of	Command(s)	Page	
	IfDvbs2BboerxIntervalStats	135	
Description	Readout of the symbol volume of an ntS2BBFoE receiver, counted in the previous measuring interval.		
RMCP Command	bis	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfDvbs2BboerxIntervalSymVolume	
	OID	1.3.6.1.4.1.5835.3.1.4.1.145.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Symbols	Symbols	0 .. 4294967295

Command SyDevModeState		Current device operating mode	Operating mode
Used as variable of	Command(s)	Page	
	SyDevMode	12	
Description	Readout of the current device operating mode: normal mode or expert mode. Remark: Use SyDevMode to change the device operating mode.		
RMCP Command	SMM	Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyDevModeState	
	OID	1.3.6.1.4.1.5835.3.1.1.19.0.1	

Command SyDevModeState		Current device operating mode		Operating mode
Values	<i>Factory Default</i>	<i>Enumeration</i>	<i>Value</i>	
	normal	Normal Expert	1 2	

Command DmMeasEsNoSat		Es/No level clipping info		
Used as variable of	<i>Command(s)</i>			<i>Page</i>
	DmMeasEsNoStruct			160
Description	Readout of the Es/No level clipping information. When reading saturated values for the Es/No estimation, the clipping info will identify the direction of saturation or return equal if the value is within range. Remark: An asterisk indicates that the readout of the Es/No value is about to saturate and may be not very accurate.			
RMCP Command	Res		Access	Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry		
	Command	ntcDevsMod01DmMeasEsNoSat		
	OID	1.3.6.1.4.1.5835.3.1.13.1.49.1.1		
Values	<i>Factory Default</i>	<i>Enumeration</i>	<i>Value</i>	
	equal	> < *	0 1 2 3	

Command DmMeasEsNo 1		Es/No estimation		
Used as variable of	<i>Command(s)</i>			<i>Page</i>
	DmMeasEsNoStruct			160
Description	Readout of the Es/No estimation in dB of the received signal.			
RMCP Command	Ren	Access		Normal user : R Expert user : R
SNMP	Table	ntcDevsMod01DemodulatorEntry		
	Command	ntcDevsMod01DmMeasEsNo		
	OID	1.3.6.1.4.1.5835.3.1.13.1.48.1.1		
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	dB	dB	9.83	-5 .. 25

Command DmEstLinMarSat		Link margin clipping info		Link margin clipping			
Used as variable of	Command(s)			Page			
	DmEstLinMarStruct			160			
Description	This variable gives an indication of a clipped link margin. This happens when the channel Es/No (decoder) saturates to a maximum.						
RMCP Command	Lss		Access	Normal user : R Expert user : R			
SNMP	Table	ntcDevsMod01DemodulatorEntry					
	Command	ntcDevsMod01DmEstLinMarSat					
	OID	1.3.6.1.4.1.5835.3.1.13.1.74.1.1					
Values	Factory Default		Enumeration	Value			
	equal		*	0 1 <			

Command DmEstLinMar		Estimated Link margin		Estimated Link margin			
Used as variable of	Command(s)				Page		
	DmEstLinMarStruct				160		
Description	Readout of the link margin. The link margin is calculated by subtracting the modcod dependent margin from the estimated Eb/No in DVB-S or Es/No in DVB-S2. It indicates the receive margin before reaching the threshold point of quasi error free operation (QEF) operation. The Eb/No for quasi error free operation is taken from the DVB standards EN300421 and EN301210. Basically it is the margin in dB that a signal can decrease in Eb/No before errors will have noticeable effects on the output transport stream.						
RMCP Command	Rld	Access		Normal user : R Expert user : R			
SNMP	Table	ntcDevsMod01DemodulatorEntry					
	Command	ntcDevsMod01DmEstLinMar					
	OID	1.3.6.1.4.1.5835.3.1.13.1.32.1.1					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)			
	dB	dB	4,02	-5 .. 25			

Command IfBrIfEnable		Active		Active	
Used as variable of	Command(s)				Page
	IfBrIfEntry				57
Description	Configuration command to enable or disable the IP interface table entry.				
RMCP Command	BTe		Access	Normal user : RW Expert user : RW	

Command IfBrifEnable		Active	Active
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfBrifEnable	
	OID	1.3.6.1.4.1.5835.3.1.4.1.182.1.1	
Values	Factory Default		Enumeration
	disabled		Disabled Enabled
		0	1

Command IfBrifLocalVlan		Local VLAN	Local VLAN
Used as variable of	Command(s)		Page
	IfBrifEntry		57
Description	Configuration of the local VLAN of this IP interface.		
RMC Command	BLv	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfBrifLocalVlan	
	OID	1.3.6.1.4.1.5835.3.1.4.1.187.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	NA	NA	0
		Expert Range (CU)	
		0 .. 4095	

Command IfBrifLocallp		Local IP address	Local IP address
Used as variable of	Command(s)		Page
	IfBrifEntry		57
Description	Configuration of the IP address assigned to the local IP interface. When the host part is zero (= the part of the IP address that is not masked by the netmask of this interface), it means that there is no IP address assigned to this interface.		
RMC Command	BLi		Access Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfBrifLocallp	
	OID	1.3.6.1.4.1.5835.3.1.4.1.185.1.1	
Values	Factory Default		String Description
	0.0.0.0		length : 0 .. 15 format : \d{1,3}\.\d{1,3}\.\d{1,3}\.\d{1,3}

Command IfBrifLocalIpMask		Local IP Netmask	Local IP Netmask
Used as variable of	Command(s)		Page
	IfBrifEntry		57
Description	Configuration of the netmask that identifies the local subnet on the IP interface.		
RMCP Command	BLm	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfBrifLocalIpMask	
	OID	1.3.6.1.4.1.5835.3.1.4.1.186.1.1	
Values	Factory Default	String Description	
	0.0.0.0	length : 0 .. 15 format : \d{1,3}.\d{1,3}.\d{1,3}.\d{1,3}	

Command IfBrifLocalGateway1		Local IP gateway	Local IP gateway
Used as variable of	Command(s)		Page
	IfBrifEntry		57
Description	Configuration of the local IP gateway (= default route) for this IP interface. This is the IP router/host to whom the IP packets are sent that do not belong within the local subnet.		
RMCP Command	BLg	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfBrifLocalGateway	
	OID	1.3.6.1.4.1.5835.3.1.4.1.184.1.1	
Values	Factory Default	String Description	
	0.0.0.0	length : 0 .. 15 format : \d{1,3}.\d{1,3}.\d{1,3}.\d{1,3}	

Command IfBrifRemotelp1		Remote IP address	Remote IP address
Used as variable of	Command(s)		Page
	IfBrifEntry		57
Description	Configuration of the remote IP address that identifies (together with the netmask) the remote IP subnet. The remote IP subnet is the part of the satellite subnet that is located at the remote side of the satellite link. Remark: The host part of this IP address should remain zero.		
RMCP Command	BRi	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfBrifRemotelp	

Command IfBrIfRemotelp1		Remote IP address	Remote IP address
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.4.1.188.1.1	
Values	<i>Factory Default</i>	<i>String Description</i>	
	0.0.0.0	length : 0 .. 15 format : \d{1,3}\.\d{1,3}\.\d{1,3}\.\d{1,3}	

Command IfBrIfRemotelpMask1		Remote IP netmask	Remote IP netmask	
Used as variable of	<i>Command(s)</i>			<i>Page</i>
	IfBrIfEntry			57
Description	Configuration of the netmask that identifies (together with the remote IP address) the remote IP subnet. The remote IP subnet is the part of the satellite subnet that is located at the remote side of the satellite link.			
RMCP Command	BRm		Access	Normal user : RW Expert user : RW
SNMP	<i>Table</i>	ntcDevsMod01InterfaceEntry		
	<i>Command</i>	ntcDevsMod01IfBrIfRemotelpMask		
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.4.1.189.1.1		
Values	<i>Factory Default</i>	<i>String Description</i>		
	0.0.0.0	length : 0 .. 15 format : \d{1,3}\.\d{1,3}\.\d{1,3}\.\d{1,3}		

Command AIselfTestString		SelfTest String	SelfTest String	
Used as variable of	<i>Command(s)</i>			<i>Page</i>
	AIselfTestBrd			43
Description	Readout of the concatenated string of individual self test results.			
RMCP Command	STS		Access	Normal user : R Expert user : R
SNMP	<i>Table</i>	ntcDevsMod01AlarmEntry		
	<i>Command</i>	ntcDevsMod01AIselfTestString		
	<i>OID</i>	1.3.6.1.4.1.5835.3.1.2.1.13.1.1		
Values	<i>Factory Default</i>	<i>String Description</i>		
		length : 0 (fixed) format : any chars		

Variables only Used via other Commands

Variable WILoginUser		WI user login name	WI user login name
Used as variable of	Command(s)	Page	
	WIUsers	19	
Description	Variable that holds the user name for the web interface user.		
Values	<i>Factory Default</i>	<i>String Description</i>	
		length : 0 .. 12 format : any chars	

Variable WILoginUserAccess		WI user login access	WI user login access
Used as variable of	Command(s)	Page	
	WIUsers	19	
Description	Variable that holds the web interface user level of login access.		
Values	<i>Factory Default</i>	<i>Enumeration</i>	<i>Value</i>
	minimum	Minimum Operator Administrator	0 1 2

Variable WILoginOldPass		WI old user login password	WI old password
Used as variable of	Command(s)	Page	
	WIUsers	19	
Description	Variable that holds the old password for the web interface user and will be used for validation of the new password.		
Values	<i>Factory Default</i>	<i>String Description</i>	
		length : 0 .. 8 format : any chars	

Variable WILoginPass		WI user login password	WI login password
Used as variable of	Command(s)		Page
	WIUsers		19
Description	Variable that holds the password for the web interface user.		
Values	Factory Default	String Description	
		length : 0 .. 8 format : any chars	

Variable WILoginReply		WI login status reply	WI login status repl
Used as variable of	Command(s)		Page
	WIUsers		19
Description	Variable that holds the status reply for the web interface login command.		
Values	Factory Default	Enumeration	Value
		Success Failed	0 1

Variable IfQosQueuePriority		Priority	Priority
Used as variable of	Command(s)		Page
	IfQosQueueEntry		61
Description	Variable that contains the quality of service queue priority. This is a read-only name of a quality of service queue.		
Values	Factory Default	String Description	
	init	length : 0 .. 15 format : any chars	

Variable IfQosQueueGuarPerFlow		Guaranteed size (in mS) per flow	Guaranteed size (in mS) per flow
Used as variable of	Command(s)		Page
	IfQosQueueEntry		61
Description	Variable that contains the guaranteed queue size per flow for each of the quality of service classes. A quality of service flow is for instance a DVB-S2 stream or a MPEG PID flow. The guaranteed queue size is respected, even when the maximum configured queue size for a quality of service class has been reached. The queue size is expressed in milliseconds: for each packet inside the quality of service queue, the time needed to transmit it via the satellite is calculated taking into account the baudrate, the modulation and coding. High priority traffic (real-time traffic for instance) gets usually a larger queue size than the low priority traffic (non real-time traffic).		

Variable IfQosQueueGuarPerFlow		Guaranteed size (in mS) per flow		Guaranteed size (in
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	NA	NA	10	1 .. 10000

Variable IfQosQueueMaxPerQos		Max size (in mS) per QOS	Max size (in mS) per
Used as variable of	Command(s)	Page	
	IfQosQueueEntry	61	
Description	Variable that contains the maximum queue size per quality of service class for all flows together. When a given flow has occupied its guaranteed buffering space in the quality of service queue, it may occupy more non-guaranteed buffering space as long as the maximum for the quality of service flow has not been reached. The queue size is expressed in milliseconds: for each packet inside the quality of service queue, the time needed to transmit it via the satellite is calculated taking into account the baudrate, the modulation and coding. High priority traffic (real-time traffic for instance) gets usually a larger queue size than the low priority traffic (non real-time traffic).		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	NA	NA	10000
			1 .. 20000

Variable IfEthQosRuleEnable		Active	Active
Used as variable of	Command(s)	Page	
	IfEthQosRuleEntry	61	
Description	This variable allows to enable or disable the quality of service rule table entry.		
Values	Factory Default	Enumeration	Value
	disabled	Disabled Enabled	0 1

Variable IfEthQosRuleClassif		classifier	classifier
Used as variable of	Command(s)	Page	
	IfEthQosRuleEntry	61	
Description	Different QOS rules can be defined. Each rule defines a pattern to match incoming Ethernet packets. When a packet is matched by a rule, this packet gets the priority that is associated to this rule. Qos rules are matched in sequence (first to last rule). There is one special rule, being the first rule in the table: this rule gets the default classifier. The default rule is selected if no other rule matches. Examples: ip.proto==udp ip.proto==17 eth.type==lacp ip.tos==4-255		

Variable IfEthQosRuleClassif		classifier	classifier
	ip.tos==8,16 ip.dscp==8-16 ip.dscp==8,16 ip.src==1.2.3.4 ip.dst==1.2.3.4		
Values	Factory Default	String Description	
		length : 0 .. 30 format : any chars	

Variable IfEthQosRulePrio		Priority	Priority
Used as variable of	Command(s)		Page
	IfEthQosRuleEntry		61
Description	Variable that contains the quality of service priority that is associated to a quality of service rule. Packets that are matched by a quality of service rule gets this priority in the system. The priority is used for admission control decisions and as scheduling priority. It is not used for re-tagging the priority values inside a packet.		
	Values	Factory Default	Enumeration
		lowest	Lowest Low High Highest
			0 1 2 3

Variable MoAcmDmSupvIp		Demodulator IP	Demodulator IP
Used as variable of	Command(s)		Page
	MoAcmDmSupvEntry		88
Description	Variable that contains the IP address of the demodulator device that is supervised by the ACM controller.		
	Values	Factory Default	String Description
		0.0.0.0	length : 0 .. 15 format : \d{1,3}\.\d{1,3}\.\d{1,3}\.\d{1,3}

Variable MoAcmDmSupvStrid		DVB-S2 Stream Id	DVB-S2 Stream Id
Used as variable of	Command(s)		Page
	MoAcmDmSupvEntry		88
Description	Variable that contains the DVB-S2 stream identifier. The DVB-S2 stream identifier should be modified depending on the receive conditions of the modulator. This field is only applicable in multi-stream modulation mode.		
	Values	GUI Unit	Cmd Unit
		NA	NA
			1
			0 .. 35

Variable IfBBTXCounter		BB TX TS Counter	BB TX TS Counter
Used as variable of	Command(s)		Page
	IfBBCounters		
Description	Variable that contains the number of transport stream frames transmitted to baseband interface. Remark: Usually a modulator card is attached to this baseband interface.		
Values	GUI Unit	Cmd Unit	Factory Default (CU) Expert Range (CU)
	Frames	Frames	0 .. 4294967295

Variable IfBBTXBBFCounter		BB TX BBF Counter	BB TX BBF Counter
Used as variable of	Command(s)		Page
	IfBBCounters		
Description	Readout of the number of baseband frames transmitted to baseband interface. Remark: Usually a modulator card is attached to this interface.		
Values	GUI Unit	Cmd Unit	Factory Default (CU) Expert Range (CU)
	Frames	Frames	0 .. 4294967295

Variable IfBBRXCounter		BB RX TS Counter	BB RX TS Counter
Used as variable of	Command(s)		Page
	IfBBCounters		
Description	Readout of the number of transport stream frames received from the baseband interface. Remark: Usually a demodulator card is attached to this interface.		
Values	GUI Unit	Cmd Unit	Factory Default (CU) Expert Range (CU)
	Frames	Frames	0 .. 4294967295

Variable IfBBRXBBFCounter		BB RX BBF Counter	BB RX BBF Counter
Used as variable of	Command(s)		Page
	IfBBCounters		
Description	Readout of the number of baseband frames received from the baseband interface. Remark: Usually a demodulator card is attached to this interface.		
Values	GUI Unit	Cmd Unit	Factory Default (CU) Expert Range (CU)
	Frames	Frames	0 .. 4294967295

Variable IfBBRxDropCounter		BB RX Dropped		BB RX Dropped		
Used as variable of	Command(s)			Page		
IfBBCounters				121		
Description	Readout of the number of frames dropped at the baseband interface because the baseband buffer is full or because the frame has an invalid or unknown format. This counter accounts for either DVBS-2 baseband frames or DVB-S transport stream frames dependant on the MdProcMode setting. Remark: Usually a demodulator card is attached to this interface.					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Frames	Frames	0	0 .. 4294967295		

Variable IfBBRXTSCrcErr		TS CRC-8		TS CRC-8		
Used as variable of	Command(s)			Page		
IfBBCounters				121		
Description	Readout of the number of times that a CRC-8 error was detected during processing of the DVB-S frames that contain transport stream payload.					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Errors	Errors	0	0 .. 4294967295		

Variable IfBBRXBBCrcErr		BBF CRC-8		BBF CRC-8		
Used as variable of	Command(s)			Page		
IfBBCounters				121		
Description	Readout of the number of times that a CRC-8 error was detected in the headers of the received DVB-S2 baseband frames.					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Errors	Errors	0	0 .. 4294967295		

Variable IfBbTxEthqCurFilling		BB TX Eth queue cur filling		BB TX Eth queue cur		
Used as variable of	Command(s)			Page		
IfBbTxEthqStats				122		
Description	Variable that contains the current filling level of the baseband TX Ethernet queue. This queue contains the frames that travel from the Ethernet interface to the baseband interface. The filling level is expressed in milliseconds.					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	ms	ms	0	0 .. 4294967295		

Variable IfBbTxEthqMaxFilling	BB TX Eth queue max filling	BB TX Eth queue max		
Used as variable of	Command(s)	Page		
	IfBbTxEthqStats			
Description	Variable that contains the maximum filling level of the baseband TX Ethernet queue. This queue contains the frames that travel from the Ethernet interface to the baseband interface. The filling level is expressed in milliseconds.			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	ms	ms	0	0 .. 4294967295

Variable IfIMPEGoUDPStatsRX	Ethernet IN IP	Ethernet IN IP		
MtuPackets				
Used as variable of	Command(s)	Page		
	IfIMPEGoUDPStats			
Description	Variable that contains the number of IP frames received from the Ethernet interface.			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Packets	Packets	0	0 .. 4294967295

Variable IfIMPEGoUDPStatsRXMtu	Ethernet IN IP bytes	Ethernet IN IP bytes		
Bytes				
Used as variable of	Command(s)	Page		
	IfIMPEGoUDPStats			
Description	Variable that contains the number of bytes received from the Ethernet interface (counted at the transport layer).			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Bytes	Bytes	0	0 .. 4294967295

Variable IfIMPEGoUDPStatsRXMtu	Ethernet IN Bitrate	Ethernet IN Bitrate		
Rate				
Used as variable of	Command(s)	Page		
	IfIMPEGoUDPStats			
Description	Variable that contains the bitrate received from the Ethernet interface (counted at the transport layer).			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	bps	bps	0	0 .. 4294967295

Variable IfMPEGoUDPStatsRXMtuDrop		Ethernet IN Dropped	Ethernet IN Dropped
Used as variable of	Command(s)		Page
	IfMPEGoUDPStats		
Description	Variable that contains the number if IP frames dropped by MPEG over IP receiver.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Packets	Packets	0
			0 .. 4294967295

Variable IfMPEGoUDPStatsRXPopTimeouts		Ethernet IN Pop	Ethernet IN Pop
Used as variable of	Command(s)		Page
	IfMPEGoUDPStats		
Description	Variable that contains the number of times that an input queue was empty (timed out) during decapsulation over the last period.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Retries	Retries	0
			0 .. 4294967295

Variable IfMPEGoUDPStatsRXMpegPackets		Ethernet IN TS	Ethernet IN TS
Used as variable of	Command(s)		Page
	IfMPEGoUDPStats		
Description	Variable that contains the number of MPEG transport stream packets received from the Ethernet interface.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Packets	Packets	0
			0 .. 4294967295

Variable IfMPEGoUDPStatsRXPushTimeouts		Ethernet IN Congestion	Ethernet IN Congesti
Used as variable of	Command(s)		Page
	IfMPEGoUDPStats		
Description	Variable that contains the number of times that an output queue was full (timed out) over the last period.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Retries	Retries	0
			0 .. 4294967295

Variable IfMPEGoUDPStatsTXMpegPackets		Ethernet OUT TS	Ethernet OUT TS
Used as variable of	Command(s)		Page
	IfMPEGoUDPStats		
Description	Variable that contains the number of MPEG transport stream packets transmitted to the Ethernet interface.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Packets	Packets	0
			0 .. 4294967295

Variable IfMPEGoUDPStatsTXMpegDrop		Ethernet OUT TS Drop	Ethernet OUT TS Drop
Used as variable of	Command(s)		Page
	IfMPEGoUDPStats		
Description	Variable that contains the number of MPEG transport stream packets dropped before encapsulation in IP.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Packets	Packets	0
			0 .. 4294967295

Variable IfMPEGoUDPStatsTXPopTimeouts		Ethernet OUT Pop	Ethernet OUT Pop
Used as variable of	Command(s)		Page
	IfMPEGoUDPStats		
Description	Variable that contains the number of times that an input queue was empty (timed out) over the last period.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Retries	Retries	0
			0 .. 4294967295

Variable IfMPEGoUDPStatsTXMtuPackets		Ethernet OUT IP	Ethernet OUT IP
Used as variable of	Command(s)		Page
	IfMPEGoUDPStats		
Description	Variable that contains the number of IP frames transmitted to the Ethernet interface.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Packets	Packets	0
			0 .. 4294967295

Variable IfMPEGoUDPStatsTXMtuBytes		Ethernet OUT IP bytes	Ethernet OUT IP byte
Used as variable of	<i>Command(s)</i>		Page
	IfMPEGoUDPStats		
Description	Variable that contains the number of bytes sent to the Ethernet interface (counted at transport layer).		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Bytes	Bytes	0
Variable IfMPEGoUDPStatsTXMtuRate		Ethernet OUT Bitrate	Ethernet OUT Bitrate
Used as variable of	<i>Command(s)</i>		Page
	IfMPEGoUDPStats		
Description	Variable that contains the bitrate of IP frames generated by the MPEG over IP processor.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	bps	bps	0
Variable IfMPEGoUDPStatsTXPushTimeouts		Ethernet OUT Congestion	Ethernet OUT Congest
Used as variable of	<i>Command(s)</i>		Page
	IfMPEGoUDPStats		
Description	Variable that contains the number of times that an output queue was full (timed out) over the last period.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Retries	Retries	0
Variable IfVolreqStatsMovAvgVol		AVG IP volume requested	AVG IP volume reques
Used as variable of	<i>Command(s)</i>		Page
	IfVolreqStats		
Description	Variable that contains the moving average of the last 32 IP volume requests converted to bits per second.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	bps	bps	0

Variable IfMPEGoUDPStatsTXPushTimeouts		Ethernet OUT Congestion	Ethernet OUT Congest
Used as variable of	<i>Command(s)</i>		Page
	IfMPEGoUDPStats		
Description	Variable that contains the number of times that an output queue was full (timed out) over the last period.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Retries	Retries	0

Variable IfVolreqStatsMovAvgVol		AVG IP volume requested	AVG IP volume reques
Used as variable of	<i>Command(s)</i>		Page
	IfVolreqStats		
Description	Variable that contains the moving average of the last 32 IP volume requests converted to bits per second.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	bps	bps	0

Variable IfVolreqStatsMovMaxVol		MAX IP volume requested	MAX IP volume requests
Used as variable of	Command(s)		Page
	IfVolreqStats		
Description	Variable that contains the moving maximum of the last 32 IP volume requests converted to bits per second.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	bps	bps	0
			0 .. 4294967295

Variable IfVolreqStatsMovMinVol		MIN IP volume requested	MIN IP volume requests
Used as variable of	Command(s)		Page
	IfVolreqStats		
Description	Variable that contains the moving minimum of the last 32 IP volume requests converted to bits per second.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	bps	bps	0
			0 .. 4294967295

Variable IfS2BBFoERxFramesRxed		RX frames	RX frames
Used as variable of	Command(s)		Page
	IfS2BBFoERxCounters		
Description	Variable that contains the DVB-S2 baseband frames over Ethernet RX frame counter.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Frames	Frames	0
			0 .. 4294967295

Variable IfS2BBFoERxTranspHdr Errors		RX transp.hdr errors	RX transp.hdr errors
Used as variable of	Command(s)		Page
	IfS2BBFoERxCounters		
Description	Variable that contains the DVB-S2 baseband frames over Ethernet RX transport header errors.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Frames	Frames	0
			0 .. 4294967295

Variable IfS2BBFoERxDflErrors		RX DFL errors	RX DFL errors
Used as variable of	Command(s)		Page
	IfS2BBFoERxCounters		
Description	Variable that contains the DVB-S2 baseband frames over Ethernet RX data field length errors.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Frames	Frames	0
Variable IfS2BBFoERxAcmErrors		RX ACM errors	RX ACM errors
Used as variable of	Command(s)		Page
	IfS2BBFoERxCounters		
Description	Variable that contains the error counter that counts the DVB-S2 baseband frames that have been received from the Ethernet interface with an invalid adaptive code modulation byte.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Frames	Frames	0
Variable IfUleStatsTMMtuPackets		Encap IN Ethernet	Encap IN Ethernet
Used as variable of	Command(s)		Page
	IfUleStats		
Description	Variable that contains the number of Ethernet packets received over the last period that were encapsulated.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Packets	Packets	0
Variable IfUleStatsTMMtuBytes		Encap IN Ethernet	Encap IN Ethernet
Used as variable of	Command(s)		Page
	IfUleStats		
Description	Variable that contains the number of bytes of the Ethernet packets transmitted over the last period.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Bytes	Bytes	0

Variable IfUleStatsTXMtuRate		Encap IN Bitrate	Encap IN Bitrate	
Used as variable of	Command(s)			Page
	IfUleStats			137
Description	Variable that contains the bitrate of the Ethernet frames encoded by the ULE processor.			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	bps	bps	0	0 .. 4294967295

Variable IfUleStatsTXMpegPackets		Encap OUT TS	Encap OUT TS	
Used as variable of	Command(s)			Page
	IfUleStats			137
Description	Variable that contains the number of MPEG transport stream packets created over the last period.			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Packets	Packets	0	0 .. 4294967295

Variable IfUleStatsTXPopTimeouts		Encap IN Pop	Encap IN Pop	
Used as variable of	Command(s)			Page
	IfUleStats			137
Description	Variable that contains the number of times that an input queue was empty (timed out) over the last period.			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Retries	Retries	0	0 .. 4294967295

Variable IfUleStatsTXPushTimeouts		Encap OUT Congestion	Encap OUT Congestion	
Used as variable of	Command(s)			Page
	IfUleStats			137
Description	Variable that contains the number of times that an output queue was full (timed out) over the last period.			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Retries	Retries	0	0 .. 4294967295

Variable IfUleStatsTXIdle		Encap OUT Idle	Encap OUT Idle	
Used as variable of	Command(s)			Page
	IfUleStats			137
Description	Variable that contains the number of times that a packet is padded with idle bytes (0xFF) during encapsulation.			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Packets	Packets	0	0 .. 4294967295

Variable IfUleStatsRXMtuPackets		Decap OUT Ethernet	Decap OUT Ethernet	
Used as variable of	Command(s)			Page
	IfUleStats			137
Description	Variable that contains the number of Ethernet packets received during decapsulation over the last period			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Packets	Packets	0	0 .. 4294967295

Variable IfUleStatsRXMtuBytes		Decap OUT Ethernet	Decap OUT Ethernet	
Used as variable of	Command(s)			Page
	IfUleStats			137
Description	Variable that contains the number of bytes sent over Ethernet during decapsulation over the last period.			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Bytes	Bytes	0	0 .. 4294967295

Variable IfUleStatsRXMtuRate		Decap OUT Bitrate	Decap OUT Bitrate	
Used as variable of	Command(s)			Page
	IfUleStats			137
Description	Variable that contains the bitrate of the Ethernet frames decoded by the ULE processor.			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	bps	bps	0	0 .. 4294967295

Variable IfUleStatsRXMpegPackets		Decap IN TS		Decap IN TS			
Used as variable of	Command(s)			Page			
	IfUleStats			137			
Description	Variable that contains the number of MPEG transport stream packets processed during decapsulation over the last period.						
	Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
		Packets	packets	0	0 .. 4294967295		

Variable IfUleStatsRXPopTimeouts		Decap IN Pop		Decap IN Pop			
Used as variable of	Command(s)			Page			
	IfUleStats			137			
Description	Variable that contains the number of times that an input queue was empty (timed out) during decapsulation over the last period.						
	Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
		Retries	Retries	0	0 .. 4294967295		

Variable IfUleStatsRXPushTimeouts		Decap OUT Congestion		Decap OUT Congestion			
Used as variable of	Command(s)			Page			
	IfUleStats			137			
Description	Variable that contains the number of times that an output queue was full (timed out) during decapsulation over the last period.						
	Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
		Retries	Retries	0	0 .. 4294967295		

Variable IfUleStatsRXCRCErrors		Decap IN CRC		Decap IN CRC			
Used as variable of	Command(s)			Page			
	IfUleStats			137			
Description	Variable that contains the number of times that a CRC error was detected during processing.						
	Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
		Errors	Errors	0	0 .. 4294967295		

Variable IfUleStatsRXIdle		Decap IN Idle		Decap IN Idle			
Used as variable of	Command(s)			Page			
	IfUleStats			137			
Description	Variable that contains the number of times that a packet was idle.						

Variable IfUleStatsRXIdle		Decap IN Idle		Decap IN Idle	
Values	GUI Unit	Cmd Unit	Factory Default (CU)		Expert Range (CU)
	Packets	Packets	0		0 .. 4294967295

Variable IfMpeStatsTMMtuPackets		Encap IN Ethernet		Encap IN Ethernet			
Used as variable of	Command(s)				Page		
	IfMpeStats				138		
Description	Variable that contains the number of Ethernet packets received over the last period that were encapsulated.						
	Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
		Packets	Packets	0	0 .. 4294967295		

Variable IfMpeStatsTMMtuBytes		Encap IN Ethernet		Encap IN Ethernet			
Used as variable of	Command(s)				Page		
	IfMpeStats				138		
Description	Variable that contains the number of bytes of the Ethernet packets transmitted over the last period.						
	Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
		Bytes	Bytes	0	0 .. 4294967295		

Variable IfMpeStatsTMMtuRate		Encap IN Bitrate		Encap IN Bitrate			
Used as variable of	Command(s)				Page		
	IfMpeStats				138		
Description	Variable that contains the bitrate of the Ethernet frames encoded by the MPE processor.						
	Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
		bps	bps	0	0 .. 4294967295		

Variable IfMpeStatsTMMpegPackets		Encap OUT TS		Encap OUT TS			
Used as variable of	Command(s)				Page		
	IfMpeStats				138		
Description	Variable that contains the number of MPEG transport stream packets created over the last period.						
	Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
		Packets	Packets	0	0 .. 4294967295		

Variable IfMpeStatsRXMtuPackets		Decap OUT Ethernet		Decap OUT Ethernet		
Used as variable of	Command(s)			Page		
	IfMpeStats			138		
Description	Variable that contains the number of Ethernet packets received during decapsulation over the last period.					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Packets	packets	0	0 .. 4294967295		

Variable IfMpeStatsRXMtuBytes		Decap OUT Ethernet		Decap OUT Ethernet		
Used as variable of	Command(s)			Page		
	IfMpeStats			138		
Description	Variable that contains the number of bytes sent over Ethernet during decapsulation over the last period.					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Bytes	Bytes	0	0 .. 4294967295		

Variable IfMpeStatsRXMtuRate		Decap OUT Bitrate		Decap OUT Bitrate		
Used as variable of	Command(s)			Page		
	IfMpeStats			138		
Description	Variable that contains the bitrate of the Ethernet frames decoded by the MPE processor.					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	bps	bps	0	0 .. 4294967295		

Variable IfMpeStatsRXMpegPackets		Decap IN TS		Decap IN TS		
Used as variable of	Command(s)			Page		
	IfMpeStats			138		
Description	Variable that contains the number of MPEG transport stream packets processed during decapsulation over the last period.					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Packets	packets	0	0 .. 4294967295		

Variable IfMpeStatsRXCRCErrors		Decap IN CRC	Decap IN CRC	
Used as variable of	Command(s)			Page
	IfMpeStats			138
Description	Variable that contains the number of times that a CRC error was detected during processing.			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Errors	Errors	0	0 .. 4294967295

Variable IfDPStatsTXMtuPackets		Encap IN Ethernet	Encap IN Ethernet	
Used as variable of	Command(s)			Page
	IfDPStats			139
Description	Variable that contains the number of Ethernet packets received over the last period that were encoded. Remark: The measurement can be reset with the command IfDPStatsReset .			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Packets	Packets	0	0 .. 4294967295

Variable IfDPStatsTXMtuBytes		Encap IN Ethernet	Encap IN Ethernet	
Used as variable of	Command(s)			Page
	IfDPStats			139
Description	Variable that contains the total number of bytes of the Ethernet packets encoded over the last measuring period. Remark: The measurement can be reset with the command IfDPStatsReset .			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Bytes	Bytes	0	0 .. 4294967295

Variable IfDPStatsTXMtuRate		Encap IN Ethernet	Encap IN Ethernet	
Used as variable of	Command(s)			Page
	IfDPStats			139
Description	Variable that contains the bitrate of the incoming Ethernet frames encoded by the datapiping processor.			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	bps	bps	0	0 .. 4294967295

Variable IfDPStatsTXMpegPackets		Encap OUT TS	Encap OUT TS	
Used as variable of	Command(s)			Page
	IfDPStats			139
Description	Variable that contains the number of MPEG-2 transport stream packets encoded over the last measuring period. Remark: The measurement can be reset with the command IfDPStatsReset .			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Packets	Packets	0	0 .. 4294967295

Variable IfDPStatsTXPopTimeouts		Encap IN Pop	Encap IN Pop	
Used as variable of	Command(s)			Page
	IfDPStats			139
Description	Variable that contains the number of times during encapsulation that an attempt was made to get Ethernet packets from an input queue but failed because it was empty over the last period. Remark: The measurement can be reset with the command IfDPStatsReset .			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Retries	Retries	0	0 .. 4294967295

Variable IfDPStatsTXPushTimeouts		Encap OUT Congestion	Encap OUT Congestion	
Used as variable of	Command(s)			Page
	IfDPStats			139
Description	Variable that contains the number of times during encapsulation that an attempt was made to add MPEG packets to the FPGA output queue but failed because queue was full over the last period. Remark: The measurement can be reset with the command IfDPStatsReset .			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Retries	Retries	0	0 .. 4294967295

Variable IfDPStatsTXIdle		Encap OUT Idle	Encap OUT Idle	
Used as variable of	Command(s)			Page
	IfDPStats			139
Description	Variable that contains the number of times that an outgoing MPEG-2 transport stream packet was padded with idle bytes (0xFF) during encapsulation over the last measuring period. Remark: The measurement can be reset with the command IfDPStatsReset .			

Variable IfDPStatsTXIdle		Encap OUT Idle		Encap OUT Idle
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Packets	Packets	0	0 .. 4294967295

Variable IfDPStatsRXMtuPackets		Decap OUT Ethernet	Decap OUT Ethernet
Used as variable of	Command(s)		Page
	IfDPStats		139
Description	Variable that contains the number of Ethernet packets sent during decapsulation over the last measuring period. Remark: The measurement can be reset with the command IfDPStatsReset .		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Packets	Packets	0
			0 .. 4294967295

Variable IfDPStatsRXMtuBytes		Decap OUT Ethernet	Decap OUT Ethernet
Used as variable of	Command(s)		Page
	IfDPStats		139
Description	Variable that contains the total number of bytes of the Ethernet packets sent during decapsulation over the last measuring period. Remark: The measurement can be reset with the command IfDPStatsReset .		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Bytes	Bytes	0
			0 .. 4294967295

Variable IfDPStatsRXMtuRate		Decap OUT Ethernet	Decap OUT Ethernet
Used as variable of	Command(s)		Page
	IfDPStats		139
Description	Variable that contains the bitrate (expressed in bit/s) of outgoing Ethernet frames decoded by the datapiping processor.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	bps	bps	0
			0 .. 4294967295

Variable IfDPStatsRXMpegPackets		Decap IN TS	Decap IN TS
Used as variable of	Command(s)		Page
	IfDPStats		139
Description	Variable that contains the number of MPEG-2 transport stream packets decoded over the last measuring period. Remark: The measurement can be reset with the command		

Variable IfDPStatsRXMpegPackets		Decap IN TS		Decap IN TS	
	<i>IfDPStatsReset.</i>				
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)	
	Packets	Packets	0	0 .. 4294967295	

Variable IfDPStatsRXPopTimeouts		Decap IN Pop		Decap IN Pop		
Used as variable of	Command(s)			Page		
	IfDPStats			139		
Description	Variable that contains the number of times that the input queue was empty (timed out) during decapsulation over the last measuring period. Remark: The measurement can be reset with the command <i>IfDPStatsReset.</i>					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Retries	Retries	0	0 .. 4294967295		

Variable IfDPStatsRXPushTimeouts		Decap OUT Congestion		Decap OUT Congestion		
Used as variable of	Command(s)			Page		
	IfDPStats			139		
Description	Variable that contains the number of times that the output queue was full (timed out) during decapsulation over the last measuring period. Remark: The measurement can be reset with the command <i>IfDPStatsReset.</i>					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Retries	Retries	0	0 .. 4294967295		

Variable IfDPStatsRXIdle		Decap IN Idle		Decap IN Idle		
Used as variable of	Command(s)			Page		
	IfDPStats			139		
Description	Variable that contains the number of times that an incoming MPEG-2 transport stream packet contained padding bytes (0xFF) over the last measuring period. Remark: The measurement can be reset with the command <i>IfDPStatsReset.</i>					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Packets	Packets	0	0 .. 4294967295		

Variable IfGBSStatsTXEthPackets		Encap IN Ethernet	Encap IN Ethernet	
Used as variable of	Command(s)			Page
	IfGBSStats			140
Description	Variable that contains the number of Ethernet packets received over the last period that were encapsulated.			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Packets	packets	0	0 .. 4294967295

Variable IfGBSStatsTXEthBytes		Encap IN Ethernet	Encap IN Ethernet	
Used as variable of	Command(s)			Page
	IfGBSStats			140
Description	Variable that contains the number of bytes of the Ethernet packets transmitted over the last period.			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Bytes	Bytes	0	0 .. 4294967295

Variable IfGBSStatsTXEthRate		Encap IN Bitrate	Encap IN Bitrate	
Used as variable of	Command(s)			Page
	IfGBSStats			140
Description	Variable that contains the bitrate of Ethernet frames encoded by the XPE processor.			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	bps	bps	0	0 .. 4294967295

Variable IfGBSStatsTXPopTimeouts		Encap IN Pop	Encap IN Pop	
Used as variable of	Command(s)			Page
	IfGBSStats			140
Description	Variable that contains the number of times that an input queue was empty (timed out) over the last period.			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Retries	Retries	0	0 .. 4294967295

Variable IfGBSStatsTXBBFrames		Encap OUT BB Fram	Encap OUT BB Fram	
Used as variable of	Command(s)			Page
	IfGBSStats			140
Description	Variable that contains the number of DVB-S2 baseband frames encoded by the interface card over the last statistics period.			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Frames	Frames	0	0 .. 4294967295

Variable IfGBSStatsTXBBBytes		Encap OUT BB Fram	Encap OUT BB Fram	
Used as variable of	Command(s)			Page
	IfGBSStats			140
Description	Variable that contains the number of bytes of the DVB-S2 Baseband frames created by the interface card that are transmitted over the last period.			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Bytes	Bytes	0	0 .. 4294967295

Variable IfGBSStatsTXPushTimeouts		Encap OUT Congestion	Encap OUT Congestion	
Used as variable of	Command(s)			Page
	IfGBSStats			140
Description	Variable that contains the number of times that an output queue was full (timed out) over the last period.			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Retries	Retries	0	0 .. 4294967295

Variable IfGBSStatsRXBBFrames		Decap IN BB Fram	Decap IN BB Fram	
Used as variable of	Command(s)			Page
	IfGBSStats			140
Description	Variable that contains the number of DVB-S2 baseband frames processed during decapsulation over the last period.			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Frames	Frames	0	0 .. 4294967295

Variable IfGBSStatsRXBBBytes		Decap IN BB Fram		Decap IN BB Fram			
Used as variable of	Command(s)			Page			
	IfGBSStats			140			
Description	Variable that contains the number of bytes from the DVB-S2 baseband frames processed during decapsulation over the last period.						
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)			
	Bytes	Bytes	0	0 .. 4294967295			

Variable IfGBSStatsRXPopTimeouts		Decap IN Pop		Decap IN Pop			
Used as variable of	Command(s)			Page			
	IfGBSStats			140			
Description	Variable that contains the number of times that an input queue was empty (timed out) during decapsulation over the last period.						
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)			
	Retries	Retries	0	0 .. 4294967295			

Variable IfGBSStatsRXCRCErrors		Decap IN CRC		Decap IN CRC			
Used as variable of	Command(s)			Page			
	IfGBSStats			140			
Description	Variable that contains the number of times that a CRC error was detected during processing.						
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)			
	Errors	Errors	0	0 .. 4294967295			

Variable IfGBSStatsRXDropped		Decaps IN Dropped		Decaps IN Dropped			
Used as variable of	Command(s)			Page			
	IfGBSStats			140			
Description	Variable that contains the number of times that a DVB-S2 baseband frame was dropped (bad data field length, CRC-8 error, no ISI, etc.) during decapsulation over the last period. Well-behaved systems should have zero drops.						
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)			
	Frames	Frames	0	0 .. 4294967295			

Variable IfGBSStatsRXEthPackets		Decap OUT Ethernet		Decap OUT Ethernet		
Used as variable of	Command(s)			Page		
	IfGBSStats			140		
Description	Variable that contains the number of Ethernet packets that are output during decapsulation over the last period.					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Packets	packets	0	0 .. 4294967295		

Variable IfGBSStatsRXEthBytes		Decap OUT Ethernet		Decap OUT Ethernet		
Used as variable of	Command(s)			Page		
	IfGBSStats			140		
Description	Variable that contains the number of bytes sent over Ethernet during decapsulation over the last period.					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Bytes	Bytes	0	0 .. 4294967295		

Variable IfGBSStatsRXEthRate		Decap OUT Bitrate		Decap OUT Bitrate		
Used as variable of	Command(s)			Page		
	IfGBSStats			140		
Description	Variable that contains the bitrate of Ethernet frames decoded by XPE processor.					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	bps	bps	0	0 .. 4294967295		

Variable IfGBSStatsRXPushTimeouts		Decap OUT Congestion		Decap OUT Congestion		
Used as variable of	Command(s)			Page		
	IfGBSStats			140		
Description	Variable that contains the number of times that an output queue was full (timed out) during decapsulation over the last period.					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Retries	Retries	0	0 .. 4294967295		

Variable IfGSEStatsTxEthPackets		Encap IN Ethernet		Encap IN Ethernet		
Used as variable of	Command(s)			Page		
	IfGSEStats			141		
Description	Number of ethernet packets received over the last period that were encapsulated					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Packets	packets	0	0 .. 4294967295		

Variable IfGSEStatsTxEthBytes		Encap IN Ethernet		Encap IN Ethernet		
Used as variable of	Command(s)			Page		
	IfGSEStats			141		
Description	Number of bytes of the ethernet packets transmitted over the last period.					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Bytes	Bytes	0	0 .. 4294967295		

Variable IfGSEStatsTxEthRate		Encap IN Bitrate		Encap IN Bitrate		
Used as variable of	Command(s)			Page		
	IfGSEStats			141		
Description	Bitrate of ethernet frames encoded by XPE processor. (bps)					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	bps	bps	0	0 .. 4294967295		

Variable IfGSEStatsTXPopTimeouts		Encap IN Pop		Encap IN Pop		
Used as variable of	Command(s)			Page		
	IfGSEStats			141		
Description	Number of times that an input queue was empty (timed out) over the last period.					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Retries	Retries	0	0 .. 4294967295		

Variable IfGSEStatsTXBBFrames		Encap OUT BB Fram		Encap OUT BB Fram		
Used as variable of	Command(s)			Page		
IfGSEStats				141		
Description	Number of DVB-S2 Baseband Frames encoded by the interface card over the last statistics period.					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Frames	Frames	0	0 .. 4294967295		

Variable IfGSEStatsTXBBBytes		Encap OUT BB Fram		Encap OUT BB Fram		
Used as variable of	Command(s)			Page		
IfGSEStats				141		
Description	Number of bytes of the DVB-S2 Baseband frames created by the interface card that are transmitted over the last period.					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Bytes	Bytes	0	0 .. 4294967295		

Variable IfGSEStatsTXPushTimeouts		Encap OUT Congestion		Encap OUT Congestion		
Used as variable of	Command(s)			Page		
IfGSEStats				141		
Description	Number of times that an output queue was full (timed out) over the last period.					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Retries	Retries	0	0 .. 4294967295		

Variable IfGSEStatsTxFragmented		Encap OUT Fragmented		Encap OUT Fragmented		
Used as variable of	Command(s)			Page		
IfGSEStats				141		
Description	Number of times that a GSE frame was fragmented during encapsulation over the last period.					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Frames	Frames	0	0 .. 4294967295		

Variable IfGSEStatsRXBBFrames		Decap IN BB Fram		Decap IN BB Fram		
Used as variable of	Command(s)			Page		
	IfGSEStats			141		
Description	Number of DVB-S2 Baseband frames processed during decapsulation over the last period					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Frames	Frames	0	0 .. 4294967295		

Variable IfGSEStatsRXBBBytes		Decap IN BB Fram		Decap IN BB Fram		
Used as variable of	Command(s)			Page		
	IfGSEStats			141		
Description	Number of bytes of the DVB-S2 Baseband frames processed during decapsulation over the last period					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Bytes	Bytes	0	0 .. 4294967295		

Variable IfGSEStatsRXPopTimeouts		Decap IN Pop		Decap IN Pop		
Used as variable of	Command(s)			Page		
	IfGSEStats			141		
Description	Number of times that an input queue was empty (timed out) during decapsulation over the last period.					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Retries	Retries	0	0 .. 4294967295		

Variable IfGSEStatsRXCRCErrors		Decap IN CRC		Decap IN CRC		
Used as variable of	Command(s)			Page		
	IfGSEStats			141		
Description	Number of times that a CRC error was detected during processing.					
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	Errors	Errors	0	0 .. 4294967295		

Variable IfGSEStatsRXDropped		Decaps IN Dropped		Decaps IN Dropped		
Used as variable of	Command(s)			Page		
	IfGSEStats			141		
Description	Number of times that a DVB-S2 baseband frame was dropped (bad DFL, CRC8 error, no ISI ...) during decapsulation over the last period. Well-					

Variable IfGSEStatsRXDropped		Decaps IN Dropped		Decaps IN Dropped	
Values	behaved systems should have 0 drops				
	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)	
Frames	Frames	0	0 .. 4294967295		

Variable IfGSEStatsRXEthPackets		Decap OUT Ethernet		Decap OUT Ethernet	
Used as variable of	Command(s)				Page
	IfGSEStats				141
Description	Number of ethernet packets that are output during decapsulation over the last period				
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)	
	Packets	Packets	0	0 .. 4294967295	

Variable IfGSEStatsRXEthBytes		Decap OUT Ethernet		Decap OUT Ethernet	
Used as variable of	Command(s)				Page
	IfGSEStats				141
Description	Number of bytes sent over ethernet during decapsulation over the last period.				
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)	
	Bytes	Bytes	0	0 .. 4294967295	

Variable IfGSEStatsRXEthRate		Decap OUT Bitrate		Decap OUT Bitrate	
Used as variable of	Command(s)				Page
	IfGSEStats				141
Description	Bitrate of ethernet frames decoded by GBS processor. (bps)				
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)	
	bps	bps	0	0 .. 4294967295	

Variable IfGSEStatsRXPushTimeouts		Decap OUT Congestion		Decap OUT Congestion	
Used as variable of	Command(s)				Page
	IfGSEStats				141
Description	Number of times that an output queue was full (timed out) during decapsulation over the last period.				
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)	
	Retries	Retries	0	0 .. 4294967295	

Variable IfGSEStatsRXFragmented		Decaps IN Fragmented	Decaps IN Fragmented	
Used as variable of	Command(s)			Page
	IfGSEStats			141
Description	Number of times that a GSE frame was fragmented during decapsulation over the last period.			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	Frames	Frames	0	0 .. 4294967295

Variable IfVLANStatsActive		Active	Active	
Used as variable of	Command(s)			Page
	IfVLANStats			143
Description	Variable that contains the indication that the VLAN statistics entry is valid. When this setting is active, the rest of the VLAN statistics members have valid information.			
Values	Factory Default	Enumeration	Value	
	notactive	Not Active Active	0 1	

Variable IfVLANStatsName		Name	Name	
Used as variable of	Command(s)			Page
	IfVLANStats			143
Description	Variable that contains a human readable name for the VLAN and its interface. The format is <Interface> VLAN <VLAN ID>. <ul style="list-style-type: none">• Interface is either interface A or B.• VLAN ID is the identifier of the VLAN.			
Values	Factory Default	String Description		
		length : 0 .. 20 format : any chars		

Variable IfVLANStatsTxPackets		TX Packets	TX Packets	
Used as variable of	Command(s)			Page
	IfVLANStats			143
Description	Variable that contains the number of Ethernet packets transmitted over VLAN (kernel counter).			
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	NA	NA	0	0 .. 4294967295

Variable IfVLANStatsTxBytes		TX Bytes	TX Bytes
Used as variable of	Command(s)		Page
	IfVLANStats		143
Description	Variable that contains the number of bytes transmitted over VLAN (kernel counter).		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	NA	NA	0 .. 4294967295

Variable IfVLANStatsRxPackets		RX Packets	RX Packets
Used as variable of	Command(s)		Page
	IfVLANStats		143
Description	Variable that contains the number of Ethernet packets received over VLAN (kernel counter).		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	NA	NA	0 .. 4294967295

Variable IfVLANStatsRxBytes		RX Bytes	RX Bytes
Used as variable of	Command(s)		Page
	IfVLANStats		143
Description	Variable that contains the number of bytes received over VLAN (kernel counter).		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	NA	NA	0 .. 4294967295

Variable IfQosStatsPriority		Priority	Priority
Used as variable of	Command(s)		Page
	IfQosStatsEntry		144
Description	Variable that contains the name for the quality of service queue.		
Values	Factory Default	String Description	
	init	length : 0 .. 15 format : any chars	

Variable IfQosStatsBytesDropped		Bytes dropped	Bytes dropped
Used as variable of	Command(s)		Page
	IfQosStatsEntry		144
Description	Variable that contains the number of bytes dropped for this quality of		

Variable IfQosStatsBytesDropped		Bytes dropped		Bytes dropped	
	service class.				
Values	<i>GUI Unit</i>	<i>Cmd Unit</i>	<i>Factory Default (CU)</i>		<i>Expert Range (CU)</i>
	Bytes	Bytes	0		0 .. 4294967295

Variable MoMonAcmStreamStrid		DVB-S2 Stream Id		DVB-S2 Stream Id			
Used as variable of	Command(s)			Page			
	MoMonAcmStreamEntry			156			
Description	ACM stream id.						
	Values	<i>GUI Unit</i>	<i>Cmd Unit</i>	<i>Factory Default (CU)</i>	<i>Expert Range (CU)</i>		
NA		NA	1	1 .. 35			

Variable MoMonAcmStreamFrameType		FEC-Frame type		FEC-Frame type			
Used as variable of	Command(s)			Page			
	MoMonAcmStreamEntry			156			
Description	Frame type of the monitored stream.						
Values	<i>Factory Default</i>	<i>Enumeration</i>	Value				
	short	Short Normal	0 1				

Variable MoMonAcmStreamNChanges		#changes		#changes			
Used as variable of	Command(s)			Page			
	MoMonAcmStreamEntry			156			
Description	Number of changes requested for this stream by ACM.						
Values	<i>GUI Unit</i>	<i>Cmd Unit</i>	<i>Factory Default (CU)</i>	<i>Expert Range (CU)</i>			
	changes	changes	0	0 .. 4294967295			

Variable MoMonAcmStreamModcod		MODCOD		MODCOD			
Used as variable of	Command(s)			Page			
	MoMonAcmStreamEntry			156			
Description	Latest modcod requested via ACM.						
Values	<i>Factory Default</i>	<i>Enumeration</i>	Value				
	noRequest	No request QPSK-1/2 QPSK-2/3 QPSK-3/4	0 11 12 13				

Variable MoMonAcmStreamModcod	MODCOD	MODCOD
	QPSK-5/6	15
	QPSK-6/7	16
	QPSK-7/8	17
	QPSK-1/4	21
	QPSK-1/3	22
	QPSK-2/5	23
	QPSK-3/5	24
	QPSK-4/5	25
	QPSK-8/9	26
	QPSK-9/10	27
	16APSK-2/3	42
	16APSK-3/4	43
	16APSK-4/5	44
	16APSK-5/6	45
	16APSK-8/9	48
	16APSK-9/10	49
	32APSK-3/4	53
	32APSK-4/5	54
	32APSK-5/6	55
	32APSK-8/9	58
	32APSK-9/10	59
	8PSK-3/5	81
	8PSK-2/3	82
	8PSK-3/4	83
	8PSK-5/6	85
	8PSK-6/7	86
	8PSK-7/8	87
	8PSK-8/9	88
	8PSK-9/10	89

Variable MoMonAcmDmSupvlp	Demodulator IP	Demodulator IP
Used as variable of	<i>Command(s)</i>	<i>Page</i>
	MoMonAcmDmSupvEntry	
Description	The IP address of the demodulator device that is supervised by the ACM controller.	
Values	<i>Factory Default</i>	<i>String Description</i>
	0.0.0.0	length : 0 .. 15 format : \d{1,3}\.\d{1,3}\.\d{1,3}\.\d{1,3}

Variable MoMonAcmDmSupvStrid	DVB-S2 Stream Id	DVB-S2 Stream Id		
Used as variable of	<i>Command(s)</i>	<i>Page</i>		
	MoMonAcmDmSupvEntry			
Description	DVB-S2 stream id that is modified under control of this ACM enabled demodulator.			
Values	<i>GUI Unit</i>	<i>Cmd Unit</i>	<i>Factory Default (CU)</i>	<i>Expert Range (CU)</i>

Variable MoMonAcmDmSupvStrid	DVB-S2 Stream Id		DVB-S2 Stream Id	
	NA	NA	1	1 .. 35

Variable MoMonAcmDmSupvEsno	EsNo	EsNo		
Used as variable of	<i>Command(s)</i>	<i>Page</i>		
	MoMonAcmDmSupvEntry	155		
Description	EsNo of ACM enabled demodulator.			
Values	<i>GUI Unit</i>	<i>Cmd Unit</i>	<i>Factory Default (CU)</i>	<i>Expert Range (CU)</i>
	dB	dB	0	-5 .. 50

Variable MoMonAcmDmSupvModcod	MODCOD		MODCOD		
Used as variable of	<i>Command(s)</i>		<i>Page</i>		
	MoMonAcmDmSupvEntry		155		
Description	MODCOD requested by ACM enabled demod.				
Values	<i>Factory Default</i>	<i>Enumeration</i>	<i>Value</i>		
	noRequest	No request QPSK-1/2 QPSK-2/3 QPSK-3/4 QPSK-5/6 QPSK-6/7 QPSK-7/8 QPSK-1/4 QPSK-1/3 QPSK-2/5 QPSK-3/5 QPSK-4/5 QPSK-8/9 QPSK-9/10 16APSK-2/3 16APSK-3/4 16APSK-4/5 16APSK-5/6 16APSK-8/9 16APSK-9/10 32APSK-3/4 32APSK-4/5 32APSK-5/6 32APSK-8/9 32APSK-9/10 8PSK-3/5 8PSK-2/3 8PSK-3/4 8PSK-5/6 8PSK-6/7 8PSK-7/8		0 11 12 13 15 16 17 21 22 23 24 25 26 27 42 43 44 45 48 49 53 54 55 58 59 81 82 83 85 86 87	

Variable MoMonAcmDmSupvModcod		MODCOD	MODCOD
		8PSK-8/9 8PSK-9/10	88 89

Variable MoMonAcmDmSupvNumRx		#rxed	#rxed
Used as variable of	Command(s)		Page
	MoMonAcmDmSupvEntry		
Description	Number of received ACM messages		
Values	GUI Unit	Cmd Unit	Factory Default (CU) Expert Range (CU)
	errors	errors	0 .. 4294967295

Variable MoMonAcmDmSupvNumTo		#timeouts	#timeouts
Used as variable of	Command(s)		Page
	MoMonAcmDmSupvEntry		
Description	Number of ACM timeouts of a demod.		
Values	GUI Unit	Cmd Unit	Factory Default (CU) Expert Range (CU)
	errors	errors	0 .. 4294967295

Variable MoMonAcmDmSupvNumCto		#contiguous timeouts	#contiguous timeouts
Used as variable of	Command(s)		Page
	MoMonAcmDmSupvEntry		
Description	Number of contiguous timeouts of an ACM enabled demodulator.		
Values	GUI Unit	Cmd Unit	Factory Default (CU) Expert Range (CU)
	errors	errors	0 .. 4294967295

Variable SyDevModePass		Device mode password	Device mode password
Used as variable of	Command(s)		Page
	SyDevMode		
Description	This variable holds the password for activating a new device mode. It serves as temporary variable argument to the device mode set command.		
Values	Factory Default	String Description	
		length : 0 .. 24 format : Hexadecimal chars	

Variable SyDevModeReply		Device mode status reply	Device mode status reply
Used as variable of	Command(s)		Page
	SyDevMode		
Description	Status reply for the device mode command.		
Values	Factory Default	Enumeration	Value
		Success	0
		Failed	1

Variable SyDevCapPass		Software license key	Software license key
Used as variable of	Command(s)		Page
	SyDevCapab		
Description	Variable that contains the password (software license key) for activating device capability.		
Values	Factory Default	String Description	
	0123456789abcdef	length : 16 (fixed) format : Hexadecimal chars	

Variable SyDevCapReply		Capability status reply	Capability status reply
Used as variable of	Command(s)		Page
	SyDevCapab		
Description	Variable that contains the status reply for the capability command.		
Values	Factory Default	Enumeration	Value
		Success	0
		Failed	1

Variable SyActionKeyId		ActionKey number	ActionKey number
Used as variable of	Command(s)		Page
	SyActKeyActivate		
Description	The action-key identifier variable identifies a key on the numeric keypad of the front panel.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	NA	NA	0 .. 9

Variable SyActionKeyReply		ActionKey command status	ActionKey command status
Used as variable of	Command(s)		Page
	SyActKeyActivate		
Description	Variable that contains the return code after action-key related commands		

Variable SyActionKeyReply		ActionKey command status	ActionKey command st
	are executed.		
Values	Factory Default	Enumeration	Value
		Success Failed	0 1

Variable ODUInfoIndex		Engineering string index	Index
Used as variable of	Command(s)		Page
	ODUInfoReq		238
Description	Temporary variable containing the outdoor unit engineering string index.		
	Values	GUI Unit	Cmd Unit
		NA	NA
			Factory Default (CU)
			0 .. 255
			Expert Range (CU)

Variable ODUInfoVal		Outdoor unit engineering string data	ODU eng. string data
Used as variable of	Command(s)		Page
	ODUInfoReq		238
Description	Variable that contains contents of the addressed part of the outdoor unit engineering string. This is a temporary variable, used by the special commands for accessing the outdoor unit engineering string data.		
	Values	Factory Default	String Description
			length : 0 .. 100 format : any chars

Variable SyConfigNum		Configuration number	Configuration number
Used as variable of	Command(s)		Page
	SyConfigLoadFlash SyConfigSaveFlash SyCfgName		166 167 167
Description	Variable that contains the configuration number for load and save configuration operations in internal flash.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	NA	NA	0
			Expert Range (CU)
			0 .. 4

Variable SyConfigStatus		Configuration status	Configuration status
Used as variable of	Command(s)		Page
	SyConfigLoadFlash SyConfigSaveFlash		166 167

Variable SyConfigStatus		Configuration status	Configuration status
	SyCfgName	167	
Description	Variable that replies the status after load and save configuration operations.		
Values	Factory Default	Enumeration	Value
		Success Failed	0 1

Variable SyLoadConfNum		Last loaded config number	Loadd conf. num.
Used as variable of	Command(s)		Page
	SyConfigLoadFlash		166
Description	The last loaded configuration number variable contains the specifier for last loaded configuration in internal flash.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	NA	NA	-1 .. 4

Variable SySaveConfNum		Last saved config number	Saved conf. num.
Used as variable of	Command(s)		Page
	SyConfigSaveFlash		167
Description	The last saved configuration number variable specifies the last saved configuration in internal flash.		
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	NA	NA	-1 .. 4

Variable SyConfigName		Configuration name	Configuration name
Used as variable of	Command(s)		Page
	SyCfgName		167
Description	Variable that contains the configuration name. This name will be visible in the top-row of the display when browsing through the different stored configurations.		
Values	Factory Default	String Description	
	def	length : 0 .. 20 format : any chars	

Variable AIAlarmString		Alarm string	Alarm string
Used as variable of	Command(s)		Page
	AIAlarmsCur AIAlarmsMem		246 247

Variable AIAAlarmString		Alarm string	Alarm string
	AIAlarmsMode		247
Description	This variable contains the concatenated string of individual replies for alarm requests.		
Values	Factory Default	String Description	
	1111111111111111 1111111111111111 1111111111111111 1111111111111111 111111111111	length : 71 (fixed) format : any chars	

Variable AIAAlarmId		Device alarm identification	Alarm Id
Used as variable of	Command(s)		Page
	AIAlarmCur AIAlarmMem		248 247
Description	This variable identifies an alarm of the device. It is used by the individual alarm commands.		
Values	Factory Default	Enumeration	Value
		Reset flag	0
		Self test	1
		Inc.	2
		General device	3
		Interface	4
		Ref. clk.	5
		Device temperature	6
		Power supply voltage	7
		NCR inserter GPS 1pps	8
		Ethernet IfA Link	9
		Ethernet IfB Link	10
		Ethernet IfA half duplex	11
		Ethernet IfB half duplex	12
		IP gateway unreachable	13
		Ethernet interface switchover	14
		Rx 1 Alarm	15
		Rx 2 Alarm	16
		Rx 5 Alarm	17
		ASI interface switchover	18
		AuxInt. ASI opt. sig. det.	19
		AuxInt. LVDS signal detect	20
		Superframe sync	21
		Decon Tmd	22
		AuxInt. Input framing	23
		Demod RX Decoder Bad Packet	24
		Demod Rx Buffer Overflow	25
		BB sync	37
		Tx 1 overflow	38
		Tx 2 overflow	39
		Tx 3 overflow	40
		Tx 4 overflow	41
		Tx 1 signal	42

Variable AIAlarmId	Device alarm identification	Alarm Id
	Tx 2 signal	43
	Tx 3 signal	44
	Tx 4 signal	45
	Clock PLL	46
	Synthesiser	47
	Out of lock LO1	48
	Out of lock LO2	49
	RF phase lock DRO	50
	ODU communication	51
	Demod lock	52
	Demod Tuner Lock	53
	Demod PL sync	54
	Demod BB sync	55
	ODU architecture	56
	ODU summary	57
	BISS	58
	M&C module	59
	Interf. module	60
	Deconcentrator module	61
	Aux. interf. module	62
	Mod. alarm	63
	Demod. module	64
	Upconverter	65
	IF To L-band module	66
	IFL converter	67
	Architecture	68
	Internal communication	69
	NCR sync status	70

Variable AIAlarmStatus	Alarm status reply	Alarm status reply
Used as variable of	Command(s)	Page
	AIAlarmCur	248
Description	This variable contains the status reply for alarms. <ul style="list-style-type: none"> • 0: Status is OK. • 1: Alarm. 	
Values	Factory Default	Enumeration
		Value
		Status OK
		0
		Alarm
		1

Variable AIAlarmCounter	Alarm events	Alarm events
Used as variable of	Command(s)	Page
	AIAlarmMem	247
Description	Readout of the number of alarm events since last reset of the alarm event counter.	
Values	GUI Unit	Cmd Unit
	Factory Default (CU)	Expert Range (CU)

Variable AIAlarmCounter		Alarm events		Alarm events
	events	events		0 .. 255

Command IfDvbs2BboeRxEnable		Active		Active
Used as variable of	Command(s)			Page
	IfDvbs2BboeRxInstances			68
Description	Selection if the configuration entry is enabled or not. <ul style="list-style-type: none">• Enabled• Disabled			
RMCP Command	BrE		Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry		
	Command	ntcDevsMod01IfDvbs2BboeRxEnable		
	OID	1.3.6.1.4.1.5835.3.1.4.1.131.1.1		
Values	Factory Default		Enumeration	Value
	disabled		Disabled Enabled	0 1

Command IfDvbs2BboeRxMcastIpAddress		Baseband receive IP address	IP address	
Used as variable of	Command(s)			Page
	IfDvbs2BboeRxInstances			68
Description	This field contains the IP address used for receiving DVB-S2 baseband frames from the encapsulator.			
RMCP Command	Brl		Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry		
	Command	ntcDevsMod01IfDvbs2BboeRxMcastIpAddress		
	OID	1.3.6.1.4.1.5835.3.1.4.1.133.1.1		
Values	Factory Default		String Description	
	0.0.0.0		length : 0 .. 15 format : \d{1,3}\.\d{1,3}\.\d{1,3}\.\d{1,3}	

Test

EL470 >> Test

In this section of the menu you can start some tests with the unit.

/Modem/Test/Interfaces

Command GbeTestRst		GBE Test Reset	GBE Test Reset
Location	/Modem/Test/Interfaces		
Description	This command performs a reset of the gigabit Ethernet board for test purposes.		
RMCP Command	GTR	Access	Normal user : no access Expert user : W
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01GbeTestRst	
	OID	1.3.6.1.4.1.5835.3.1.4.1.181.1.1	
Values	Factory Default	Enumeration	Value
	Disable configuration		1

Command MoBufTimeLimit		Max Eth-to-mod buffering delay	Max Eth-to-mod buffer
Location	/Modem/Test/Interfaces		
Description	Configuration of the maximum buffering delay for Ethernet packets that travel from the Ethernet interface to the modulator. This value is especially important when traffic goes from a variable rate network (e.g. Ethernet) to a network with a lower bitrate (the satellite link).		
RMCP Command	Mbd	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoBufTimeLimit	
	OID	1.3.6.1.4.1.5835.3.1.3.1.100.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU) Expert Range (CU)
	ms	ms	750 0 .. 30000

Command	MoBufNonQosTimeLim	qos unaware eth-to-mod queue size	qos unaware eth-to-m	
Location	<code>/Modem/Test/Interfaces</code>			
Description	Configuration of the queue length in milliseconds for Ethernet packets that travel from the Ethernet interface board to the modulator board. This small queue is not quality of service aware. It should be small enough, to avoid non-quality of service aware queuing. It should be large enough, to avoid buffer underflow: buffer underflow would reduce the throughput of the system.			
RMCP Command	qub	Access		
SNMP	Table	ntcDevsMod01ModulatorEntry		
	Command	ntcDevsMod01MoBufNonQosTimeLim		
	OID	1.3.6.1.4.1.5835.3.1.3.1.105.1.1		
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)
	mS	mS	5	0 .. 30000

/Modem/Test/Modulation

Command	IfBbbTxSig	Internal Baseband Output to Modulator	Internal BB Output
Location	<code>/Modem/Test/Modulation</code>		
Description	Configuration of the output signal to the internal modulator baseband board connector. Typically four possibilities exist: <ul style="list-style-type: none">• By default the active external interface input signal is selected.• When an additional processing function is present (e.g. rate adaptation), the output of the processing block can be selected.• For testing purposes a test generator signal can be routed to the modulator.• The selection off, disables the output signal.		
RMCP Command	BTS		Access
Values	Factory Default	Enumeration	Value
	off	OFF Rx Sig TG Proc Signal AIS Buffer	0 1 2 3 4 5

Command IfComTxSig		Interface output signal selection	Output signal
Location	/Modem/Test/Modulation		
Description	<p>Configuration of the output signal placed on all outputs of the interface board.</p> <p>By default the active external interface input signal is brought back out. When an additional processing function is present (e.g. the rate adapter) the output of the processing block can be selected.</p> <p>For testing purposes, a test generator signal can be routed to the output (local loopback).</p> <p>The selection off disables the output signal.</p> <p>Remark: The output signal selection is independent of the input interface type selection.</p>		
RMCP Command	COS	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01InterfaceEntry	
	Command	ntcDevsMod01IfComTxSig	
	OID	1.3.6.1.4.1.5835.3.1.4.1.44.1.1	
Values	Factory Default	Enumeration	Value
	rxsignal	Off Rx sig. TG Proc. sig. AIS Buffer	0 1 2 3 4 5

Command ODUSSPAARfAlTrippoint		HPA RF power alarm level setpoint	HPA power alarm setp
Location	/Modem/Test/Modulation		
Description	Configuration of the high power amplifier RF alarm level set-point.		
RMCP Command	THt	Access	Normal user : no access Expert user : RW
	Table	ntcDevsMod01ODUEntry	
	Command	ntcDevsMod01ODUSSPAARfAlTrippoint	
Values	OID	1.3.6.1.4.1.5835.3.1.14.1.6.1.1	
	GUI Unit	Cmd Unit	Factory Default (CU)
	W	W	0 .. 9999

Command ODUSSPAAttenuation		HPA attenuation	HPA attenuation
Location	/Modem/Test/Modulation		
Description	Configuration of the high power amplifier attenuation.		
RMCp Command	THg	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ODUEntry	
	Command	ntcDevsMod01ODUSSPAAttenuation	
	OID	1.3.6.1.4.1.5835.3.1.14.1.7.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	dB	dB	0 .. 99.9

Special Command ODUInfoReq		Engineering string request	Eng. string
Location	/Modem/Test/Modulation		
Description	Readout of the engineering string data from the outdoor unit. The engineering string is additional information about the outdoor unit that is not needed on an operational basis but can be accessed for troubleshooting purposes.		
RMCp Command	Eng		Access Normal user : no access Expert user : R
SNMP	Table	ntcDevsMod01ODUEntry	
	Command	ntcDevsMod01ODUInfoReq	
	OID	1.3.6.1.4.1.5835.3.1.14.1.5.1.1	
Get Command Arguments		Set Command Arguments	
Command(s) / Variable(s)	Page	Command(s) / Variable(s)	Page
ODUInfofold	230	NA	NA
Get Reply Values		Set Reply Values	
Command(s) / Variable(s)	Page	Command(s) / Variable(s)	Page
ODUInfoVal	230	NA	NA

Command MoTxData		Transmit data	Transmit data
Location	/Modem/Test/Modulation		
Description	<p>Configuration which source will transmit data. Select between external data input as source to transmit data (default) and internally generated PRBS. For testing, installation and link evaluation, the internal data generator on the modulator can be used as a transmit data source. This data source generates a PRBS (pseudo random binary sequence) data stream of 2^23-1 as specified in CCITT Rec. 0.151.</p> <p>In conjunction with a Newtec demodulator that is standard equipped with an automatic PRBS detector, the possibility exists to determine the actual BER performance of a satellite link.</p>		
RMCP Command	TDi	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoTxData	
	OID	1.3.6.1.4.1.5835.3.1.3.1.35.1.1	
Values	Factory Default	Enumeration	Value
	external	External Int testgenerator	0 5

Command MoTgFrameType		DVB-S2 Testgenerator FEC-Frame type	Testgen Frame type
Location	/Modem/Test/Modulation		
Description	<p>Configuration of the DVB-S2 FEC-frame type parameter on the test generator when MoTgFrameFormat is set to baseband frames.</p> <p>DVB-S2 defines two FEC-frame types:</p> <ul style="list-style-type: none"> Normal FEC-frames of 64800 bits or 8100 bytes. Short FEC-frames of 16200 bits or 2025 bytes. 		
RMCP Command	TCF	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoTgFrameType	
	OID	1.3.6.1.4.1.5835.3.1.3.1.108.1.1	
Values	Factory Default	Enumeration	Value
	short	Short Normal	0 1

Command MoTgFecMod2		Testgen FEC-rate and modulation	Testgen FEC-rate and																																																																			
Location	/Modem/Test/Modulation																																																																					
Description	<p>Configuration of the DVB-S2 FEC-rate and modulation parameters on the test generator when MoTgFrameFormat is set to baseband frames.</p> <p>The selection of the FEC-rate and modulation are coupled and depend on the present modulation standard and capability of the device.</p> <p>Because the selection of a new FEC-rate and/or modulation type changes the symbol rate and thus the bandwidth of the signal, transmit is disabled. After verification of the occupied bandwidth the operator has to re-enable transmit to go back on air. Remark: Only those selections possible with the current device capability will be listed.</p>																																																																					
RMCP Command	tMx		Access																																																																			
	<i>Table</i>		ntcDevsMod01ModulatorEntry																																																																			
	<i>Command</i>		ntcDevsMod01MoTgFecMod2																																																																			
Values	<i>OID</i>		1.3.6.1.4.1.5835.3.1.3.1.107.1.1																																																																			
	<i>Factory Default</i>		<i>Enumeration</i>																																																																			
	qPSKModulationRate34		<table> <tbody> <tr><td>Dummy PLFRAMES</td><td>0</td></tr> <tr><td>QPSK no FEC (SKYPLEX)</td><td>10</td></tr> <tr><td>QPSK-1/2</td><td>11</td></tr> <tr><td>QPSK-2/3</td><td>12</td></tr> <tr><td>QPSK-3/4</td><td>13</td></tr> <tr><td>QPSK-5/6</td><td>15</td></tr> <tr><td>QPSK-6/7</td><td>16</td></tr> <tr><td>QPSK-7/8</td><td>17</td></tr> <tr><td>QPSK-1/4</td><td>21</td></tr> <tr><td>QPSK-1/3</td><td>22</td></tr> <tr><td>QPSK-2/5</td><td>23</td></tr> <tr><td>QPSK-3/5</td><td>24</td></tr> <tr><td>QPSK-4/5</td><td>25</td></tr> <tr><td>QPSK-8/9</td><td>26</td></tr> <tr><td>QPSK-9/10</td><td>27</td></tr> <tr><td>16APSK-2/3</td><td>42</td></tr> <tr><td>16APSK-3/4</td><td>43</td></tr> <tr><td>16APSK-4/5</td><td>44</td></tr> <tr><td>16APSK-5/6</td><td>45</td></tr> <tr><td>16APSK-8/9</td><td>48</td></tr> <tr><td>16APSK-9/10</td><td>49</td></tr> <tr><td>32APSK-3/4</td><td>53</td></tr> <tr><td>32APSK-4/5</td><td>54</td></tr> <tr><td>32APSK-5/6</td><td>55</td></tr> <tr><td>32APSK-8/9</td><td>58</td></tr> <tr><td>32APSK-9/10</td><td>59</td></tr> <tr><td>16QAM-3/4</td><td>63</td></tr> <tr><td>16QAM-7/8</td><td>67</td></tr> <tr><td>8PSK-3/5</td><td>81</td></tr> <tr><td>8PSK-2/3</td><td>82</td></tr> <tr><td>8PSK-3/4</td><td>83</td></tr> <tr><td>8PSK-5/6</td><td>85</td></tr> <tr><td>8PSK-8/9</td><td>88</td></tr> <tr><td>8PSK-9/10</td><td>89</td></tr> </tbody> </table>	Dummy PLFRAMES	0	QPSK no FEC (SKYPLEX)	10	QPSK-1/2	11	QPSK-2/3	12	QPSK-3/4	13	QPSK-5/6	15	QPSK-6/7	16	QPSK-7/8	17	QPSK-1/4	21	QPSK-1/3	22	QPSK-2/5	23	QPSK-3/5	24	QPSK-4/5	25	QPSK-8/9	26	QPSK-9/10	27	16APSK-2/3	42	16APSK-3/4	43	16APSK-4/5	44	16APSK-5/6	45	16APSK-8/9	48	16APSK-9/10	49	32APSK-3/4	53	32APSK-4/5	54	32APSK-5/6	55	32APSK-8/9	58	32APSK-9/10	59	16QAM-3/4	63	16QAM-7/8	67	8PSK-3/5	81	8PSK-2/3	82	8PSK-3/4	83	8PSK-5/6	85	8PSK-8/9	88	8PSK-9/10
Dummy PLFRAMES	0																																																																					
QPSK no FEC (SKYPLEX)	10																																																																					
QPSK-1/2	11																																																																					
QPSK-2/3	12																																																																					
QPSK-3/4	13																																																																					
QPSK-5/6	15																																																																					
QPSK-6/7	16																																																																					
QPSK-7/8	17																																																																					
QPSK-1/4	21																																																																					
QPSK-1/3	22																																																																					
QPSK-2/5	23																																																																					
QPSK-3/5	24																																																																					
QPSK-4/5	25																																																																					
QPSK-8/9	26																																																																					
QPSK-9/10	27																																																																					
16APSK-2/3	42																																																																					
16APSK-3/4	43																																																																					
16APSK-4/5	44																																																																					
16APSK-5/6	45																																																																					
16APSK-8/9	48																																																																					
16APSK-9/10	49																																																																					
32APSK-3/4	53																																																																					
32APSK-4/5	54																																																																					
32APSK-5/6	55																																																																					
32APSK-8/9	58																																																																					
32APSK-9/10	59																																																																					
16QAM-3/4	63																																																																					
16QAM-7/8	67																																																																					
8PSK-3/5	81																																																																					
8PSK-2/3	82																																																																					
8PSK-3/4	83																																																																					
8PSK-5/6	85																																																																					
8PSK-8/9	88																																																																					
8PSK-9/10	89																																																																					

Command MoTgPilots		Testgen Pilot insertion	Testgen Pilots
Location	/Modem/Test/Modulation		
Description	<p>Configuration command that enables or disables the physical layer pilot insertion for the test generator.</p> <p>When enabled, every 16 slots (of 90 symbols) the modulator will insert 36 non-modulated symbols to aid in receiver synchronisation.</p> <ul style="list-style-type: none"> • Off: Pilot insertion disabled. • On: Pilot insertion enabled. 		
RMC Command	TCP	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoTgPilots	
	OID	1.3.6.1.4.1.5835.3.1.3.1.109.1.1	
Values	Factory Default	Enumeration	Value
	off	Off On	0 1

Command MoDlyMode		Modulator delay mode	Modulator delay mode
Location	/Modem/Test/Modulation		
	Only valid for DVB-S2 modes.		
Description	<p>Configuration of the modulator delay mode. When the modulator is operating with external transmit clock, the transmit clock is slaved to the incoming data frames via a PLL circuit. This command selects the operating point (set-point) of the PLL :</p> <ul style="list-style-type: none"> • Minimum: The PLL tracks the input signal with minimum delay through the modulator. • Programmed: The PLL tracks the input signal to a programmed delay set-point. The set-point itself is programmable via one of the commands MoBufSetup (expressed in % of the input buffer) and MoBufFramSetup (expressed in frames). • Automatic: The system will determine the optimal settings. Remark: For low baudrate operation (lower than 100K), the programmed delay mode can result in very long settling times for the target delay. 		
RMC Command	Mdm	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoDlyMode	
	OID	1.3.6.1.4.1.5835.3.1.3.1.66.1.1	
Values	Factory Default	Enumeration	Value
	automatic	Minimum Programmed Automatic	0 1 2

Command MoBufSetup		Buffer setpoint		Buffer setpoint		
Location	/Modem/Test/Modulation					
	Only valid for DVB-S2 modes.					
Description	Configuration of the input FIFO buffer set-point for the clock loop when transmit clock is configured for external operation. External operation means that the clock is slaved to the input signal. The buffer content set-point is expressed in % of the physical buffer size.					
RMC Command	Bsp	Access		Normal user : no access Expert user : RW		
SNMP	Table	ntcDevsMod01ModulatorEntry				
	Command	ntcDevsMod01MoBufSetup				
	OID	1.3.6.1.4.1.5835.3.1.3.1.60.1.1				
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	%	%	50	0 .. 100		

Command MoBufFramSetup		Buffer setpoint		Buffer setpoint		
Location	/Modem/Test/Modulation					
	Only valid for DVB-S2 modes.					
Description	Configuration of the input FIFO buffer set-point for the clock loop when the transmit clock is configured for external operation. External operation means that the clock is slaved to the input signal. The buffer delay set-point is expressed in frame size units. The frame size for the data in the buffer depends on the selected input format, the frame type and data field length: <ul style="list-style-type: none">• If input format = DVB-S2 baseband frames:a) Short frame type: Frame size = 16200 bits or 2025 bytes.b) Normal frame type: Frame size = 64800 bits or 8100 bytes.• Other input formats (TS, GS): The frame size = data field length bits.The set-point equals the nominal number of frames (with size as described above) that will be stored in the FIFO input buffer when the transmit clock is operating in slaved mode (PLL).Remark: The associated MoBufSetup variable indicates the corresponding percentage of buffer contents.					
RMC Command	mfs	Access		Normal user : no access Expert user : RW		
SNMP	Table	ntcDevsMod01ModulatorEntry				
	Command	ntcDevsMod01MoBufFramSetup				
	OID	1.3.6.1.4.1.5835.3.1.3.1.59.1.1				
Values	GUI Unit	Cmd Unit	Factory Default (CU)	Expert Range (CU)		
	frames	frames	1	0 .. 1000		

Command MoBbNcoMode		Baseband NCO programming mode	BB NCO mode
Location	/Modem/Test/Modulation		
Description	<p>Configuration of the baseband network clock oscillator programming mode. The test generator on the modulator board is clocked by an independent baseband network clock oscillator. The output rate of this network clock oscillator is directly programmable via this command. Although total independent programming of the rate is required for factory testing, from a standard operator viewpoint it is more desirable that the test generator baseband network clock oscillator rate is automatically programmed to a value that is compatible to other modulator settings.</p> <p>This mode command selects the desired behaviour:</p> <ul style="list-style-type: none"> • Automatic: Upon selection of frame type, modcod, symbol rate and test generator timing mode, the baseband network clock oscillator is automatically programmed to a compatible value for proper operation. Remark: In case that MoTgTimMode is set to free running mode, the network clock oscillator is programmed to the calculated interface rate. In case that MoTgTimMode is set to throttled mode, the network clock oscillator is running at the maximum rate. • Manual: In this mode, the baseband network clock oscillator rate is only affected by the MoBbNcoRate command and it is the responsibility of the operator to select a compatible value. 		
RMCP Command	BNM	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoBbNcoMode	
	OID	1.3.6.1.4.1.5835.3.1.3.1.85.1.1	
Values	Factory Default	Enumeration	Value
	auto	Auto Man	0 1

Command MoBbNcoRate		Testgenerator output bitrate	Testgen output rate
Location	/Modem/Test/Modulation		
	Only valid for DVB-S2 modes.		
Description	<p>Configuration of the test generator output bitrate when the input clock selection is set to internal. The internal test generator clock is generated by a 32-bit network clock oscillator clocked at the 120 MHz master clock.</p> <p>Remark: When the input clock selection is set to external, the test generator is clocked with the interface clock.</p>		
RMCP Command	tgr	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoBbNcoRate	
	OID	1.3.6.1.4.1.5835.3.1.3.1.58.1.1	
Values	GUI Unit	Cmd Unit	Factory Default (CU)
	Mbps	bps	100

Command MoTgTimMode		Testgenerator output timing mode	Testgen timing mode
Location	/Modem/Test/Modulation		
	Only valid for DVB-S2 modes.		
Description	Configuration of the output timing mode on the test generator. The internal test generator can operate in two timing modes: <ul style="list-style-type: none"> • Free running: The output rate is solely controlled by the programmed test generator bitrate. • Throttled: The output rate is also throttled using data request pulses from the modulator. 		
RMCP Command	tTm	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01ModulatorEntry	
	Command	ntcDevsMod01MoTgTimMode	
	OID	1.3.6.1.4.1.5835.3.1.3.1.84.1.1	
Values	Factory Default	Enumeration	Value
	free_running	Free running Throttled	0 1

/Modem/Test/Demodulation

Command SyTestRst		Test Reset	Test Reset
Location	/Modem/Test/Demodulation		
Description	This command can initiate different reset functions, but this command is ONLY used for test purposes.		
RMCP Command	STR array : [1 .. 2]	Access	Normal user : no access Expert user : W
SNMP	Table	ntcDevsMod01SystemEntry	
	Command	ntcDevsMod01SyTestRst	
	OID	1.3.6.1.4.1.5835.3.1.1.1.78.1.1.[1 .. 2]	
Values	Factory Default	Enumeration	Value
		DemodReset InitForAcq TunerInit GlobalReConfig FpgaReset	1 2 3 4 5

Command DmEquCtrl		Adaptive equalising filter	Adaptive equalising
Location	/Modem/Test/Demodulation		
Description	Configuration of the adaptive equalising filter on the demodulator. The different settings are: <ul style="list-style-type: none">• On: The equaliser is enabled.• Off: The equaliser is disabled.		
RMCP Command	EQc	Access	Normal user : no access Expert user : RW
SNMP	Table	ntcDevsMod01DemodulatorEntry	
	Command	ntcDevsMod01DmEquCtrl	
	OID	1.3.6.1.4.1.5835.3.1.13.1.64.1.1	
Values	Factory Default	Enumeration	Value
	on	Off On	0 1

6 ALARMS

Alarm Types

- **Active alarm:** alarm that is present at the time when you read the alarm.
- **Memorised alarm:** alarm that has happened in the past but has been resolved before you read the alarm (in case of intermittent alarms or a setting that has been corrected since). The purpose of this type of alarm is to warn you that there has been an alarm in the past but that the alarm condition is currently not present.
- **Alarm counter:** the number of times an alarm occurred. This counter can record up to a maximum of 255 events.

Alarm Commands

Special Command AIAlarmsCur		Current alarm status string	Alarm status string
Location	/Config		
Description	Readout of the concatenated string of all individual alarm status replies of the device. A get request returns the current alarm buffer contents. The buffer is not reset. A set command returns the current alarm buffer contents and resets the buffer.		
RMCP Command	CAs	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01AlarmEntry	
	Command	ntcDevsMod01AIAlarmsCur	
	OID	1.3.6.1.4.1.5835.3.1.2.1.9.0.1	
Get Command Arguments		Set Command Arguments	
Command(s) / Variable(s)		Command(s) / Variable(s)	Page
none		none	none
Get Reply Values		Set Reply Values	
Command(s) / Variable(s)		Command(s) / Variable(s)	Page
AIAlarmString		AIAlarmString	231

Special Command AIAlarmsMem		Memorised alarm string	Mem. al. string
Location	/Config		
Description	Readout of the concatenated string describing the state of all individual memorised alarm counters. <ul style="list-style-type: none"> • 0: Indicates that the respective counter did not count any alarm events since last reset. • 1: Indicates that the respective counter did count alarm events since last reset. A get request returns the memorised alarm counter status. The counters are not reset. A set command returns the memorised alarm counter status and resets the counters. Remark: The number of events can be retrieved with the individual counter reading command AIAlarmMem. 		
RMCP Command	MAs	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01AlarmEntry	
	Command	ntcDevsMod01AIAlarmsMem	
	OID	1.3.6.1.4.1.5835.3.1.2.1.10.0.1	
Get Command Arguments		Set Command Arguments	
Command(s) / Variable(s)	Page	Command(s) / Variable(s)	Page
none	none	none	none
Get Reply Values		Set Reply Values	
Command(s) / Variable(s)	Page	Command(s) / Variable(s)	Page
AIAlarmString	231	AIAlarmString	231

Special Command AIAlarmsMode		Alarm mode string	Alarm mode string
Location	/Config		
Description	Configuration of the current alarm modes for all device alarms. The alarm mode provides more detailed information about the current alarm status. It indicates if the alarm is operational, masked by the operator or suppressed by system state, priority or capability limitations. The command returns the concatenated string of all individual alarm mode replies. The different options are : <ul style="list-style-type: none"> • Normal : Selects "normal" operational behaviour. • Masked : A masked alarm is continuously kept in the no alarm (0) status. • Forced : A forced alarm is continuously kept in the alarm (1) status. The command argument consists of the concatenated string of all individual control action words hence allowing individual control of all alarms with this single command. The command always replies with the concatenated string consisting of all individual current control status words. Remark: The current and memorised alarms are immediately cleared when an alarm is masked by the user. 		
RMCP Command	CAm	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01AlarmEntry	
	Command	ntcDevsMod01AIAlarmsMode	

Special Command AIAAlarmsMode		Alarm mode string	Alarm mode string
	OID	1.3.6.1.4.1.5835.3.1.2.1.11.0.1	
Get Command Arguments			Set Command Arguments
Command(s) / Variable(s)	Page	Command(s) / Variable(s)	Page
none	none	AIAAlarmString	231
Get Reply Values			Set Reply Values
Command(s) / Variable(s)	Page	Command(s) / Variable(s)	Page
AIAAlarmString	231	AIAAlarmString	231

Special Command AIAAlarmCur		Current alarm status	Current alarm status
Location	/Config		
Description	Readout of the current alarm status for the specified alarm from the alarm buffer. <ul style="list-style-type: none"> • 0 = Currently, no alarm is present. • 1 = Currently, the alarm is active. A get request returns the current alarm buffer contents without resetting the buffer. A set command returns the current alarm buffer contents and resets the buffer. 		
RMC Command	Cas	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01AlarmEntry	
	Command	ntcDevsMod01AIAAlarmCur	
	OID	1.3.6.1.4.1.5835.3.1.2.1.4.0.1	
Get Command Arguments		Set Command Arguments	
Command(s) / Variable(s)	Page	Command(s) / Variable(s)	Page
AIAAlarmId	232	AIAAlarmId	232
Get Reply Values			Set Reply Values
Command(s) / Variable(s)	Page	Command(s) / Variable(s)	Page
AIAAlarmStatus	233	AIAAlarmStatus	233

Special Command AIAAlarmMem		Memorised alarm counter	Alarm counter
Location	/Config		
Description	Readout of the memorised alarm counter for the specified alarm. <ul style="list-style-type: none"> • 0 = No alarm events occurred since last alarm reset. • n = n alarm events occurred since last alarm reset with n an integer number. A get request returns the memorised alarm counter contents, the counter is not reset. A set command returns the memorised alarm counter contents and resets the counter. 		
RMC Command	Mas	Access	Normal user : RW Expert user : RW
SNMP	Table	ntcDevsMod01AlarmEntry	
	Command	ntcDevsMod01AIAAlarmMem	
	OID	1.3.6.1.4.1.5835.3.1.2.1.6.0.1	

Special Command AIAlarmMem	Memorised alarm counter		Alarm counter
Get Command Arguments		Set Command Arguments	
Command(s) / Variable(s)	Page	Command(s) / Variable(s)	Page
AIAlarmId		AIAlarmId	
<i>Get Reply Values</i>		<i>Set Reply Values</i>	
Command(s) / Variable(s)	Page	Command(s) / Variable(s)	Page
AIAlarmCounter	233	AIAlarmCounter	233

Alarm Front Panel Operation

The alarm menu is built dynamically. Only alarms that are present (both actual and memorised) are indicated.

Example:

- Click **CLR** to clear all memorised alarms and to obtain a list of the actual alarms only.
- 1. Memorised alarm

EL470/Alarm
Buffer overflow: Mem. Alarm Cnt.: 3

If the monitored parameters have had an alarm state and this state has been resolved at the time you read the alarm, the display indicates a memorised alarm and the number of times the alarm has occurred since the last reset.

- Click **CLR** to clear this counter.
- 2. Active alarm

EL470/Alarm

If the monitored parameters have had an alarm state at the time you read the alarm, the display indicates an actual alarm and indicates the number of times the alarm has occurred since the last reset.

- 3. Alarm modes

In expert mode all the available alarms are displayed. When neither an active nor a memorised alarm is present it shows the alarm status OK.

EL470/Alarm
Device temperature: OK

- Click **OK** when an alarm type is displayed. This allows you to change the alarm mode from normal to masked or forced.

- **Masked alarm:** Under specific circumstances you are allowed to mask alarms. However, be careful because the alarm will be ignored when it occurs and all subsequent actions (like disabling of RF transmit) will not be taken. This could be dangerous. Therefore you should only consider to mask alarms after you have consulted Newtec technical support. You can only mask alarms in expert mode. When you return to the normal device operating mode the alarms remain masked.
- **Forced alarm:** while performing test and installation procedures it might be useful to simulate an alarm, e.g. by triggering a simulated redundancy switch over. You can only force an alarm in expert mode. As soon as you return to the normal device operating mode, the forced alarms are reset to normal. The alarm relay contacts – more thoroughly explained in the User Manual – only close when a general device alarm and the interface alarm occur. When you force, for example, the external 10 MHz reference alarm, only this alarm is raised and not the general device alarm. To test the redundancy switching systems, force either the general device alarm or the interface alarm.
- Alarm times

The start and stop time of an alarm are logged.

- Press "?" to show these times. When the alarm is not present (memorised or active) the time indication is empty. When an alarm is present and active the start time is displayed and the stop time mentions "still active". When an alarm is memorised, both the start and stop time are displayed.

Start: Tue Dec 9 10:11:53

Stop: still active

Alarm List

EL470 >> Alarm

The following list contains all possible alarms.

Alarm Label	Name	Description
Device has been reset	AIResFlag	Reports that the main-controller has had a reset. This can indicate that all the parameters in the device are changed.
Self test	AIselfTest	After power-on or reset, the device performs an internal self test. If this self test fails it will trigger this alarm.
Incompatibility	AllIncompat	The device asserts the incompatibility alarm if a new control setting was attempted that would result in a conflict with one or more of the other present settings. The new control setting is accepted but not activated (the device remains operational in the last state). By changing one or more of the conflicting parameters, the incompatibility condition can be removed. Only when this occurs, the new "compatible" state is activated and the incompatibility alarm is de-asserted. Under RMCP, details on the type of incompatibility that occurred can be obtained using the "Incompatibility Identification" command.
General device	AIgenDev	An alarm is indicated if at least one of the alarms is active (logical-OR of the alarm indications).
Interface	AllInterface	The interface alarm is a combined alarm indicating a missing or invalid input signal at the selected interface. (this alarm does not include further signal processing related alarms).
Reference clock	AIRefClock	Selected 10 MHz reference clock absent or level too low.
Device temperature	AIDevTemp	A device temperature alarm indicates that the device internal temperature exceeds the +10° C and +70° C limits.
Power supply voltage	AIPowSup	Summarises the four power supply alarms, an alarm is

Alarm Label	Name	Description
		generated if at least one of the monitored power supply voltages is out of range.
Ethernet IfA Link	AllIfaLink	This interface alarm is triggered on a missing or invalid input signal (Link Down) at the ethernet interface A. (this alarm does not include further signal processing related alarms).
Ethernet IfB Link	AllIfbLink	This interface alarm is triggered on a missing or invalid input signal (Link Down) at the ethernet interface B. (this alarm does not include further signal processing related alarms).
IP gateway unreachable	AllIfGwUnreachable	This interface alarm is triggered when at least one of the configured IP gateways in the traffic path is unreachable.
Ethernet interface switchover	AIEthSwo	This alarm indicates that an Ethernet interface switchover has happened, with Ethernet interface redundancy enabled.
Demod RX Decoder Bad Packet	AllIfRxBadPacket	The decoder on the interface card has received unrecognizable packets from its baseband interface, which is usually attached to a demodulator. Plausible cause : user configures reception of a specific datastream, but the real data has not been encoded with the expected (or unrecognizable) protocol.
Demod Rx Buffer Overflow	AllIfBBRXOverflow	The frames were dropped at the baseband interface.
Baseband frame sync	AIMoBbSync	A Baseband framing sync alarm indicates loss of synchronisation between the baseband framing and the input signal.
Clock PLL	AIMoClkPll	The clock PLL alarm is generated when the transmit clock is not synchronised to the interface clock, if the device operates with external transmit clock. The alarm is asserted when the buffer contents exits the centre zone [40% - 60%]. For the lower bitrates, the nominal buffer set-point(=contents) is reduced in order to minimize overall delay. Therefore the lower limit for the PLL alarm is reduced as well : 1 Mbps <= interface rate : [40% - 60%] nominal 50% 200 Kbps <= interface rate < 1 Mbps : [10% - 60%] nominal

Alarm Label	Name	Description
		25% 50 Kbps <= interface rate < 200 Kbps : [5% - 60%] nominal 12.5% This alarm is not applicable if the internal transmit clock (free running) is selected.
Synthesiser	AlMoSynth	The synthesiser alarm indicates a malfunction of the hardware which generates the carrier frequency. The presence of this alarm suppresses transmit of the L-band/Rf output (internal L-band).
Demod lock	AIReceiverOk	This alarm is asserted when the receiver is not synchronised.
Demod Tuner Lock	AIDrvTunerLock	Alarm indicates whether the Tuner Synthesizer is phase locked.
Demod Physical layer sync	AIDrvPISync	Alarm indicates Loss of Physical Layer frame synchronisation.
Demod Baseband frame sync	AIDrvBbSync	A Baseband framing sync alarm indicates loss of synchronisation between the baseband framing and physical layer framing.
Internal M&C module	AIMcModule	Indicates an alarm internal to the M&C board. For detailed information the alarms of the M&C module should be consulted.
Internal interface module	AllIntfModule	Indicates an alarm internal to the interface function/module. For detailed information the alarms of the interface module should be consulted.
Internal modulator	AIModModule	Indicates an alarm internal to the modulator board.
Demodulator module	AIDrvModule	Indicates an alarm internal to the demodulator board. For detailed information the alarms of the M&C module should be consulted.
Device architecture	AIArchitecture	The architecture alarm indicates that the detected device architecture (modules/interconnect) does not match the expected architecture.
Internal communication	AllIntComm	An internal communication alarm indicates that there is a communication error between different boards in the system.
Input alarm	AllInput	The input alarm is a combined alarm indicating a missing or invalid input signal to the device.

APPENDIX A: ACTION KEYS

The idea behind Action Keys is that you as system integrator can define a group of frequently executed operations to configure the device. Use the numerical keypad as a selection panel. When you press a certain number, a string appears that clearly describes the commands that will be executed. You can then press **OK** to execute the command(s).

Contrary to loading complete device configurations by using the load and save configurations option, you can define group of commands (1-20) that have to be executed when you execute a specific Action Key.



The action keys are not displayed in the tree view of the Graphical user interface (GUI). This function is in the Function controls window of the GUI under the tab Macro.

We refer to the explanation of the GUI in the user manual of this device.

Definition of the Action Keys

EL470>> Actionkeys

Special Command SyActKeyActivate		Action keys			
Location	Modulator/Actionkeys				
Description	This command represents a key-press when in the ActionKey menu. An expert user can program the actions taken when such a key is pressed.				
RMCP Command	AKa filesdraf	Access	Normal user : W Expert user : W		
SNMP	Table	ntcDevsMod01SystemEntry			
	Command	ntcDevsMod01SyActKeyActivate			
	OID	1.3.6.1.4.1.5835.3.1.1.1.47.1.1			
Get Command Arguments		Set Command Arguments			
Command(s) / Variable(s)		Command(s) / Variable(s)	Page		
NA		SyActionKeyId	229		
Get Reply Values		Set Reply Values			
Command(s) / Variable(s)		Command(s) / Variable(s)	Page		
NA		SyActionKeyReply	229		

Parameter	Define	
Description	<p>With this command you can set which key on the keyboard executes a certain sequence of commands. When you navigate to the Actionkey menu, press 0-9 to display the user-defined Actionkey name. Click OK to execute the RMCP command(s) that are associated with this Actionkey.</p> <p>Examples:</p> <ul style="list-style-type: none"> • AKd!0,BBC1,OOF!140000000;TTm!1 Displays the string "BBC1" when you press 0 and sets the output frequency of 140 MHz and enables L-band transmit when you click OK. • AKd!1,Reduced CW,TLa!1;TMm!0 Displays the string "Reduced CW" when you press 1 and reduces the current output with 15 dB and selects pure carrier modulation when you click OK. 	
RMCP	AKd ActionKey Number, Label, Command 1;Command 2; ... Command n	
SNMP	Table	ntcDevsMod01SystemEntry
	Command	ntcDevsMod01SyActKeyDef
	OID	.1.3.6.1.4.1.5835.3.1.1.1.48.1.1
Values	<ul style="list-style-type: none"> • ActionKey Number: identifies a key on the numerical keypad of the front panel. • Label: can be any text that should appear on the display to describe the set of commands behind the Actionkey (maximum length 20 characters, only the semicolon ";" character cannot be used). • Commands: This string is used to define the commands of an ActionKey, it has the following format: CMD1; CMD2... CMDn; CMD# is a complete RMCP command. 	

Example

To download the RMCP Loader, go to www.newtec.eu and choose **Support > FAQ > What is RMCP loader and How to get it > RMCP LOADER download now..** Click **Grouped Commands** to send the following commands in a .txt file to the IP Satellite Modem.

- AKd!0,Pure carrier;TMm!0
- AKd!5,Modulated;TMm!1
- AKd!1,Reduced;TLa!1
- AKd!6,Nominal;TLa!0
- AKd!2,Low rate QPSK3/4;TRr!8448000;TMx!13
- AKd!7,High rate 8PSK 5/6;TRr!21503000;TMx!85
- AKd!3,IF transmit off;TTm!0
- AKd!8,IF transmit on;TTm!1

When entering the Action Keys menu, press **2** to display:

Action keys: <0-9> or <OK> to execute
2: Low rate QPSK ¾

When you press **OK** the interface rate is set to 8.448 Mbit/s (TRr!8448000) and QPSK modulation with FEC 3/4 is selected (TMx!13).



After a reset to factory defaults the Action Keys are all reset to off (default value).

Action Key definition via the Web interface:

- Navigate to the Action Key menu.
- Click **Define** to enter the label of the Action Key and the associated RMCP commands that need to be executed by this macro. To find the RMCP command that is used to set or get a parameter, refer to the manual.
- Click **Manual** in the top-navigation bar or select the parameter name in a parameter entry page to open the manual at the position where that parameter is described, including the RMCP commands.



Request a RMCP manual via the Newtec Service Desk tool:

- > Browse to <http://customersupport.newtec.eu>
 - > Fill in your Username and Password
 - > Create a ticket
- As response of your request you will receive the manual from our support team.
In case you don't have a Username and Password yet for the Newtec Service Desk tool request a login to techsupport@newtec.eu

Once you have defined the Action Keys, click **Execute** to execute the macro. You can only define or change Action Keys when you are logged in as Administrator. In other modes you can only view the definition, not change it.

APPENDIX B: TROUBLESHOOTING

Consult the Reference Manual

When an alarm occurs, an alarm message appears on the display of your device and in the alarm menu on your device. You can retrieve information on the alarm in the alarm list in this manual. In most cases you will find a short description about what caused the alarm and what you can do to solve this problem.

Contact support

Do not hesitate to contact our support engineers if you need help. Our "follow-the-sun" policy ensures that you can get help at any time. Generate a diagnostics support to enable our support engineers to help you.

Generate a Diagnostics report

- In the GUI, click **Diagnostics report**.
- Click **Generate Basic Diagnostics Report**.
After a few seconds the diagnostics file appears in html format.
- Send the diagnostics report.

Attach a diagnostics report via the Newtec Service Desk tool:

- > Browse to <http://customersupport.newtec.eu>
- > Fill in your Username and Password
- > Create a ticket
- > Attach your diagnostics report to your service request in the service desk tool via the brows button at the bottom of your service request

 [Attachments](#)

As response of your request you will receive the manual from our support team.

In case you don't have a Username and Password yet for the Newtec Service Desk tool request a login to techsupport@newtec.eu

Support case logging

At Newtec Cy N.V. we use a case tracking database to log and track all our support cases. Each case has a unique identifier that can be used to quickly refer to that case. Automatic escalation assures that every case receives the attention it requires.

Appendix C: ABBREVIATIONS

Acronym	Definition
ACF	AutoCorrelation Function
ACM	Adaptive Coding Modulation
AGC	Automatic Gain Control
APSK	Amplitude and Phase Shift Keying
ARP	Address Resolution Protocol (TCP/IP)
ASCII	American Standard Code for Information Interchange
ASI	Asynchronous Serial Interface
BB	Base Band
BBF	Base Band Frame
BER	Bit Error Rate/Ratio
BISS	Basic Interoperable Scrambling System
BPSK	Binary Phase Shift Keying
C/N	Carrier to Noise Ratio
CBR	Constant Bit Rate
CCITT	Comité Consultatif International Télégraphique et Téléphonique (known today as the ITU-T)
CCM	Constant Coding and Modulation
CMD1	Command 1
CPU	Central Processing Unit
CRC	Cyclic Redundancy Check
CW	Continuous Wave (Radio signal without modulation)
DC	Direct Current
DFL	Data Field Length
DFM	Digital Frequency Meter
DRO	Dielectric Resonator Oscillator
DSNG	Digital Satellite News Gathering
DVB	Digital Video Broadcasting

Acronym	Definition
DVB-S	Digital Video Broadcasting-Satellite
FAQ	Frequently Asked Question
FEC	Forward Error Correction (in data transmission systems)
FIFO	First in First Out
FPGA	Field Programmable Gate Array
FTP	File Transfer Protocol (computer networks & systems)
GBE	Gigabit Ethernet
GSE	Generic Stream Encapsulation
GPS	Global Positioning System
GTS	Global Telecommunications Society
GUI	Graphical User Interface
HPA	High Power Amplifier (used in SNG terminals)
HSSI	High Speed Serial Interface
HW	Hardware
ID	Identifier
IF	Intermediate Frequency
IFL	Inter Facility Link
IP	Internet Protocol
IRS	Information Receiving Station
ISI	Input Stream Identifier
L3	Level 3
LAN	Local Area Network
LCD	Liquid Crystal Display
LED	Light Emitting Diode
LNB	Low noise block down converter
LO	Local Oscillator
LOF	Local Oscillator Frequency
LVDS	Low Voltage Digital Signalling
M&C	Monitoring and Control
MAC	Medium Access Control

Acronym	Definition
MGC	Manual Gain Control
MIN	Mobile Identification Number
MPE	Multi Protocol Encapsulation Maximum Permissible Exposure (EMR or RF level)
MPEG	Motion Picture Experts Group
NCO	Network Clock Oscillator
NCR	(DVB-RCS) Network Clock Reference
NTC	Newtec Company
ODU	Outdoor Unit
OEM	Original Equipment Manufacturer
OID	Object Identifier
PC	Personal Computer
PCR	Program Clock Reference
PHY	Physical Layer
PID	Packet Identifier
PLL	Phase Locked Loop
PLS	Physical Layer Scrambler
PRBS	Pseudo Random Binary Sequence
PSK	Phase Shift Keying
QAM	Quadrature Amplitude Modulation
QEF	Quasi Error Free
QOS	Quality Of Service
QPSK	Quadrature Phase Shift Keying
RAM	Random Access Memory (in computer systems)
RCS	Return Channel by Satellite
RF	Radio Frequency
RMCP	Remote Monitor and Control Protocol
RS	Reed Solomon
RTP	Real-time Transmission Protocol
RX	Receive

Acronym	Definition
S2BBF	S2 Base Band Frame
SCA	Subsidiary Communications Authority
SIT	Satellite Interactive Terminal
SNMP	Simple Network Management Protocol
SW	Software
TCO	Tx Clock Offset
TCP	Transmission Control Protocol
TS	Transport Stream
TX	Transmit
UDP	User Datagram Protocol
VBR	Variable Bit Rate
VCM	Variable Coding and Modulation
VLAN	Virtual Local Area Network
VRRP	Virtual Router Redundancy Protocol
WI	Web Interface

APPENDIX D: LIST OF COMMANDS

List of Commands			
AESEraseAllKey.....	30	DmAESKeyParityISI.....	112
AESGroupKey.....	29	DmAESOddGlobalKey.....	111
AESKeyLength.....	30	DmAESOddKeyISI.....	114
AIAlarmCounter.....	232	DmAftDecBER.....	102
AIAlarmCur.....	247	DmBuEnable.....	107
AIAlarmId.....	231	DmBuRxRfFreq.....	106
AIAlarmMem.....	247	DmBuSwitchCnt.....	107
AIAlarmsCur.....	245	DmBuSwitchTimeout.....	107
AIAlarmsMem.....	246	DmBuSynRate.....	106
AIAlarmsMode.....	246	DmDecapModcodStatGSE.....	141
AIAlarmStatus.....	232	DmEquCtrl.....	244
AIAlarmString.....	230	DmEstLinMar.....	189
AISelfPermissionBrd.....	43	DmEstLinMarSat.....	189
AISelfPermissionString.....	192	DmEstLinMarStruct.....	159
BecBec.....	6	DmExcBW.....	105
BecStatus.....	6	DmExcBWStat.....	102
BuDecOwnIpaddrA.....	63	DmExtLOFreq.....	27
BuDecOwnIpaddrB.....	63	DmExtLOPolVal.....	27
BuDecOwnNetMaskA.....	63	DmFECDemod2.....	101
BuDecOwnNetMaskB.....	64	DmFECDemodStat.....	160
CvLNBPow.....	26	DmFrameType.....	103
CvRxRfFreq.....	99	DmFrameTypeStat.....	160
DmAcmClientEsnoVariation.....	162	DmInput.....	99
DmAcmClientFeedback.....	163	DmIntRate.....	100
DmAcmClientLog.....	163	DmISIControl.....	103
DmAcmClientLogToday.....	163	DmMeasAGC.....	173
DmAcmClientLogYesterday.....	164	DmMeasAGCCo.....	174
DmAcmClientPoll.....	162	DmMeasAGCCoSat.....	173
DmACMMode.....	98	DmMeasAGCCoStruct.....	156
DmAcqRan.....	100	DmMeasAGCSat.....	173
DmAEEEnableEncGlobal.....	109	DmMeasAGCStruct.....	156
DmAEEEnableEnclSI.....	111	DmMeasCarOff.....	157
DmAEEEncEvenGlobalKey.....	110	DmMeasClk.....	158
DmAEEEncEvenKeyISI.....	113	DmMeasClkPpm.....	158
DmAEEEncOddGlobalKey.....	110	DmMeasEbNo.....	167
DmAEEEncOddKeyISI.....	113	DmMeasEbNoSat.....	167
DmAEEEncryptionCtrl.....	108	DmMeasEbNoStruct.....	157
DmAEEEvenGlobalKey.....	111	DmMeasEsNo.....	188
DmAEEEvenKeyISI.....	114	DmMeasEsNoSat.....	188
DmAESKeyISI.....	112	DmMeasEsNoStruct.....	159
DmAESKeyParityGlob.....	109	DmModCodStatChCD.....	171

DmModCodStatChCDSat.....	171	IfBrifLocalGateway.....	191
DmModCodStatChDistQEF.....	172	IfBrifLocalIp.....	190
DmModCodStatChDistQEFSat.....	172	IfBrifLocalIpMask.....	191
DmModCodStatChQESt.....	171	IfBrifLocalVlan.....	190
DmModCodStatFrameCnt.....	169	IfBrifRemotelp.....	191
DmModCodStatFrameType.....	169	IfBrifRemotelpMask.....	192
DmModCodStatModCod.....	167	IfChConfigEthRx.....	58
DmModCodStatPilots.....	169	IfChConfigEthRxAirMac.....	177
DmModCodStatSat.....	170	IfChConfigEthRxEnable.....	174
DmModCodStatStruct.....	161	IfChConfigEthRxIp.....	175
DmModCodStatUncorCnt.....	170	IfChConfigEthRxIpMask.....	176
DmMPegCrcErrs.....	157	IfChConfigEthRxMac.....	175
DmPidFilteringControl.....	106	IfChConfigEthRxPackingDelay.....	177
DmPilots.....	102	IfChConfigEthRxPID.....	177
DmPLSSignature.....	104	IfChConfigEthRxStreamId.....	176
DmSpecInv.....	104	IfChConfigEthRxVlanId.....	175
DmSynRate.....	100	IfChConfigEthTx.....	58
ExtLOFreq.....	27	IfChConfigEthTxAirMac.....	179
ExtLOPolVal.....	28	IfChConfigEthTxEnable.....	178
GbeTestRst.....	234	IfChConfigEthTxISI.....	179
IfAcmFwSigFetched.....	143	IfChConfigEthTxMac.....	180
IfAcmFwSigRxed.....	143	IfChConfigEthTxPID.....	179
IfAcmRtSigFetched.....	144	IfChConfigEthTxVlanId.....	180
IfAcmRtSigRxed.....	144	IfComTxSig.....	236
IfBbbTxSig.....	235	IfDevMacAddrA.....	115
IfBBCntRst.....	121	IfDevMacAddrB.....	116
IfBBCounters.....	120	IfDPStats.....	138
IfBBRXBBFCounter.....	197	IfDPStatsReset.....	138
IfBBRXBBFCrcErr.....	198	IfDPStatsRXIdle.....	213
IfBBRXChannelDrop.....	124	IfDPStatsRXMpegPackets.....	212
IfBBRXCounter.....	197	IfDPStatsRXMtuBytes.....	212
IfBBRXDropCounter.....	198	IfDPStatsRXMtuPackets.....	212
IfBBRXEstimBitRate.....	123	IfDPStatsRXMtuRate.....	212
IfBBRXEstimFrameRate.....	123	IfDPStatsRXPopTimeouts.....	213
IfBBRXTSCrcErr.....	198	IfDPStatsRXPushTimeouts.....	213
IfBBTXBBFCounter.....	197	IfDPStatsTXIdle.....	211
IfBBTXCounter.....	197	IfDPStatsTXMpegPackets.....	211
IfBBTxDvbs2FillingLevel.....	123	IfDPStatsTXMtuBytes.....	210
IfBBTXEstimOutpRate.....	122	IfDPStatsTXMtuPackets.....	210
IfBbTxEthqCurFilling.....	198	IfDPStatsTXMtuRate.....	210
IfBbTxEthqMaxFilling.....	199	IfDPStatsTXPopTimeouts.....	211
IfBbTxEthqStats.....	121	IfDPStatsTXPushTimeouts.....	211
IfBBTXInfRate.....	122	IfDvbs2BboerxCurlpVolume.....	185
IfBBTXNPStuffingRate.....	122	IfDvbs2BboerxCurPaddingVolume.....	185
IfBridgeType.....	54	IfDvbs2BboerxCurStats.....	134
IfBrifEnable.....	189	IfDvbs2BboerxCurSymbolVolume.....	186
IfBrifEntry.....	57	IfDvbs2BboeRxEnable.....	233

IfDvbs2BboerxErrEncapDisabled.....	184	IfEthUnitRedunVridB.....	.52
IfDvbs2BboerxErrEncapId.....	184	IfEthUnitRedunVrrp.....	.51
IfDvbs2BboerxErrIpVol0.....	185	IfForcePromiscuous.....	.55
IfDvbs2BboerxErrors.....	133	IfGbeConfigError.....	.119
IfDvbs2BboerxErrSequence.....	184	IfGbePacketLog.....	.126
IfDvbs2BboerxFrames.....	183	IfGbePacketLogReason.....	.126
IfDvbs2BboeRxInstances.....	68	IfGbeSwErrCount.....	.120
IfDvbs2BboerxIntervalIpVolume.....	186	IfGbeSwError.....	.119
IfDvbs2BboerxIntervalPadVolume.....	187	IfGBSSettings.....	.59
IfDvbs2BboerxIntervalStats.....	134	IfGBSSettingsCRC.....	.182
IfDvbs2BboerxIntervalSymVolume.....	187	IfGBSSettingsDestMac.....	.181
IfDvbs2BboeRxMcastIpAddress.....	233	IfGBSSStats.....	.139
IfDvbs2BboeRxUdpPort.....	67	IfGBSSStatsReset.....	.139
IfDvbs2BboeTxIp.....	67, 69	IfGBSSStatsRXBBBytes.....	.216
IfDvbs2BboeTxUdpPort.....	68, 70	IfGBSSStatsRXBBFrames.....	.215
IfDvbs2BbRxAvgCodingCompr.....	132	IfGBSSStatsRXCRCErrors.....	.216
IfDvbs2BbRxAvgCodingComprWin.....	71	IfGBSSStatsRXDropped.....	.216
IfDvbs2BbRxBuffHeadroomMs.....	70	IfGBSSStatsRXEthBytes.....	.217
IfDvbs2BbRxEncapsTimetick.....	70	IfGBSSStatsRXEthPackets.....	.217
IfDvbs2BbRxUdpPort.....	69	IfGBSSStatsRXEthRate.....	.217
IfEnableL2routing.....	54	IfGBSSStatsRXPopTimeouts.....	.216
IfEnableModDemodSig.....	62	IfGBSSStatsRXPushTimeouts.....	.217
IfEnableQosClassif.....	60	IfGBSSStatsTXBBBytes.....	.215
IfEthAutoNegEn.....	46, 47	IfGBSSStatsTXBBFrames.....	.215
IfEthAutoNegRestart.....	46, 47	IfGBSSStatsTXEthBytes.....	.214
IfEthForceSpeed2.....	46, 48	IfGBSSStatsTXEthPackets.....	.214
IfEthIfRedunEnable.....	48	IfGBSSStatsTXPopTimeouts.....	.214
IfEthIfRedunFollowGw.....	50	IfGBSSStatsTXPushTimeouts.....	.215
IfEthInputConf.....	53	IfGSESettings.....	.60
IfEthMccastIf.....	64	IfGSESettingsDestMac.....	.182
IfEthMtu.....	45	IfGSEStats.....	.140
IfEthQosRuleClassif.....	195	IfGSEStatsReset.....	.140
IfEthQosRuleEnable.....	195	IfGSEStatsRXBBBytes.....	.220
IfEthQosRuleEntry.....	61	IfGSEStatsRXBBFrames.....	.220
IfEthQosRulePrio.....	196	IfGSEStatsRXCRCErrors.....	.220
IfEthRxFixedFilterProtocols.....	54	IfGSEStatsRXDropped.....	.220
IfEthStatsReset.....	118	IfGSEStatsRXEthBytes.....	.221
IfEthStatsRXCongDropped.....	117	IfGSEStatsRXEthPackets.....	.221
IfEthStatsRXNoMatch.....	117	IfGSEStatsRXEthRate.....	.221
IfEthStatsRXPackets.....	117	IfGSEStatsRXFragmented.....	.222
IfEthUnitRedunFollowGw.....	52	IfGSEStatsRXPopTimeouts.....	.220
IfEthUnitRedunState.....	50	IfGSEStatsTXBBBytes.....	.219
IfEthUnitRedunVmac.....	51	IfGSEStatsTXBBFrames.....	.219
IfEthUnitRedunVridA.....	51	IfGSEStatsTXEthBytes.....	.218
		IfGSEStatsTXEthPackets.....	.218

IfGSEStatsTXEthRate.....	218	IfPacketLogFilter.....	125
IfGSEStatsTxFragmented.....	219	IfPacketLogFiltPat.....	125
IfGSEStatsTXPopTimeouts.....	218	IfPromiscFlag.....	55
IfGSEStatsTXPushTimeouts.....	219	IfProxyARPIgnoredCount.....	118
IfIbSigTxed.....	144	IfProxyARPRespCount.....	118
IfItfaStatus.....	116	IfQosOnCpupload.....	61
IfItfbStatus.....	116	IfQosQueueEntry.....	61
IfMPEGoUDPRXSettingsFormat.....	65	IfQosQueueGuarPerFlow.....	194
IfMPEGoUDPRXSettingsIP.....	66	IfQosQueueMaxPerQos.....	195
IfMPEGoUDPRXSettingsProfile.....	66	IfQosQueuePriority.....	194
IfMPEGoUDPRXSettingsType.....	65	IfQosStatsBytesDropped.....	223
IfMPEGoUDPRXSettingsUDPPort.....	67	IfQosStatsEntry.....	143
IfMPEGoUDPStats.....	129	IfQosStatsPriority.....	223
IfMPEGoUDPStatsReset.....	129	IfQosStatsReset.....	142
IfMPEGoUDPStatsRXMpegPackets.....	200	IfRTPStatsRXDrop.....	131
IfMPEGoUDPStatsRXMtuBytes.....	199	IfRTPStatsRXMaxTSCount.....	132
IfMPEGoUDPStatsRXMtuDrop.....	200	IfRTPStatsRXResync.....	131
IfMPEGoUDPStatsRXMtuPackets.....	199	IfRTPStatsRXSeq.....	130
IfMPEGoUDPStatsRXMtuRate.....	199	IfRTPStatsRXSyncSrc.....	130
IfMPEGoUDPStatsRXPopTimeouts.....	200	IfRTPStatsRXTIMEouts.....	131
IfMPEGoUDPStatsRXPushTimeouts.....	200	IfS2BBFoERxAcmeErrors.....	204
IfMPEGoUDPStatsTXLastTSnbr.....	132	IfS2BBFoERxCounters.....	135
IfMPEGoUDPStatsTXMpegDrop.....	201	IfS2BBFoERxDflErrors.....	204
IfMPEGoUDPStatsTXMpegPackets.....	201	IfS2BBFoERxFramesRxed.....	203
IfMPEGoUDPStatsTXMtuBytes.....	202	IfS2BBFoERxTransphdrErrors.....	203
IfMPEGoUDPStatsTXMtuPackets.....	201	IfStrConfig.....	78
IfMPEGoUDPStatsTXMtuRate.....	202	IfStrConfigEnable.....	183
IfMPEGoUDPStatsTXPopTimeouts.....	201	IfStrConfigStreamId.....	182
IfMPEGoUDPStatsTXPushTimeouts.....	202	IfUleSettings.....	59
IfMpEStats.....	137	IfUleSettingsCRC.....	181
IfMpEStatsReset.....	137	IfUleSettingsDestMac.....	178
IfMpEStatsRXCRCErrors.....	210	IfUleStats.....	136
IfMpEStatsRXMpegPackets.....	209	IfUleStatsReset.....	135
IfMpEStatsRXMtuBytes.....	209	IfUleStatsRXCRCErrors.....	207
IfMpEStatsRXMtuPackets.....	209	IfUleStatsRXIdle.....	207
IfMpEStatsRXMtuRate.....	209	IfUleStatsRXMpegPackets.....	207
IfMpEStatsTXMpegPackets.....	208	IfUleStatsRXMtuBytes.....	206
IfMpEStatsTXMtuBytes.....	208	IfUleStatsRXMtuPackets.....	206
IfMpEStatsTXMtuPackets.....	208	IfUleStatsRXMtuRate.....	206
IfMpEStatsTXMtuRate.....	208	IfUleStatsRXPopTimeouts.....	207
IfOutputClock.....	105	IfUleStatsRXPushTimeouts.....	207
IfPacketGenBitRate.....	128	IfUleStatsTXIdle.....	206
IfPacketGenBytesToTx.....	128	IfUleStatsTXMpegPackets.....	205
IfPacketGenFormat.....	127	IfUleStatsTXMtuBytes.....	204
IfPacketGenProbe.....	126	IfUleStatsTXMtuPackets.....	204
IfPacketInsStreamId.....	56	IfUleStatsTXMtuRate.....	205
IfPacketLogAction.....	124	IfUleStatsTXPopTimeouts.....	205

IfUleStatsTXPushTimeouts.....	205	MoAESKeyParityISI.....	.96
IfVLANForwarding.....	56	MoAESOddGlobalKey.....	.95
IfVLANStats.....	142	MoAESOddKeyISI.....	.98
IfVLANStatsActive.....	222	MoAmplEq.....	.90
IfVLANStatsName.....	222	MoBBLEfficiency.....	.153
IfVLANStatsRxBytes.....	223	MoBbNcoMode.....	.242
IfVLANStatsRxPackets.....	223	MoBbNcoRate.....	.242
IfVLANStatsTxBytes.....	223	MoBBSShortFrameRatio.....	.153
IfVLANStatsTxPackets.....	222	MoBufCont.....	.146
IfVLANSupport.....	53	MoBufFramSetp.....	.241
IfVLANTypeId.....	57	MoBufNonQosTimeLim.....	.235
IfVolreqStats.....	133	MoBufSetp.....	.241
IfVolreqStatsMovAvgVol.....	202	MoBufSize.....	.147
IfVolreqStatsMovMaxVol.....	203	MoBufTimeLimit.....	.234
IfVolreqStatsMovMinVol.....	203	MoCaMod.....	.77
InpRateEstim.....	146	MoClkLoopState.....	.149
MdModStand.....	44	MoCntRst.....	.152
MdProcMode.....	44	MoDelaySetp.....	.148
MoAcmCtrlCommFailModcod.....	84	MoDFL.....	.80
MoAcmCtrlDistortSpec.....	85	MoDFLMode.....	.79
MoAcmCtrlEnable.....	81	MoDlyMode.....	.240
MoAcmCtrlMaxModcod.....	83	MoDummyPLCntr.....	.152
MoAcmCtrlMinMargSpec.....	85	MoDummyPLRate.....	.152
MoAcmCtrlMinModcod.....	82	MoExcBw.....	.90
MoAcmCtrlMonitorOnly.....	86	MoFecMod2.....	.72
MoAcmCtrlTgtMargSpec.....	85	MoFrameType.....	.74
MoAcmDemodLog.....	154	MoGainCtrlMode.....	.76
MoAcmDemodLogToday.....	155	MoGainCtrlState.....	.149
MoAcmDemodLogYestrd.....	156	MoInpPacketCnt.....	.150
MoAcmDiagLog.....	154	MoInpPacketRate.....	.151
MoAcmDmSupvEntry.....	87	MoInpRate.....	.74
MoAcmDmSupvIp.....	196	MoISI.....	.81
MoAcmDmSupvStrid.....	196	MoLinPredMode.....	.88
MoAcmFwSigPlane.....	86	MoMainState.....	.149
MoACMMode.....	71	MoMonAcmDmSupvEntry.....	.154
MoAcmRtSigPlane.....	108	MoMonAcmDmSupvEsno.....	.226
MoAESEnableEncGlobal.....	92	MoMonAcmDmSupvIp.....	.225
MoAESEnableEnclSI.....	95	MoMonAcmDmSupvModcod.....	.226
MoAESEncEvenGlobalKey.....	93	MoMonAcmDmSupvNumCto.....	.227
MoAESEncEvenKeyISI.....	96	MoMonAcmDmSupvNumRx.....	.227
MoAESEncOddGlobalKey.....	94	MoMonAcmDmSupvNumTo.....	.227
MoAESEncOddKeyISI.....	97	MoMonAcmDmSupvStrid.....	.225
MoAESEncryptionCtrl.....	92	MoMonAcmStreamEntry.....	.155
MoAESEvenGlobalKey.....	94	MoMonAcmStreamFrameType.....	.224
MoAESEvenKeyISI.....	97	MoMonAcmStreamModcod.....	.224
MoAESKeyISI.....	95	MoMonAcmStreamNChanges.....	.224
MoAESKeyParityGlob.....	93	MoMonAcmStreamStrid.....	.224

MoMonOutputFreq.....	145	SyConfigStatus.....	.229
MoMonOutputMode.....	90	SyDevActivate.....	.22
MoMonSpectInv.....	145	SyDevCapab.....	.41
MoNonLinPredMode.....	89	SyDevCapPass.....	.228
MoOccBw.....	91	SyDevCapReply.....	.228
MoODU100.....	29	SyDevDispContrast.....	.17
MoOLevelOffset.....	26	SyDevGenerate.....	.22
MoOpOutputFreq.....	75	SyDevHwCapab.....	.39
MoOutLevelDet.....	147	SyDevHwId.....	.36
MoOutLevelPlan.....	76	SyDevHwVer.....	.39
MoOutputEnable.....	77	SyDevIPAddr.....	.15
MoOutputLevel.....	75	SyDevIPCoreSwId.....	.42
MoPacketCnt.....	151	SyDevIPCoreSwVer.....	.42
MoPacketRate.....	151	SyDevIPGateWay.....	.15
MoPhaseErrDev.....	148	SyDevIPMask.....	.15
MoPilots.....	73	SyDevMacAddr.....	.16
MoPLEfficiency.....	153	SyDevMode.....	.12
MoPLSSignature.....	87	SyDevModePass.....	.227
MoSpectInv.....	88	SyDevModeReply.....	.228
MoSymRate.....	75	SyDevModeState.....	.187
MoSYNCD.....	80	SyDevPowM12V.....	.32
MoTgFecMod2.....	239	SyDevPowP12V.....	.32
MoTgFrameType.....	238	SyDevPowP3V3.....	.31
MoTgPilots.....	240	SyDevPowP5V.....	.31
MoTgTimMode.....	243	SyDevProdId.....	.37
MoTxData.....	238	SyDevProdNbr.....	.42
MoTxOffs.....	147	SyDevRmcver.....	.13
MoTxStatus.....	150	SyDevRs485Addr.....	.14
ODCurLimits.....	29	SyDevRst.....	.21
ODMeasPow.....	145	SyDevRtc.....	.13
ODPow.....	28	SyDevSerifType.....	.14
91		SyDevSleepMode.....	.20
ODUInfofold.....	229	SyDevSn.....	.4, 37
ODUInfoReq.....	237	SyDevSwCapab.....	.40
ODUInfoVal.....	229	SyDevSwId.....	.40
ODUSSPAARfAITrippoint.....	236	SyDevSwVer.....	.40
ODUSSPAAttenuation.....	237	SyDevType.....	.41
SyActionKeyId.....	228	SyDevUptime.....	.13
SyActionKeyReply.....	228	SyEthTransType.....	.16
SyActKeyActivate.....	253	SyInputAIEscallation.....	.23
SyBucketVersion.....	37	SyIntAlarmMaskMode.....	.23
SyBuDeclPGateWay.....	64	SyIntTemp.....	.31
SyCfgName.....	166	SyLoadConfNum.....	.230
SyConfigLoadFlash.....	165	SyOSVer.....	.38
SyConfigName.....	230	SyPPCVer.....	.38
SyConfigNum.....	229	SyRamDiskVer.....	.38
SyConfigSaveFlash.....	166	SyRef10MCalib.....	.25

SyRef10MCtrl.....	25	SyTestRst.....	243
SyRef10MLevel.....	32	SyTrapCommunity.....	19
SyRef10MTuning.....	24	SyTrapIPAddr.....	18
SyRefClock.....	24	SyTSRapport.....	43
SyRFCalcForm.....	33	SyUnitRedunOperState.....	115
SyROCommunity.....	18	WILogInOldPass.....	193
SyRWCommunity.....	18	WILogInPass.....	194
SySaveConfNum.....	230	WILogInReply.....	194
SyScreenSaveDly.....	17	WILogInUser.....	193
SyScreenSaveMsg.....	17	WILogInUserAccess.....	193
SySigIp.....	62	WIUsers.....	19
SySnmpVer.....	39		